

Parts Catalog

FARMTRAC

TRACTOR FARMTRAC 30 H

Escorts Agri Machinery

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
1	ENGINE ASSEMBLY MITSUBISHI MVS3L2-Z361ET-21.3KW@2800RPM EXPORT DRESSED UP WITH CLUTCH ASSEMBLY	1	1-2
2	CYLINDER HEAD	2	3-4
3	LIFTING EYE	3	5-6
4	VALVE MECHANISM	4	7-8
5	ROCKER COVER	5	9-10
6	CAMSHAFT & TAPPET	6	11-12
7	CRANKCASE (ASSY)	7	13-14
8	CRANKCASE (OIL SEAL CASE)	8	15-16
9	DRAIN COCK & PIPE	9	17-18
10	INLET SYSTEM	10	19-20
11	MAIN BEARING	11	21-22
12	CONNECTING ROD	12	23-24
13	EXHAUST SYSTEM	13	25-26
14	TIMING GEAR CASE	14	27-28
15	CRANKSHAFT	15	29-30
16	OIL PUMP	16	31-32
17	TIMING GEAR	17	33-34
18	CRANK PULLEY	18	35-36
19	OIL STRAINER	19	37-38
20	OIL SYSTEM	20	39-40
21	OIL FILTER	21	41-42
22	OIL PAN	22	43-44
23	OIL FILLER & GUAGE	23	45-46
24	ENGINE SUPPORT	24	47-48
25	BREATHER	25	49-50
26	PISTON	26	51-52
27	WATER PUMP	27	53-54
28	FUEL SYSTEM	28	55-56
29	WATER PUMP PULLEY	29	57-58
30	COOLING SYSTEM	30	59-60

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
31	FAN SPACER	31	61-62
32	FUEL SYSTEM (NOZZLE ASSY)	32	63-64
33	GOVERNOR	33	65-66
34	INJECTION PUMP	34	67-68
35	FUEL INJECTION PUMP DRIVE	35	69-70
36	GLOW PLUG & WIRE	36	71-72
37	ENGINE CONTROL (STOP)	37	73-74
38	INJECTION PUMP (ASSY)	38	75-76
39	ACCESSORY	39	77-78
40	INSTRUMENT	40	79-80
41	OVERHAUL GASKET KIT	41	81-82
42	COOLING SYSTEM SUBASSEMBLY	42	83-84
43	AIR CLEANER SUBASSEMBLY	43	85-86
44	EXHAUST SYSTEM SUBASSEMBLY	44	87-88
45	COOLER OIL SUBASSEMBLY (HST)	45	89-90
46	TRANSMISSION ASSEMBLY DRESSED UP	46	91-92
47	HARDWARE BUCKLE UP HOUSING INTERMEDIATE AND FRONT SUBASSEMBLY	47	93-94
48	DRIVE TRAIN INPUT FRONT HOUSING HST ASSEMBLY	48	95-96
49	HOUSING FRONT HST ASSEMBLY	49	97-98
50	HST UNIT SUBASSEMBLY WITH HARDWARE	50	99-100
51	DRIVE TRAIN 4WD SUBASSEMBLY (HST)	51	101-102
52	RETAINER AND GEAR PAIR INPUT SUB ASSEMBLY WITH HARDWARE (HST)	52	103-104
53	HOUSING ASSEMBLY INTERMEDIATE (HST)	53	105-106
54	CLUTCH WET PTO SUBASSEMBLY	54	107-108
55	PLATE INTERMEDIATE TRANSMISSION ASSEMBLY	55	109-110
56	BRAKE LINKAGE SUB ASSEMBLY (HST)	56	111-112
57	GEAR ASSEMBLY 4WD IDLER	57	113-114
58	DRIVE TRAIN RANGE GEAR ASSEMBLY	58	115-116
59	RANGE GEAR SHIFTING ASSEMBLY (COMPACT)	59	117-118
60	HOUSING REAR AXLE CENTRE SUBASSEMBLY (HST)	60	119-120

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
61	GEAR AND DIFFERENTIAL REAR AXLE SUBASSEMBLY	61	121-122
62	DIFFERENTIAL LOCK SUBASSEMBLY	62	123-124
63	RETAINER BEARING DIFFERENTIAL SUBASSEMBLY LH	63	125-126
64	RETAINER BEARING DIFFERENTIAL SUBASSEMBLY RH	64	127-128
65	HOUSING REAR AXLE RH SUBASSEMBLY	65	129-130
66	HOUSING REAR AXLE LH SUBASSEMBLY	66	131-132
67	PTO REAR SHIFTING ASSEMBLY (HST)	67	133-134
68	PTO MID SHIFTING ASSEMBLY	68	135-136
69	GEARS AND SHAFT PTO SUBASSEMBLY (HST)	69	137-138
70	PTO MID DROP BOX ASSEMBLY	70	139-140
71	HARDWARE BUCKLE UP TRANSMISSION AND REAR AXLE SUBASSEMBLY	71	141-142
72	FRONT AXLE ASSY.	72	143-144
73	HOUSING ASSEMBLY SWIVEL FRONT AXLE RH (4WD COMPACT)	74	145-148
74	HOUSING ASSEMBLY SWIVEL FRONT AXLE LH (4WD COMPACT)	75	149-152
75	PILLOW BLOCK SUBASSEMBLY FRONT	75	153-154
76	PILLOW BLOCK SUBASSEMBLY REAR	76	155-156
77	DIFFERENTIAL ASSEMBLY FRONT AXLE (4WD COMPACT)	77	157-158
78	RETAINER AND BEVEL PINION SHAFT ASSEMBLY FRONT AXLE (4WD COMPACT)	78	159-160
79	INDICATOR FRONT AXLE OIL LEVEL	79	161-162
80	AXLE FRONT WITH CYLINDER AND LINK ASSEMBLY	80	163-164
81	COVER ASSEMBLY GUARD STEERING CYLINDER	81	165-166
82	SUPPORT AND FRONT AXLE ASSEMBLY	82	167-168
83	WEIGHT FRONT AND BUMPER ASSEMBLY	83	169-170
84	BUMPER AND NUT ASSEMBLY FRONT	84	171-172
85	TOW HOOK ASSEMBLY FRONT	85	173-174
86	COUPLING TRANSMISSION CLUTCH HOUSING ASSEMBLY	86	175-176
87	LEVER POSITION CONTROL SUBASSEMBLY	87	177-178
88	FRAME FUEL TANK AND BRACKET HINGE ASSEMBLY	88	179-180
89	FUEL TANK SUBASSEMBLY	89	181-182
90	FUEL TANK FUEL SYSTEM AND TUBING SUBASSEMBLY	90	183-184

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
91	WHEEL STEERING AND UNIT STEERING SUBASSEMBLY	91	185-186
92	PEDAL SPEED CONTROL AND CRUISE CONTROL SUBASSEMBLY	92	187-190
93	LEVER RANGE HIGH LOW MEDIUM GEAR SHIFT SUBASSEMBLY	93	191-192
94	LEVER PTO GEAR SHIFT SUBASSEMBLY	95	193-194
95	LEVER MID PTO GEAR SHIFT SUBASSEMBLY	96	195-196
96	LINKAGE ASSEMBLY DIFFERENTIAL LOCK CONTROL	96	197-198
97	LINKAGE THROTTLE SUBASSEMBLY	97	199-200
98	LEVER CONTROL 2WD 4WD SUBASSEMBLY	99	201-202
99	LINKAGE THREE POINT COMPACT TRACTOR SUBASSEMBLY	100	203-204
100	PUMP HYDRAULIC LIFT ASSEMBLY	100	205-206
101	TUBING HYDRAULIC SUCTION SUBASSEMBLY	101	207-208
102	TUBING POWER STEERING SUBASSEMBLY	102	209-212
103	TUBING AUXILLARY VALVE SUBASSEMBLY	103	213-214
104	HYDRAULIC LIFT SUBASSEMBLY (HST)	104	215-216
105	CYLINDER ASSY	105	217-218
106	INTERNAL LEVER ASSY	106	219-220
107	TOP LINK BRACKET ASSY	107	221-222
108	CONTROL LEVERS ASSY	108	223-224
109	SEAT DRIVER SUBASSEMBLY	109	225-226
110	HITCH REAR SWINGING DRAWBAR SUBASSEMBLY	110	227-228
111	FENDER SUB ASSEMBLY	111	229-232
112	BOARD RUNNING RH AND LH SUBASSEMBLY	112	233-234
113	HOOD FRONT AND MIRROR SUBASSEMBLY	113	235-236
114	HOOD FRONT LOWER ASSEMBLY	114	237-238
115	HOOD FRONT LOWER SIDE LH ASSEMBLY	115	239-240
116	HOOD FRONT LOWER SIDE RH ASSEMBLY	116	241-242
117	HEADLAMP AND BRACKET MOUNTING ASSEMBLY RH	117	243-244
118	HOOD REAR SUBASSEMBLY (HST)	118	245-246
119	PANEL HOOD REAR AND SWITCH SUBASSEMBLY (HST)	119	247-248
120	BAFFLE PLATE SIDE ASSEMBLY	120	249-250

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
121	LATCH ASSEMBLY HOOD FRONT	121	251-252
122	COVER ASSEMBLY ENGINE SIDE RH	122	253-254
123	COVER ASSEMBLY ENGINE SIDE LH	115	255-256
124	MIRROR AND FRONT LAMP SUBASSEMBLY	124	257-258
125	GUIDE SUPPORT AND GAS SPRING FRONT HOOD SUBASSEMBLY	125	259-260
126	GUIDE SUPPORT AND RADIATOR FRAME SUBASSEMBLY	126	261-262
127	HARNESS SUBASSEMBLY	127	263-266
128	GUARD PROPELLER SHAFT SUBASSEMBLY	128	267-268
129	WHEEL AND TYRE ASSEMBLY FRONT 23X8.50-12 (M/S BKT - INDUSTRIAL)	129	269-270
130	ROPS FOLDABLE SUBASSEMBLY	130	271-272
131	WHEEL AND TYRE ASSEMBLY REAR 33X15.50-16.50 (M/S BKT - INDUSTRIAL)	131	273-274
132	DECAL AND BADGES MODEL IDENTIFICATION ASSEMBLY HST	132	275-276
133	CONSUMABLES SUBASSEMBLY	133	277-278
134	HARDWARE BUCKLE UP CLUTCH HOUSING & SPEED HOUSING SUBASSEMBLY	134	279-280
135	HARDWARE BUCKLE UP ADAPTOR PLATE & BACKEND HOUSING SUBASSEMBLY	135	281-282
136	KIT ENGINE OVERHAULING WITH HEAD GASKET (COMPACT TRACTOR)	136	283-284
137	KIT ENGINE OVERHAULING WITH GASKET / MAIN UNDER SIZE 0.25 AND CONNECTING ROD BEARING SET SIZE 0.25	137	285-286
138	KIT ENGINE OVERHAULING WITH GASKET / MAIN UNDER SIZE 0.50 AND CONNECTING ROD BEARING SET SIZE 0.50	138	287-288
139	KIT ENGINE VALVES INLET AND EXHAUST (COMPACT)	139	289-290
140	KIT GASKETS OVERHAULING WITH HEAD GASKET (COMPACT)	140	291-292

TABLE-1
ENGINE ASSEMBLY MITSUBISHI MVS3L2-Z361ET-21.3KW@2800RPM EXPORT DRESSED UP WITH CLUTCH ASSEMBLY




TABLE-1**ENGINE ASSEMBLY MITSUBISHI MVS3L2-Z361ET-21.3KW@2800RPM EXPORT DRESSED UP WITH CLUTCH ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D87500720.9	PIN 6X20 PLAIN DOWEL	3
3	D86500030.9	WASHER M8 SPRING LOCK	2
4	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	6
5	D10017460.9	CLAMP ASSEMBLY FUEL TUBE	1
6	D10567380.9	HOSE ASSEMBLY FUEL TANK RETURN	1
12	D10524990.9	LEVER ALTERNATOR ADJUSTING	1
13	D84500450.9	STUD B M12X45-10.9	2
14	D10607060.9	FLYWHEEL ASSEMBLY (MITSUBISHI MVS3L2-W463JCET)	1
15	D87500570.9	PIN 9.5X20 PLAIN DOWEL	2
16	D81503200.9	BOLT M12X1.25X30-10.9 HEX HEAD	12
17	D10702040.9	GASKET REAR PLATE ENGINE	1
18	D10702010.9	ADAPTER ENGINE TRANSMISSION COUPLING	1
18-1	D10524940.9	ADAPTER ENGINE TRANSMISSION COUPLING	1
19	D10524980.9	GASKET STARTER MOTOR	1
20	D10525010.9	SPACER ALTERNATOR ADJUSTMENT	1
21	D10101750.9	BOLT M10X1.50X25-8.8 HEX HEAD	2
22	D81500470.9	BOLT M10X1.50X115 HEX HEAD	1
23	D83500170.9	NUT M10X1.50 NYLOCK HEX	1
24	D86500050.9	WASHER M10 SPRING LOCK	2
25	D82500060.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
26	D83500060.9	NUT M8X1.25-6 HEX	1
27	D85500050.9	WASHER M8 FLAT	1
28	D10536230.9	ENGINE ASSEMBLY MITSUBISHI-MVS3L2-Z361ET-21.3KW 2800RPM-EXPORT	1

TABLE-2
CYLINDER HEAD




TABLE-2
CYLINDER HEAD

Fig. No.	Part No.	Description	Qty
1	D10732550.9	HEAD ASSY,CYLINDER (MITSUBISHI PART NO. 31N01-01053)	1
2	D10732560.9	SEAT,INLET VALVE (MITSUBISHI PART NO.31A01-01201)	3
3	D10732570.9	SEAT EXHAUST VALVE (MITSUBISHI PART NO.31A01-01301)	3
4	D10732610.9	BOLT CYLINDER HEAD (MITSUBISHI PART NO.31A01-21100)	11
5	D10732620.9	GASKET CYLINDER HEAD (MITSUBISHI PART NO.31B01-23200)	1
6	D10732630.9	GUIDE EXHAUST VALVE (MITSUBISHI PART NO.31N01-00800)	3
7	D10732640.9	GUIDE INLET VALVE (MITSUBISHI PART NO.31N01-02300)	3

TABLE-3
LIFTING EYE




TABLE-4
VALVE MECHANISM




TABLE-4
VALVE MECHANISM

Fig. No.	Part No.	Description	Qty
1	D10732680.9	VALVE INLET (MITSUBISHI PART NO.31N04-01300)	3
2	D10732690.9	VALVE EXHAUST (MITSUBISHI PART NO. 31N04-01400)	3
3	D10732700.9	SPRING VALVE (MITSUBISHI PART NO. 31N04-01500)	6
4	D10732710.9	RETAINER VALVE SPRING (MITSUBISHI PART NO. MM433-30601)	6
5	D10732720.9	LOCK SPRING RETAINER (MITSUBISHI PART NO. 30N04-00500)	12
6	D10732730.9	SEAL,VALVE STEM (MITSUBISHI PART NO. MD115472)	6
7	D10732740.9	CAP,VALVE STEM (MITSUBISHI PART NO. 31A04-00700)	6
8	D10732750.9	SHAFT ASSY,ROCKER(MITSUBISHI PART NO. 31N04-10080)	1
9	D10732760.9	BRACKET,ROCKER SHAFT (MITSUBISHI PART NO. 31N04-00800)	2
10	D10732770.9	SPRING,ROCKER SHAFT(MITSUBISHI PART NO. 31N04-00900)	2
11	D10732780.9	BRACKET,ROCKER SHAFT (MITSUBISHI PART NO. 31N04-01700)	1
12	D10732790.9	ARM,ROCKER(MITSUBISHI PART NO. 31N04-03500)	6
13	D10732800.9	SHAFT ASSY,ROCKER(MITSUBISHI PART NO. 31N04-10010)	1
14	D10732810.9	CAP,SEALING(MITSUBISHI PART NO. 31N04-00200)	2
15	D10732820.9	SCREW,ROCKER(MITSUBISHI PART NO. 32A04-02401)	6
16	D10732830.9	BOLT(MITSUBISHI PART NO. F1035-05010)	1
17	D10732840.9	NUT,(MITSUBISHI PART NO. F2325-08000)	6
18	D10732850.9	RING,SNAP(MITSUBISHI PART NO. F3200-01900)	2
19	D10732860.9	BOLT,ROCKER BRACKET(MITSUBISHI PART NO. 31N04-01100)	3

TABLE-5
ROCKER COVER




TABLE-5
ROCKER COVER

Fig. No.	Part No.	Description	Qty
1	D10732870.9	COVER ASSY,ROCKER (MITSUBISHI PART NO. 31N04-00071)	1
2	D10698140.9	GASKET ROCKER COVER (MITSUBISHI PART NO 31B0413201)	1
3	D10732890.9	BOLT,W/WASHER(MITSUBISHI PART NO. F1805-08040)	4
4	D10732900.9	CAP,OIL FILLER (MITSUBISHI PART NO. MD008784)	1

TABLE-6
CAMSHAFT & TAPPET




TABLE-6
CAMSHAFT & TAPPET

Fig. No.	Part No.	Description	Qty
1	D10732910.9	CAMSHAFT (MITSUBISHI PART NO. 31N05-00600)	1
2	D10732920.9	KEY,WOODRUFF (MITSUBISHI PART NO. F2872-05019)	1
3	D10732930.9	PLATE,THRUST (MITSUBISHI PART NO. 31N05-00300)	1
4	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	2
5	D10732950.9	TAPPET (MITSUBISHI PART NO. 31N05-00400)	6
6	D10732960.9	ROD,PUSH (MITSUBISHI PART NO. 31N05-00500)	6
7	D10419680.9	PLATE SUPPORT DEFLECTOR AIR	1

TABLE-7
CRANKCASE (ASSY)




TABLE-7
CRANKCASE (ASSY)

Fig. No.	Part No.	Description	Qty
1	D10732970.9	BLOCK ASSY,CYLINDER (MITSUBISHI PART NO. 31N07-01090)	AR
2	D10732980.9	BOLT,BEARING CAP(MITSUBISHI PART NO.31A07-00801)	8
3	D10732990.9	BUSH,CAMSHAFT (MITSUBISHI PART NO.31A07-03100)	1
4	D10733000.9	CAP,SEALING (MITSUBISHI PART NO.31N07-01800)	2
5	D10733010.9	CAP,SEALING (MITSUBISHI PART NO.31N07-01900)	2
6	D10733020.9	GUIDE,OIL LEVEL GAUGE (MITSUBISHI PART NO.30N07-02100)	1
7	D10733030.9	CAP,SEALING (MITSUBISHI PART NO.F5014-12000)	1
8	D10733040.9	CAP,SEALING (MITSUBISHI PART NO.F5014-14000)	1
9	D10732600.9	PLUG TAPERED (MITSUBISHI PART NO.30N01-01600)	1
10	D10733050.9	PLUG,TAPERED MEC (MITSUBISHI PART NO.31N07-02100)	2
11	D10733060.9	BUSHING,KNOCK (MITSUBISHI PART NO.31N07-01100)	4
12	D10733070.9	BUSHING,KNOCK (MITSUBISHI PART NO.30N07-03200)	2
13	D10733080.9	BUSHING,KNOCK (MITSUBISHI PART NO.31N07-01300)	1
14	D10733090.9	PLUG,EXPANSION (MITSUBISHI PART NO.MF665511)	1
15	D10733100.9	PIN,DOWEL (MITSUBISHI PART NO.30N07-02700)	1
16	D10733110.9	PIN,DOWEL (MITSUBISHI PART NO.30N07-00600)	2
17	D10733120.9	SHAFT ASSY,IDLER (MITSUBISHI PART NO.31N07-00050)	1
18	D10733130.9	STEEL BALL,BEARING(MITSUBISHI PART NO.F8000-08000)	1
19	D10733140.9	PIN,DOWEL (MITSUBISHI PART NO.F2846-05000)	2
20	D10733150.9	PLUG,TAPERED (MITSUBISHI PART NO.31N07-02200)	1

TABLE-8
CRANKCASE (OIL SEAL CASE)




TABLE-8**CRANKCASE (OIL SEAL CASE)**

Fig. No.	Part No.	Description	Qty
1	D10733160.9	SEAL,SIDE (MITSUBISHI PART NO.31A07-12200)	4
2	D10733170.9	SHAFT,OIL FILTER (MITSUBISHI PART NO.30N07-02400)	1
3	D10733180.9	CASE,OIL SEAL (MITSUBISHI PART NO.31N07-01400)	1
4	D10733190.9	GASKET,OIL SEAL CASE (MITSUBISHI PART NO.31A07-11701)	1
5	D10698310.9	SEAL OIL (MITSUBISHI PART NO 31A0702300)	1
6	D10733210.9	BOLT (MITSUBISHI PART NO. 31N07-02300)	5

TABLE-9
DRAIN COCK & PIPE




TABLE-9
DRAIN COCK & PIPE

Fig. No.	Part No.	Description	Qty
1	D10733220.9	PLUG,TAPERED (MITSUBISHI PART NO. 30N07-02500)	1
2	D10151390.9	END ASSEMBLY FUEL SHUT OFF LEVER	1

TABLE-10
INLET SYSTEM




TABLE-10
INLET SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10733850.9	COVER ASSY,INLET (MITSUBISHI PART NO. 31N30-00031)	1
2	D10733860.9	GASKET,INLET COVER (MITSUBISHI PART NO.31N30-01300)	1
3	D10733870.9	BOLT,W/WASHER (MITSUBISHI PART NO.F1805-08035)	5

TABLE-11
MAIN BEARING




TABLE-11
MAIN BEARING

Fig. No.	Part No.	Description	Qty
1	D10733230.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01010)	1
2	D10733240.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01020)	1
3	D10733250.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01030)	1
4	D10733260.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01040)	1

TABLE-12
CONNECTING ROD




TABLE-12
CONNECTING ROD

Fig. No.	Part No.	Description	Qty
1	D10733660.9	ROD ASSY,CONNECTING (MITSUBISHI PART NO. 31N19-00070)	3
2	D10733670.9	NUT,CONNECTING ROD (MITSUBISHI PART NO. MD006704)	6
3	D10733680.9	BOLT,CONNECTING ROD (MITSUBISHI PART NO. MD021105)	6
4	D10733690.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO.30A19-00040)	3
5	D10733700.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10010)	3
6	D10733710.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10020)	3
7	D10733720.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10030)	3

TABLE-13
EXHAUST SYSTEM




TABLE-13
EXHAUST SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10733880.9	MANIFOLD,EXHAUST (MITSUBISHI PART NO. 31N32-00100)	1
2	D10733890.9	GASKET,EXHAUST MANIFOLD (MITSUBISHI PART NO. 31B32-01200)	1
3	D10733900.9	STUD (MITSUBISHI PART NO. F1450-08025)	4
4	D10733910.9	BOLT (MITSUBISHI PART NO. F1035-08020)	4
5	D10733920.9	BOLT (MITSUBISHI PART NO. F1035-08055)	2
6	D10010060.9	GASKET EXHAUST ELBOW	1

TABLE-14
TIMING GEAR CASE




TABLE-14
TIMING GEAR CASE

Fig. No.	Part No.	Description	Qty
1	D10733270.9	PLATE,FRONT (MITSUBISHI PART NO. 31A11-02100)	1
2	D10733280.9	GASKET,FRONT PLATE (MITSUBISHI PART NO. 31N11-00600)	1
3	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	5
4	D10733290.9	CASE,GEAR (MITSUBISHI PART NO. 31A11-10103)	1
5	D10733300.9	GASKET,GEAR CASE (MITSUBISHI PART NO. 31A11-11101)	1
6	D10733310.9	BOLT (MITSUBISHI PART NO. 31N11-00900)	8
7	D10698380.9	OIL SEAL (MITSUBISHI PART NO MD008762)	1
8	D10733330.9	HOUSING,GEAR PUMP (MITSUBISHI PART NO. 31A11-05101)	1
9	D10733340.9	GASKET,HOUSING (MITSUBISHI PART NO.31A11-05201)	1
10	D10733350.9	COVER,OIL PUMP SHAFT (MITSUBISHI PART NO.MM401205)	1
11	D10733360.9	COVER,OIL PUMP (MITSUBISHI PART NO. K7910451)	1
12	D10733370.9	GASKET,OIL PUMP COVER (MITSUBISHI PART NO. 30A11-00101)	2
13	D10733380.9	CAP,FILLER (MITSUBISHI PART NO. 31A42-01300)	1
14	D10733390.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08030)	1
15	D10733400.9	STUD (MITSUBISHI PART NO. MS401433)	1
16	D10733410.9	STUD (MITSUBISHI PART NO.MS401426)	1
17	D10733420.9	NUT (MITSUBISHI PART NO. F2300-08000)	4
18	D10733430.9	BOLT,W/WASHER (MITSUBISHI PART NO.F1825-08016)	4
19	D10733440.9	BOLT (MITSUBISHI PART NO. F1035-08070)	2
20	D10733450.9	WASHER,SPRING (MITSUBISHI PART NO. F2515-08000)	4

TABLE-15
CRANKSHAFT




TABLE-15
CRANKSHAFT

Fig. No.	Part No.	Description	Qty
1	D10733730.9	CRANKSHAFT (MITSUBISHI PART NO. 31B20-00204)	1
2	D10732920.9	KEY,WOODRUFF (MITSUBISHI PART NO. F2872-05019)	2
3	D10733740.9	WASHER,PLAIN (MITSUBISHI PART NO. F2500-18000)	1
4	D10733750.9	WASHER,SPRING (MITSUBISHI PART NO.F2515-18000)	1
5	D10733760.9	NUT (MITSUBISHI PART NO. F2300-18000)	1

TABLE-16
OIL PUMP




TABLE-16
OIL PUMP

Fig. No.	Part No.	Description	Qty
1	D10733930.9	PUMP ASSY,OIL (MITSUBISHI PART NO.31N35-00010)	1
2	D10733940.9	PACKING,BODY (MITSUBISHI PART NO. 31N35-01900)	1
3	D10733950.9	BOLT (MITSUBISHI PART NO. F1035-08025)	3

TABLE-17
TIMING GEAR




TABLE-17
TIMING GEAR

Fig. No.	Part No.	Description	Qty
1	D10733780.9	GEAR,CRANKSHAFT (MITSUBISHI PART NO. 31N23-10300)	1
2	D10733790.9	GEAR,CAMSHAFT (MITSUBISHI PART NO. 31N23-10400)	1
3	D10733800.9	GEAR,INJECTION PUMP (MITSUBISHI PART NO. 31N23-00700)	1
4	D10733810.9	GEAR ASSY,IDLER (MITSUBISHI PART NO. 31N23-10020)	1
5	D10733820.9	BUSHING,IDLER GEAR (MITSUBISHI PART NO. 31A23-00600)	1
6	D10733830.9	GEAR,OIL PUMP (MITSUBISHI PART NO. 31A23-01502)	1
7	D10733840.9	BEARING,BALL (MITSUBISHI PART NO.MD712517)	2

TABLE-18
CRANK PULLEY




TABLE-18
CRANK PULLEY

Fig. No.	Part No.	Description	Qty
1	D10733770.9	PULLEY,CRANK (MITSUBISHI PART NO.31N20-00601)	1

TABLE-19
OIL STRAINER




TABLE-19
OIL STRAINER

Fig. No.	Part No.	Description	Qty
1	D10733960.9	STRAINER ASSY (MITSUBISHI PART NO.31N35-00050)	1
2	D10733970.9	NUT,JAM (MITSUBISHI PART NO.F2320-16000)	1
3	D10733980.9	GASKET (MITSUBISHI PART NO. MF660036)	1

TABLE-20
OIL SYSTEM




TABLE-21
OIL FILTER




TABLE-21
OIL FILTER

Fig. No.	Part No.	Description	Qty
1	D10671130.9	FILTER ASSEMBLY LUBE OIL	1

TABLE-22
OIL PAN




TABLE-22**OIL PAN**

Fig. No.	Part No.	Description	Qty
1	D10733460.9	PAN ASSY,OIL (MITSUBISHI PART NO. 31N13-02010)	1
2	D10733470.9	GASKET (MITSUBISHI PART NO. 31N13-00400)	2
3	D10733480.9	PLUG,DRAIN (MITSUBISHI PART NO. 31N13-00500)	2
4	D10733490.9	BOLT,FLANGE (MITSUBISHI PART NO. 30H13-00801)	12
5	D10733500.9	BOLT (MITSUBISHI PART NO.F1035-08040	1
6	D10733510.9	BOLT (MITSUBISHI PART NO. MM434762)	2

TABLE-23
OIL FILLER & GUAGE




TABLE-23
OIL FILLER & GUAGE

Fig. No.	Part No.	Description	Qty
1	D10734020.9	GAGE,OIL LEVEL (MITSUBISHI PART NO. 31N42-00500)	1

TABLE-24
ENGINE SUPPORT




TABLE-24
ENGINE SUPPORT

Fig. No.	Part No.	Description	Qty
1	D10733520.9	BOLT (MITSUBISHI PART NO. F1035-12025)	4

TABLE-25
BREATHER




TABLE-25
BREATHER

Fig. No.	Part No.	Description	Qty
1	D10698180.9	HOSE BREATHER (MITSUBISHI PART NO 31N4300101)	1

TABLE-26
PISTON




TABLE-26**PISTON**

Fig. No.	Part No.	Description	Qty
7	D10733590.9	PISTON (MITSUBISHI PART NO. 31N17-03400)	3
8	D10733600.9	PIN,PISTON (MITSUBISHI PART NO. 31A17-10602)	3
9	D10733610.9	RING SET PISTON (MITSUBISHI PART NO.31A17-00010)	3
10	D10733620.9	RING SET PISTON (MITSUBISHI PART NO. 31A17-00020)	3
11	D10733630.9	RING SET PISTON (MITSUBISHI PART NO. 31A17-00030)	3
12	D10733640.9	PISTON (MITSUBISHI PART NO. 31N17-03500)	3
13	D10733650.9	PISTON (MITSUBISHI PART NO. 31N17-03600)	3

TABLE-27
WATER PUMP




TABLE-27
WATER PUMP

Fig. No.	Part No.	Description	Qty
1	D10698320.9	WATER PUMP ASSEMBLY-SL (MITSUBISHI PART NO 31N4500020)	1
2	D10698330.9	GASKET WATER PUMP (MITSUBISHI PART NO 31N4500200)	1
3	D10734100.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08045)	3
4	D10734110.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08060)	1
5	D10734120.9	WASHER,PLAIN (MITSUBISHI PART NO. F2500-08000)	4

TABLE-28
FUEL SYSTEM




TABLE-28
FUEL SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10734260.9	NOZZLE ASSY,INJECTION (MITSUBISHI PART NO. MM435-94101)	3
2	D10698160.9	GASKET HOLDER (MITSUBISHI PART NO 30N6100600)	3
3	D10698150.9	GASKET FUEL RETURN PIPE (MITSUBISHI PART NO 30N6100800)	3
4	D10734290.9	NUT (MITSUBISHI PART NO. 31N61-00100)	3
5	D10734300.9	PIPE,INJECTION NO.1 (MITSUBISHI PART NO. 31N61-02200)	1
6	D10734310.9	PIPE,INJECTION NO.2 (MITSUBISHI PART NO. 31N61-02300)	1
7	D10734320.9	PIPE,INJECTION NO.3 (MITSUBISHI PART NO. 31N61-02400)	1
8	D10734350.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1825-06025)	2
9	D10734360.9	PIPE,FUEL LEAK OFF (MITSUBISHI PART NO. 31N61-01600)	1
10	D10698210.9	HOSE ASSEMBLY AIR VENT (MITSUBISHI PART NO 31N6101200)	1
11	D10698220.9	HOSE FUEL (MITSUBISHI PART NO 31N6101700)	1
12	D10698230.9	HOSE FUEL (MITSUBISHI PART NO 31N6101400)	1
13	D10734400.9	CLIP,HOSE (MITSUBISHI PART NO. 30N61-01300)	4
14	D10734410.9	HOSE,RUBBER (MITSUBISHI PART NO. 31N61-01300)	1
15	D10734420.9	JOINT,THREE WAY (MITSUBISHI PART NO. 30N61-01200)	1

TABLE-29
WATER PUMP PULLEY




TABLE-29
WATER PUMP PULLEY

Fig. No.	Part No.	Description	Qty
1	D10734130.9	PULLEY,WATER PUMP (MITSUBISHI PART NO. 31N45-00300)	1

TABLE-30
COOLING SYSTEM




TABLE-30
COOLING SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10734140.9	CASE ASSY,THERMOSTAT (MITSUBISHI PART NO. 31N46-00050)	1
2	D10734150.9	THERMOSTAT ASSY (MITSUBISHI PART NO. K6516441)	1
3	D10734160.9	GASKET,THERMOSTAT (MITSUBISHI PART NO. 31A46-11200)	1
4	D10734170.9	BOLT,FLANGE (MITSUBISHI PART NO. F1010-08025)	2
5	D10734180.9	COVER,THERMOSTAT (MITSUBISHI PART NO. 31N46-00600)	1
6	D10734190.9	GASKET,THERMO CASE (MITSUBISHI PART NO. 31N46-00700)	1
7	D10734200.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08065)	2
8	D10698280.9	HOSE ASSEMBLY BY-PASS (MITSUBISHI PART NO 31N4600060)	1
9	D10734220.9	HOSE,BY-PASS (MITSUBISHI PART NO. 31N46-00800)	1
10	D10734230.9	CLAMP,HOSE(MITSUBISHI PART NO. F4300-02000)	2
11	D10734240.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08070)	1

TABLE-31
FAN SPACER




TABLE-31
FAN SPACER

Fig. No.	Part No.	Description	Qty
1	D10734250.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-06025)	4

TABLE-32
FUEL SYSTEM (NOZZLE ASSY)




TABLE-32
FUEL SYSTEM (NOZZLE ASSY)

Fig. No.	Part No.	Description	Qty
1	D10734260.9	NOZZLE ASSY,INJECTION (MITSUBISHI PART NO. MM435-94101)	3
2	D10698170.9	NOZZLE AND HOLDER ASSEMBLY (MITSUBISHI PART NO MM43594101)	3
3	D10734440.9	HOLDER ASSY (MITSUBISHI PART NO. MM514045)	3
4	D10734450.9	SHIM (MITSUBISHI PART NO. MD603490)	AR
5	D10734460.9	SHIM (MITSUBISHI PART NO. MD603491)	AR
6	D10734470.9	SHIM (MITSUBISHI PART NO. MD603492)	AR
7	D10734480.9	SHIM (MITSUBISHI PART NO. MD603493)	AR
8	D10734490.9	SHIM (MITSUBISHI PART NO. MD603494)	AR
9	D10734500.9	SHIM (MITSUBISHI PART NO. MD603495)	AR
10	D10734510.9	SHIM (MITSUBISHI PART NO. MD603496)	AR
11	D10734520.9	SHIM (MITSUBISHI PART NO. MD603497)	AR
12	D10734530.9	SHIM (MITSUBISHI PART NO. MD603498)	AR
13	D10734540.9	SHIM (MITSUBISHI PART NO. MD603499)	AR
14	D10734550.9	PIN,PRESSURE (MITSUBISHI PART NO. MM501838)	3
15	D10734560.9	PIECE,DISTANCE (MITSUBISHI PART NO. MM501841)	3
16	D10734570.9	SPRING,PRESSURE (MITSUBISHI PART NO. MM514047)	3
17	D10734580.9	BODY SUB ASSY (MITSUBISHI PART NO.MM514048)	3
18	D10734590.9	NUT,NOZZLE RETAINING (MITSUBISHI PART NO. MM514380)	3

TABLE-33
GOVERNOR




TABLE-33
GOVERNOR

Fig. No.	Part No.	Description	Qty
1	D10734600.9	LEVER ASSY,TENSION (MITSUBISHI PART NO. 31N63-01030)	AR
2	D10734610.9	CASE ASSY,GOVERNOR (MITSUBISHI PART NO. 31N63-03040)	1
12	D10734710.9	SPRING SET,TORQUE (MITSUBISHI PART NO. 31A64-01080)	1
13	D10734720.9	NUT,TORQUE SET (MITSUBISHI PART NO. 30L63-00600)	1
14	D10734730.9	CASE,TORQUE SPRING (MITSUBISHI PART NO. 31A64-00200)	1
15	D10734740.9	SPRING,TORQUE (MITSUBISHI PART NO. 31A64-01800)	2
16	D10734750.9	NUT (MITSUBISHI PART NO. MD000961)	1
17	D10734760.9	SCREW,ADJUSTING ROCK (MITSUBISHI PART NO. MD065628)	1
18	D10734770.9	STOPPER,SPRING (MITSUBISHI PART NO. MM434541)	1
19	D10698350.9	SPRING TIE ROD (MITSUBISHI PART NO 31N6302700)	1
26	D10734850.9	LEVER,GOVERNOR (MITSUBISHI PART NO. 31N63-04400)	1
27	D10734860.9	NUT (MITSUBISHI PART NO. 49302-90070)	1
32	D10698360.9	SPRING GOVERNOR (MITSUBISHI PART NO 31N6304200)	1
33	D10734910.9	GASKET,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03100)	1
34	D10734920.9	SHAFT,SLIDING SLEEVE (MITSUBISHI PART NO. 31A63-10305)	1
35	D10734930.9	SLEEVE,SLIDING (MITSUBISHI PART NO. 31A63-20201)	1
36	D10734940.9	WEIGHT ASSY,GOVERNOR (MITSUBISHI PART NO. 31A63-11061)	1
37	D10734950.9	COVER,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04700)	1
38	D10734960.9	COVER,TORQUE SET (MITSUBISHI PART NO. 30N63-04400)	1
39	D10733310.9	BOLT (MITSUBISHI PART NO. 31N11-00900)	8
40	D10734970.9	BOLT,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03500)	1
41	D10734980.9	COVER,TIE ROD (MITSUBISHI PART NO. 31N63-03600)	1
42	D10734990.9	GASKET,TIE ROD COVER (MITSUBISHI PART NO. 30A63-00101)	1
43	D10735000.9	BOLT,W/B/WWASHER (MITSUBISHI PART NO. F1805-06014)	4

TABLE-34
INJECTION PUMP




TABLE-34
INJECTION PUMP

Fig. No.	Part No.	Description	Qty
1	D10698250.9	PUMP ASSEMBLY FUEL INJECTOR (MITSUBISHI PART NO 31B6514090)	1
2	D10735020.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01100)	AR
3	D10735030.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01200)	AR
4	D10735040.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01300)	AR
5	D10735050.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01400)	AR
6	D10735060.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01500)	AR
7	D10735070.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01600)	AR
8	D10735080.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01700)	AR
9	D10735090.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01800)	AR
10	D10735100.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01900)	AR
11	D10735110.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03100)	AR
12	D10735120.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03200)	AR
13	D10735130.9	SHIM,ADJUSTING (MITSUBISHI PART NO.31N65-03300)	AR
14	D10735140.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03400)	AR
15	D10735150.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03500)	AR
16	D10733210.9	BOLT (MITSUBISHI PART NO. 31N07-02300)	5
17	D10735160.9	WASHER,SEAL (MITSUBISHI PART NO. MK661-12000)	2
18	D10735170.9	COLLAR,UNION (MITSUBISHI PART NO. 31B65-00300)	1

TABLE-35
FUEL INJECTION PUMP DRIVE




TABLE-35
FUEL INJECTION PUMP DRIVE

Fig. No.	Part No.	Description	Qty
1	D10735480.9	SHAFT,FUEL INJECTION PUMP (MITSUBISHI PART NO. 31N65-00700)	1
2	D10735490.9	BEARING,RADIAL BALL (MITSUBISHI PART NO. MD703856)	1
3	D10735500.9	WASHER (MITSUBISHI PART NO. MD000425)	1
4	D10735510.9	KEY,SUNK (MITSUBISHI PART NO. 30N07-02800)	1
5	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	2

TABLE-36
GLOW PLUG & WIRE




TABLE-37
ENGINE CONTROL (STOP)




TABLE-37
ENGINE CONTROL (STOP)

Fig. No.	Part No.	Description	Qty
1	D10698240.9	SOLENOID AND NUT SET (MITSUBISHI PART NO 30A8700061)	1
2	D10735550.9	SOLENOID ASSY (MITSUBISHI PART NO. MM409-67002)	1
3	D10735560.9	NUT (MITSUBISHI PART NO. MM409-67101)	1

TABLE-38
INJECTION PUMP (ASSY)




TABLE-38
INJECTION PUMP (ASSY)

Fig. No.	Part No.	Description	Qty
1	D10698250.9	PUMP ASSEMBLY FUEL INJECTOR (MITSUBISHI PART NO 31B6514090)	1
2	D10735180.9	HOUSING SUB ASSY(MITSUBISHI PART NO. 47X01-06100)	1
3	D10735190.9	ELEMENT SUB ASSY (MITSUBISHI PART NO. 47X01-05400)	3
4	D10735200.9	VALVE SUB ASSY (MITSUBISHI PART NO. 47X01-07700)	3
5	D10735210.9	HOLDER,DELIVERY (MITSUBISHI PART NO. 47X01-13200)	3
6	D10735220.9	SPRING,DELIVERY (MITSUBISHI PART NO. 47X01-13300)	3
7	D10735230.9	O RING(MITSUBISHI PART NO. 47X01-22700)	3
8	D10735240.9	SLEEVE,CONTROL (MITSUBISHI PART NO. MM500229)	3
9	D10735250.9	TAPPET SUB ASSY,INJECTION (MITSUBISHI PART NO. MM500230)	3
10	D10735260.9	PIN,TAPPET GUIDE (MITSUBISHI PART NO. MM500231)	3
11	D10735270.9	SHIM (MITSUBISHI PART NO. MM500309)	AR
12	D10735280.9	SHIM (MITSUBISHI PART NO. MM500314)	AR
13	D10735290.9	SHIM (MITSUBISHI PART NO. MM500310)	AR
14	D10735300.9	SHIM (MITSUBISHI PART NO. MM500315)	AR
15	D10735310.9	SHIM (MITSUBISHI PART NO. MM500311)	AR
16	D10735320.9	SHIM (MITSUBISHI PART NO. MM501246)	AR
17	D10735330.9	SHIM (MITSUBISHI PART NO. MM500312)	AR
18	D10735340.9	SEAT,SPRING (MITSUBISHI PART NO. MM500316)	3
19	D10735350.9	SPRING,PLUNGER (MITSUBISHI PART NO. MM500360)	3
20	D10735360.9	WASHER,COPPER PLATE (MITSUBISHI PART NO. MM500578)	1
21	D10735370.9	SEAT,SPRING (MITSUBISHI PART NO. MM501098)	3
22	D10735380.9	SCREW,AIR BLEEDER (MITSUBISHI PART NO. MM501152)	1
23	D10735390.9	PLATE (MITSUBISHI PART NO. MM501162)	1
24	D10735400.9	SHIM (MITSUBISHI PART NO. MM501364)	AR
25	D10735410.9	RACK ASSY,CONTROL (MITSUBISHI PART NO. MM501311)	1
26	D10735420.9	SCREW,HOLLOW (MITSUBISHI PART NO. MM501320)	1
27	D10735430.9	SHIM (MITSUBISHI PART NO. MM500299)	AR
28	D10735440.9	SHIM (MITSUBISHI PART NO. MM501365)	AR
29	D10735450.9	GASKET,DELIVERY (MITSUBISHI PART NO. MM501856)	3
30	D10735460.9	PLATE,ADJUSTING (MITSUBISHI PART NO. MM514109)	2
31	D10735470.9	BOLT,WASHER HEAD (MITSUBISHI PART NO. MM514195)	2
32	D10698410.9	PUMP ASSEMBLY FUEL (MITSUBISHI PART NO 30N6020301)	1

TABLE-39
ACCESSORY



TABLE-39
ACCESSORY

Fig. No.	Part No.	Description	Qty
1	D10734200.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08065)	1

TABLE-40
INSTRUMENT





TABLE-40
INSTRUMENT

Fig. No.	Part No.	Description	Qty
1	D10698200.9	SWITCH ASSEMBLY THERMOMETER (MITSUBISHI PART NO 30N4600500)	1
2	D10735580.9	PLUG,DRAIN (MITSUBISHI PART NO. MM316248)	1
3	D10698390.9	WASHER SEALING (MITSUBISHI PART NO 0594601601)	2
4	D10698190.9	SWITCH OIL PRESS (MITSUBISHI PART NO 31N9000200)	1
5	D10698300.9	SENSOR TEMPERATURE (MITSUBISHI PART NO 30N9600950)	1

TABLE-41
OVERHAUL GASKET KIT




TABLE-41
OVERHAUL GASKET KIT

Fig. No.	Part No.	Description	Qty
1	D10698400.9	GASKET KIT (MITSUBISHI PART NO 31N9400050)	1
2	D10732620.9	GASKET CYLINDER HEAD (MITSUBISHI PART NO.31B01-23200)	1
3	D10732730.9	SEAL, VALVE STEM (MITSUBISHI PART NO. MD115472)	6
4	D10698140.9	GASKET ROCKER COVER (MITSUBISHI PART NO 31B0413201)	1
5	D10733160.9	SEAL, SIDE (MITSUBISHI PART NO.31A07-12200)	4
6	D10735630.9	GASKET, OIL SEAL CASE (MITSUBISHI PART NO. 31N07-01500)	1
7	D10733280.9	GASKET, FRONT PLATE (MITSUBISHI PART NO. 31N11-00600)	1
8	D10733300.9	GASKET, GEAR CASE (MITSUBISHI PART NO. 31A11-11101)	1
9	D10733340.9	GASKET, HOUSING (MITSUBISHI PART NO.31A11-05201)	1
10	D10698290.9	GASKET OIL PUMP (MITSUBISHI PART NO 30N1101900)	2
11	D10735650.9	GASKET, INLET COVER (MITSUBISHI PART NO. 31B30-00800)	1
12	D10733890.9	GASKET, EXHAUST MANIFOLD (MITSUBISHI PART NO. 31B32-01200)	1
13	D10735660.9	PACKING, OIL PUMP (MITSUBISHI PART NO. 31A35-02300)	1
14	D10734000.9	GASKET (MITSUBISHI PART NO. 34340-00700)	1
15	D10733980.9	GASKET (MITSUBISHI PART NO. MF660036)	1
16	D10698330.9	GASKET WATER PUMP (MITSUBISHI PART NO 31N4500200)	1
17	D10734190.9	GASKET, THERMO CASE (MITSUBISHI PART NO. 31N46-00700)	1
18	D10734160.9	GASKET, THERMOSTAT (MITSUBISHI PART NO. 31A46-11200)	1
19	D10698160.9	GASKET HOLDER (MITSUBISHI PART NO 30N6100600)	3
20	D10698150.9	GASKET FUEL RETURN PIPE (MITSUBISHI PART NO 30N6100800)	3
21	D10734910.9	GASKET, GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03100)	1
22	D10734990.9	GASKET, TIE ROD COVER (MITSUBISHI PART NO. 30A63-00101)	1
23	D10698270.9	GASKET (MITSUBISHI PART NO F420214000)	2
24	D10698390.9	WASHER SEALING (MITSUBISHI PART NO 0594601601)	3

TABLE-42
COOLING SYSTEM SUBASSEMBLY




TABLE-42
COOLING SYSTEM SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10557900.9	SPACER FAN WATER COOLING	1
2	D10558670.9	RADIATOR AND SHROUD ASSEMBLY	1
3	D10560000.9	PIPE AND CLIP ASSEMBLY RECOVERY BOTTLE OVERFLOW	1
4	D10555800.9	PLATE BAFFLE RADIATOR FRAME	1
5	D10521940.9	FAN ASSEMBLY WATER COOLING	1
6	D86500030.9	WASHER M8 SPRING LOCK	11
7	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	3
8	D85500050.9	WASHER M8 FLAT	11
9	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
10	D81500210.9	BOLT M10X1.50X35-6.6P HEX HEAD	4
11	D86500050.9	WASHER M10 SPRING LOCK	4
11A	D10600490.9	FRAME ASSEMBLY RADIATOR	1
12	D83500060.9	NUT M8X1.25-6 HEX	14
13	D83500220.9	NUT M6X1.00-5 HEX	2
14	D10547430.9	MESH ASSEMBLY RADIATOR FRONT	1
15	D10587760.9	FRAME ASSEMBLY RADIATOR SIDE LH	1
16	D83500070.9	NUT M6X1.00-6 HEX	4
17	D10587750.9	FRAME ASSEMBLY RADIATOR SIDE RH	1
18	D10547480.9	HOSE RADIATOR TOP	1
19	D10547490.9	HOSE RADIATOR BOTTOM	1
20	D10186570.9	BOTTLE RADIATOR ASSEMBLY RECOVERY (1.5 LITRE)	1
20-1	D10801990.9	BOTTLE RADIATOR ASSEMBLY RECOVERY	1
21	D82500050.9	SCREW M6X1.00X12-6.8 HEX HEAD	2
22	D85500040.9	WASHER M6 FLAT	6
23	D10017540.9	CLAMP RADIATOR HOSE UPPER	4
24	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	4
25	D10559580.9	FOAM SEALING RADIATOR BOTTOM	1
26	D86500040.9	WASHER M6 SPRING LOCK	4
27	D81503520.9	BOLT M6X1.0X50-10.9 HEX HEAD	4
28	D10212530.9	BEADING CONSOLE FUEL TANK	1

TABLE-43
AIR CLEANER SUBASSEMBLY




TABLE-43**AIR CLEANER SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10517880.9	CLEANER ASSEMBLY ENGINE AIR	1
2	D10522000.9	BRACKET ASSEMBLY AIR CLEANER	1
3	D10521960.9	BRACKET ASSEMBLY AIR CLEANER HOLDING REAR	1
3-1	D10521960AD.9	BRACKET ASSEMBLY AIR CLEANER HOLDING REAR	1
4	D83500070.9	NUT M6X1.00-6 HEX	2
5	D10521990.9	RUBBER STRAP ASSEMBLY AIR CLEANER HOLDING	1
6	D10522380.9	PIPE AIR CLEANER INTAKE	1
7	D10532900.9	INDICATOR RESTRICTION AIR CLEANER	1
8	D10521950.9	HOSE AIR CLEANER TO INTAKE MANIFOLD	1
9	D10017170.9	CLAMP ASSEMBLY 70MM DIAMETER	3
10	D86500030.9	WASHER M8 SPRING LOCK	6
11	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
12	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	2
13	D85500050.9	WASHER M8 FLAT	9
14	D83500060.9	NUT M8X1.25-6 HEX	2
15	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	1
16	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
17	D10517920.9	FILTER ASSEMBLY PRIMARY ENGINE AIR CLEANER	1

TABLE-44
EXHAUST SYSTEM SUBASSEMBLY




TABLE-44**EXHAUST SYSTEM SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10551000.9	MUFFLER ASSEMBLY HORIZONTAL(INSIDE)	1
2	D10551010.9	PIPE EXHAUST AND BRACKET ASSEMBLY	1
3	D10551080.9	GASKET MUFFLER OUTLET	1
4	D10551070.9	GASKET MUFFLER INLET	1
5	D83500060.9	NUT M8X1.25-6 HEX	4
6	D86500030.9	WASHER M8 SPRING LOCK	8
7	D81501580.9	BOLT M8X1.25X16 HEX HEAD FLANGED	2
8	D85500050.9	WASHER M8 FLAT	6
9	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	2
10	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2

TABLE-45
COOLER OIL SUBASSEMBLY (HST)




TABLE-45**COOLER OIL SUBASSEMBLY (HST)**

Fig. No.	Part No.	Description	Qty
1	D10600480.9	BRACKET SUPPORT OIL COOLER ASSEMBLY	1
2	D84500230.9	STUD B M6X1X33-8.8	2
3	D86500030.9	WASHER M8 SPRING LOCK	4
4	D85500050.9	WASHER M8 FLAT	4
5	D83500220.9	NUT M6X1.00-5 HEX	2
6	D86500040.9	WASHER M6 SPRING LOCK	1
7	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
8	D85500040.9	WASHER M6 FLAT	1
9	D81500360.9	BOLT M6X1.00X16-9.8 HEX HEAD	1
10	D10587670.9	COOLER OIL ASSEMBLY (HST)	1
10-1	D10713560.9	COOLER OIL ASSEMBLY	1

TABLE-46
TRANSMISSION ASSEMBLY DRESSED UP




TABLE-46
TRANSMISSION ASSEMBLY DRESSED UP

Fig. No.	Part No.	Description	Qty
1	D10609600.9	BRACKET MID PTO GEAR SHIFT SWITCH HOLDING ASSEMBLY	1
2	D10614830.9	BRACKET PTO SWITCH HOLDING	1
3	D10552830.9	BRACKET ASSEMBLY HIGH LOW MEDIUM AND PTO LEVER HOLDING	1
4	D10552770.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (HIGH LOW MEDIUM)	1
5	D10740510.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (2WD 4WD)	1
6	D10769000.9	FRAME ASSEMBLY SOLENOID MOUNTING	1
7	D10774510.9	BRACKET ASSEMBLY SOLENOID FRAME MOUNTING TRANSMISSION HOUSING	1
8	D10554230.9	LEVER ASSEMBLY BRAKE PEDAL REAR LH	1
8-1	D10604770.9	LEVER ASSEMBLY BRAKE PEDAL REAR LH	1
9	D10554200.9	LEVER ASSEMBLY BRAKE PEDAL REAR RH	1
9-1	D10604790.9	LEVER ASSEMBLY BRAKE PEDAL REAR RH	1
10	D10552400.9	BLOCK SWIVEL BRAKE PEDAL REAR	4
11	D10552410.9	LEVER BRAKE PEDAL REAR	2
12	D10556870.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (PTO)	1
12-1	D10617950.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (PTO)	1
13	D10602680.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (MID PTO)	1
14	D10182150.9	PLUG M16X1.5X16	1
15	D10498400.9	SWITCH ASSEMBLY STOP LAMP	1
16	D10013460.9	PIN 1/8"X0.75" COTTER	10
17	D87500330.9	PIN 8X40 SPRING DOWEL COMBINATION TYPE	2
18	D87500320.9	PIN 6.35X40 SPRING DOWEL COMBINATION TYPE	2
18-1	D87000160.9	PIN 1/4"X1.50" SPRING DOWEL COMBINATION TYPE	2
19	D87500510.9	PIN 6.0X35.0 SPRING DOWEL	1
19-1	D10683440.9	PIN 6.0X35 SPRING DOWEL COMBINATION TYPE	1
20	D93400450.9	PIN 10X45 CLEVIS	2
21	D10552680.9	PIN LEVER 2WD 4WD ASSEMBLY	1
22	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
23	D82500100.9	SCREW M8X1.25X40-6.6 HEX HEAD	1
24	D82500040.9	SCREW M8X1.25X20-8.8 HEX HEAD	7
25	D85500140.9	WASHER M10 FLAT	10
26	D10009600.9	WASHER 8.5X22 FLAT PHOSPHATED	10
27	D86500030.9	WASHER M8 SPRING LOCK	10
28	D10471030.9	FRONT AXLE ASSEMBLY WITH CYLINDER AND GUARD ASSEMBLY(4WD COMPACT)	1
29	D10564460.9	AXLE FRONT ASSEMBLY 4WD COMPACT	1

TABLE-47
HARDWARE BUCKLE UP HOUSING INTERMEDIATE AND FRONT SUBASSEMBLY




TABLE-47**HARDWARE BUCKLE UP HOUSING INTERMEDIATE AND FRONT SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D81503310.9	BOLT M10X1.50X35-10.9 HEX HEAD	6
1-1	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	6
2	D81501910.9	BOLT M12X1.75X30-10.9 HEX HEAD	2
3	D84500350.9	STUD M10X1.5X48-10.9	2
4	D83500090.9	NUT M10X1.50-8 HEX	2
5	D86500020.9	WASHER M12 SPRING LOCK	2
6	D86500090.9	WASHER M10 SPRING LOCK	8
7	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-48
DRIVE TRAIN INPUT FRONT HOUSING HST ASSEMBLY




TABLE-48
DRIVE TRAIN INPUT FRONT HOUSING HST ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10538690.9	BEARING BALL 6001 2RS	1
2	D10580490.9	SHAFT INPUT HYDROSTATIC TRANSMISSION	1
3	D10590330.9	COUPLING INPUT HYDROSTATIC TRANSMISSION	1
4	D10809900.9	DAMPER ASSEMBLY	1
5	D86500030.9	WASHER M8 SPRING LOCK	4
6	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
7	D10809890.9	SPRING DAMPER INPUT HST	1
8	D87500720.9	PIN 6X20 PLAIN DOWEL	3

TABLE-49
HOUSING FRONT HST ASSEMBLY




TABLE-49
HOUSING FRONT HST ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10599230.9	HOUSING FRONT COMPACT HST	1
2	D10559860.9	WASHER M8 FLAT COPPER (FUEL INJECTION PUMP)	1
3	D10238120.9	PLUG M30X1.5X12 WELCH	2
4	D10616070.9	PLUG M30X1.5 ALLEN	2
5	D93100330.9	PLUG M24X2.0-6G	1
6	D10614170.9	HOSE ASSEMBLY INLET HST	1
7	D10515960.9	CONNECTOR M18X1.50 AND M18X1.50 STUD END	1
8	D10174950.9	SEAL BANJO BOLT DISTRIBUTOR TO CYLINDER TUBE	5
9	D10614200.9	PLATE BLOCK FILTER MOUNTING HST	1
10	D10174960.9	BOLT BANJO M18X1.50	2
11	D81504240.9	BOLT M12X1.75X50-8.8 ALLEN	2
12	D10796180.9	FILTER AND ADAPTOR ASSEMBLY HST OIL INTAKE	1
13	D81503090.9	BOLT M8X1.25X16-8.8 HEX HEAD	1
14	D10616120.9	WASHER BONDED SEAL 27.05X34.93X2.34	1
15	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR
16	D10005120.9	WASHER M24 FLAT COPPER	1

TABLE-50
HST UNIT SUBASSEMBLY WITH HARDWARE





TABLE-50
HST UNIT SUBASSEMBLY WITH HARDWARE

Fig. No.	Part No.	Description	Qty
1	D10616640.9	HYDROSTATIC UNIT ASSEMBLY (NEUTRAL TYPE)	1
2	D81503150.9	BOLT M10X1.50X60-10.9 HEX HEAD	2
3	D81500160.9	BOLT M10X1.50X45-10.9 HEX HEAD	2
4	D84500330.9	STUD B M10X1.5X65-10.9	2
5	D86500090.9	WASHER M10 SPRING LOCK	6
6	D10616120.9	WASHER BONDED SEAL 27.05X34.93X2.34	1
7	D10614190.9	CONNECTOR M18X1.50 AND 3/4"- BSP STUD END	1
8	D83500090.9	NUT M10X1.50-8 HEX	2
9	D95000420.9	LOCTITE 262	AR
10	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-51
DRIVE TRAIN 4WD SUBASSEMBLY (HST)



SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH) 20





TABLE-51
DRIVE TRAIN 4WD SUBASSEMBLY (HST)

Fig. No.	Part No.	Description	Qty
1	D10599870.9	SHAFT OUTPUT DROP BOX (HST)	1
2	D90500370.9	CIRCLIP B47X2.0 H	2
3	D93601300.9	SEAL OIL 25X47X10	1
4	D10541470.9	BEARING BALL 6005	1
5	D10548300.9	SPRING COMPRESSION GEAR (4WD)	1
6	D10542300.9	LEVER 4WD ENGAGE	1
7	D10252790.9	PIN PTO SHIFTER FORK	1
8	D10152510.9	SEAL OIL 20.0X30.0X7.0	1
9	D10583080.9	SPACER 20X26X8.0 SHAFT DROP BOX	1
10	D90000480.9	CIRCLIP A25X2.0 H	1
11	D10616670.9	PLATE 4WD COMPACT HST	1
12	D81503090.9	BOLT M8X1.25X16-8.8 HEX HEAD	2
13	D86500030.9	WASHER M8 SPRING LOCK	2
14	D10599860.9	RETAINER 4WD SHAFT (HST)	1
15	D10602670.9	BEARING BALL 6005 2RS	1
16	D81502150.9	BOLT M10X1.50X25-10.9 HEX HEAD	2
16-1	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	2
17	D86500090.9	WASHER M10 SPRING LOCK	2
18	D10542260.9	GEAR OUTPUT 4WD Z-25	1
19	D10006740.9	BALL 5/16" SNAP LOCK	1
20	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-52
RETAINER AND GEAR PAIR INPUT SUB ASSEMBLY WITH HARDWARE (HST)




TABLE-52**RETAINER AND GEAR PAIR INPUT SUB ASSEMBLY WITH HARDWARE (HST)**

Fig. No.	Part No.	Description	Qty
1	D10580500.9	CASING INPUT PAIR HYDROSTATIC TRANSMISSION	1
2	D10580510.9	RETAINER INPUT PAIR HYDROSTATIC TRANSMISSION	1
3	D10580520.9	SHAFT DRIVING CONSTANT MESH Z-14	1
4	D10580530.9	GEAR DRIVEN CONSTANT MESH Z-23	1
5	D10580540.9	SHAFT DRIVEN CONSTANT MESH	1
6	D10587490.9	BEARING TAPER ROLLER 30204	1
7	D10587500.9	BEARING TAPER ROLLER TMB32004	2
8	D10539330.9	BEARING TAPPER ROLLER 32005	1
9	D85500580.9	WASHER 40X47X3.0 FLAT	1
10	D85500590.9	WASHER 36X42X3.0 FLAT	1
11	D90000010.9	CIRCLIP A25X1.2 N	1
12	D90500370.9	CIRCLIP B47X2.0 H	1
13	D10596520.9	SHIM 36X42 (THICKNESS 0.075 MM)	1
14	D10596530.9	SHIM 36X42 (THICKNESS 0.125 MM)	1
15	D10596540.9	SHIM 36X42 (THICKNESS 0.2285 MM)	1
16	D10596550.9	SHIM 36X42 (THICKNESS 0.4065 MM)	1
17	D10596560.9	SHIM 36X42 (THICKNESS 0.6 MM)	1
18	D10596570.9	SHIM 36X42 (THICKNESS 0.7875 MM)	1
19	D10596580.9	SHIM 40X47 (THICKNESS 0.075 MM)	1
20	D10596590.9	SHIM 40X47 (THICKNESS 0.125 MM)	1
21	D10596600.9	SHIM 40X47 (THICKNESS 0.2285 MM)	1
22	D10596610.9	SHIM 40X47 (THICKNESS 0.4065 MM)	1
23	D10596620.9	SHIM 40X47 (THICKNESS 0.6 MM)	1
24	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	5
24A	D86500030.9	WASHER M8 SPRING LOCK	5
25	D10580480.9	COUPLING OUTPUT HYDROSTATIC TRANSMISSION	1
26	D81503340.9	BOLT M10X1.50X90-10.9 HEX HEAD	1
27	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	4

TABLE-53
HOUSING ASSEMBLY INTERMEDIATE (HST)




TABLE-53
HOUSING ASSEMBLY INTERMEDIATE (HST)

Fig. No.	Part No.	Description	Qty
1	D10590310.9	HOUSING INTERMEDIATE COMPACT (HST)	1
2	D87500030.9	PIN 10X22 PLAIN DOWEL	7
3	D93100410.9	PLUG 1/4"-18 SOCKET HEX HEAD (STEEL)	4
4	D10614560.9	INDICATOR OIL LEVEL TRANSMISSION (HST)	1
5	D10005120.9	WASHER M24 FLAT COPPER	1

TABLE-54
CLUTCH WET PTO SUBASSEMBLY




TABLE-54**CLUTCH WET PTO SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10580880.9	CLUTCH ASSEMBLY WET PTO	1
2	D10580890.9	HUB WET PTO CLUTCH INPUT	1
3	D10580900.9	SHAFT WET PTO CLUTCH OUTPUT	1
4	D93601240.9	SEAL OIL PTFE 16.35X20.25X1.85	2
5	D93601250.9	SEAL OIL PTFE 24.35X28.25X1.85	2
6	D10580910.9	BEARING BALL 6202 C3	1
7	D82500730.9	SCREW M8X1.25X18 ALLEN	1
8	D85500900.9	WASHER 26X8X5 THRUST	1
9	D10541460.9	BEARING BALL 6304	1
10	D90500390.9	CIRCLIP B52X2.0 N	1
11	D10580920.9	RETAINER WET PTO CLUTCH	1
12	D93100060.9	PLUG 1/"8-27 SOCKET HEX HEAD (STEEL)	1
13	D93601280.9	SEAL O RING 1.0X6.0	1
14	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	3
15	D81503420.9	BOLT M10X1.50X70-10.9 HEX HEAD	1
16	D10602280.9	BEARING BALL 6007	1
17	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	1
18	D95000420.9	LOCTITE 262	AR

TABLE-55
PLATE INTERMEDIATE TRANSMISSION ASSEMBLY




TABLE-55**PLATE INTERMEDIATE TRANSMISSION ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10565720.9	PLATE INTERMEDIATE TRANSMISSION Z 24	1
2	D81502150.9	BOLT M10X1.50X25-10.9 HEX HEAD	4
3	D10001990.9	BEARING ASSEMBLY TRANSMISSION MAIN SHAFT REAR PILOT	1
4	D10565690.9	GEAR DRIVER 4WD Z 24	1
5	D10541490.9	BEARING ROLLER NJ 205	1
6	D10541500.9	BEARING ROLLER NJ 204	1
7	D90500390.9	CIRCLIP B52X2.0 N	1

TABLE-56
BRAKE LINKAGE SUB ASSEMBLY (HST)




TABLE-56
BRAKE LINKAGE SUB ASSEMBLY (HST)

Fig. No.	Part No.	Description	Qty
1	D81000470.9	BOLT 7/16"-14X1.50" HEX HEAD	1
2	D91000050.9	KEY 4X5 WOODRUFF	1
3	D81502010.9	BOLT M4X20-6.8 HEX HEAD	4
4	D10768840.9	SWITCH ASSEMBLY NC/NO TYPE	2
5	D10012250.9	SPRING BRAKE PEDAL RETURN	2
6	D10552230.9	COVER RUBBER RETURN STOPPER	2
7	D90000570.9	CIRCLIP A28X1.5 N	2
8	D10564110.9	KNOB ASSEMBLY INDEPENDENT PARKING BRAKE	1
9	D10604840.9	BRACKET ASSEMBLY INDEPENDENT PARKING BRAKE MOUNTING	1
10	D10292730.9	PIN 3/8" CLEVIS	3
11	D10258180.9	PIN 10X35 CLEVIS	4
12	D10604820.9	ROD TIE AND CLEVIS ASSEMBLY PARKING BRAKE	2
13	D83500290.9	NUT M12X1.75 HEX	4
14	D10293160.9	CLEVIS 3/8"	3
15	D83000010.9	NUT 3/8"-24 HEX	5
16	D10558920.9	GUIDE SUPPORT LEVER (IGUS)	1
17	D10610590.9	ROD TIE AND CLEVIS ASSEMBLY INDEPENDENT PARKING BRAKE	1
18	D83500070.9	NUT M6X1.00-6 HEX	2
19	D10604800.9	ROD TIE AND CLEVIS ASSEMBLY BRAKE PEDAL	2
20	D10605700.9	PEDAL ASSEMBLY BRAKE LH (HST)	1
21	D10605730.9	PEDAL ASSEMBLY BRAKE RH (HST)	1
22	D10552220.9	PAD RUBBER TOP PLATE	2
23	D10012260.9	WASHER BRAKE PEDAL CROSS SHAFT THRUST	4
24	D10471840.9	SPACER BRAKE ACTUATING SHAFT LH	1
25	D10604740.9	HUB AND LEVER ASSEMBLY INDEPENDENT PARKING BRAKE RH	1
26	D10604710.9	BRAKE PEDAL SHAFT ASSEMBLY INNER	1
27	D10604690.9	SHAFT ASSEMBLY BRAKE PEDAL OUTER	1
28	D81500340.9	BOLT M6X1.00X35-8.0 HEX HEAD	1
29	D86500040.9	WASHER M6 SPRING LOCK	1
30	D85500040.9	WASHER M6 FLAT	1
31	D83500090.9	NUT M10X1.50-8 HEX	2
32	D85500190.9	WASHER M4.0 FLAT	4
33	D10013460.9	PIN 1/8"X0.75" COTTER	4
34	D85500140.9	WASHER M10 FLAT	8

TABLE-57
GEAR ASSEMBLY 4WD IDLER




TABLE-57
GEAR ASSEMBLY 4WD IDLER

Fig. No.	Part No.	Description	Qty
1	D10542270.9	SHAFT IDLER 4WD	1
2	D10542250.9	GEAR IDLER 4WD Z-26	1
3	D10106190.9	BEARING NEEDLE ROLLER (25X33X23.8)	1
4	D90000480.9	CIRCLIP A25X2.0 H	1
5	D86500190.9	WASHER 45X25X1.5	1
6	D10673250.9	WASHER THRUST GEAR 4WD IDLER	1

TABLE-58
DRIVE TRAIN RANGE GEAR ASSEMBLY





TABLE-58
DRIVE TRAIN RANGE GEAR ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10534980.9	GEAR DRIVING HIGH RANGE Z-27	1
2	D10534990.9	GEAR DRIVING MEDIUM RANGE Z-23	1
3	D10580560.9	GEAR DRIVEN LOW RANGE Z-32	1
4	D10580550.9	SHAFT RANGE DRIVING Z-18	1
5	D90500140.9	CIRCLIP B55X2 N INTERNAL (IS3075 PART-II)	1
6	D10541450.9	BEARING BALL 6006	1
7	D10541770.9	SPACER RANGE DRIVING LOW GEAR	1
8	D10541760.9	SPACER RANGE DRIVING HIGH GEAR	1
9	D10547280.9	WASHER TAB LOCK	1
10	D83501010.9	NUT M22X1.5 HEX HEAD (THICKNESS 8.0MM)	1
11	D10535000.9	GEAR DRIVEN HIGH-MEDIUM RANGE Z-16/27	1
12	D90000080.9	CIRCLIP A30X1.5 N	1
13	D10541780.9	SPACER TAIL PINION SHAFT	1
14	D10052860.9	BEARING TAPPER ROLLER 30206	1
15	D10562420.9	SPACER GRADED PINION SHAFT (2.5 MM)	AR
16	D10562430.9	SPACER GRADED PINION SHAFT (2.6 MM)	AR
17	D10562440.9	SPACER GRADED PINION SHAFT (2.7 MM)	AR
18	D10562450.9	SPACER GRADED PINION SHAFT (2.8 MM)	AR
19	D10562460.9	SPACER GRADED PINION SHAFT (2.9 MM)	AR
20	D10562470.9	SPACER GRADED PINION SHAFT (3.0 MM)	AR
21	D10562480.9	SPACER GRADED PINION SHAFT (3.1 MM)	AR
22	D10562490.9	SPACER GRADED PINION SHAFT (3.2 MM)	AR
23	D90500320.9	CIRCLIP B62X3.0 H	1
24	D10541500.9	BEARING ROLLER NJ 204	1

TABLE-59
RANGE GEAR SHIFTING ASSEMBLY (COMPACT)





TABLE-59
RANGE GEAR SHIFTING ASSEMBLY (COMPACT)

Fig. No.	Part No.	Description	Qty
1	D87500700.9	PIN 6X30 SPRING DOWEL COMBINATION TYPE	1
2	D10535070.9	RAIL RANGE SHIFTING	1
3	D10535080.9	SHAFT AND LEVER ASSEMBLY RANGE SHIFTING	1
4	D10152510.9	SEAL OIL 20.0X30.0X7.0	1
5	D10535060.9	FORK RANGE SHIFTING	1
6	D10547290.9	SPRING RANGE GEAR SHIFT	1
7	D10006740.9	BALL 5/16" SNAP LOCK	1

TABLE-60
HOUSING REAR AXLE CENTRE SUBASSEMBLY (HST)




TABLE-60
HOUSING REAR AXLE CENTRE SUBASSEMBLY (HST)

Fig. No.	Part No.	Description	Qty
1	D10594190.9	HOUSING REAR COMPACT MID PTO	1
2	D10213110.9	PLUG DRAIN 3/4-14 NPTF (MAGNETIC)	1
3	D87500030.9	PIN 10X22 PLAIN DOWEL	8
4	D93400460.9	PIN 10X35 PLAIN DOWEL	2
5	D10541130.9	SHIM RETAINER DIFFERENTIAL (0.075 MM)	AR
6	D10541140.9	SHIM RETAINER DIFFERENTIAL (0.125 MM)	AR
7	D10541150.9	SHIM RETAINER DIFFERENTIAL (0.2285 MM)	AR
8	D10541160.9	SHIM RETAINER DIFFERENTIAL (0.4065 MM)	AR
9	D10541170.9	SHIM RETAINER DIFFERENTIAL (0.5335 MM)	AR
10	D10541180.9	SHIM RETAINER DIFFERENTIAL (0.7875 MM)	AR
11	D10537800.9	SHIM REAR AXLE SHAFT (0.075 MM)	AR
12	D10537810.9	SHIM REAR AXLE SHAFT (0.125 MM)	AR
13	D10537820.9	SHIM REAR AXLE SHAFT (0.2285 MM)	AR
14	D10537830.9	SHIM REAR AXLE SHAFT (0.4065 MM)	AR
15	D10537840.9	SHIM REAR AXLE SHAFT (0.5335 MM)	AR
16	D10537850.9	SHIM REAR AXLE SHAFT (0.7875 MM)	AR

TABLE-61
GEAR AND DIFFERENTIAL REAR AXLE SUBASSEMBLY




TABLE-61
GEAR AND DIFFERENTIAL REAR AXLE SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10541050.9	GEAR SET BEVEL PINION AND CROWN WHEEL REAR AXLE Z-41/11	1
1.1	D10541060.9	SHAFT BEVEL PINION REAR AXLE DIFFERENTIAL Z-11	1
1.2	D10541070.9	GEAR DRIVEN REAR AXLE DIFFERENTIAL Z-41	1
2	D10537130.9	CASING DIFFERENTIAL REAR AXLE	1
3	D82501060.9	SCREW M8X1.25X18-10.9 HEX HEAD	10
4	D85500440.9	WASHER 8.1X13X1.0 FLAT	10
5	D10536870.9	WASHER LOCK DIFFERENTIAL CROWN WHEEL GEAR	5
6	D10520880.9	BEVEL SIDE GEAR DIFFERENTIAL Z-13	2
7	D10536860.9	WASHER REAR AXLE DIFFERENTIAL THRUST	2
8	D10520890.9	PINION GEAR DIFFERENTIAL Z-9	2
9	D10536850.9	WASHER REAR AXLE DIFFERENTIAL PINION	2
10	D10536840.9	SPIDER REAR AXLE DIFFERENTIAL	1
11	D87500540.9	PIN 5X40 SPRING DOWEL	1

TABLE-62
DIFFERENTIAL LOCK SUBASSEMBLY




TABLE-62
DIFFERENTIAL LOCK SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10541080.9	SPRING REAR AXLE DIFFERENTIAL LOCK	1
2	D10541100.9	SHAFT AND LEVER ASSEMBLY REAR AXLE DIFFERENTIAL LOCK	1
3	D10541110.9	FORK DIFFERENTIAL LOCK	1
4	D10007720.9	SEAL O RING 2.00X14.00	2
5	D10546180.9	PIN REAR AXLE DIFFERENTIAL LOCK SHAFT	2
6	D10550590.9	SPACER 18X26X4.0 FLAT	1
7	D10541090.9	SLEEVE REAR AXLE DIFFERENTIAL LOCK	1

TABLE-63
RETAINER BEARING DIFFERENTIAL SUBASSEMBLY LH





TABLE-63**RETAINER BEARING DIFFERENTIAL SUBASSEMBLY LH**

Fig. No.	Part No.	Description	Qty
1	D10537770.9	RETAINER BEARING DIFFERENTIAL LH	1
2	D10584630.9	BALL BEARING 6211 CN	1
3	D86500030.9	WASHER M8 SPRING LOCK	6
4	D82500080.9	SCREW M8X1.25X25-8.8 HEX HEAD	6

TABLE-64
RETAINER BEARING DIFFERENTIAL SUBASSEMBLY RH




TABLE-64**RETAINER BEARING DIFFERENTIAL SUBASSEMBLY RH**

Fig. No.	Part No.	Description	Qty
1	D10537780.9	RETAINER BEARING DIFFERENTIAL RH	1
2	D10541480.9	BEARING BALL 6011	1
3	D86500030.9	WASHER M8 SPRING LOCK	6
4	D82500080.9	SCREW M8X1.25X25-8.8 HEX HEAD	6

TABLE-65
HOUSING REAR AXLE RH SUBASSEMBLY




TABLE-65
HOUSING REAR AXLE RH SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10527530.9	HOUSING REAR AXLE RH	1
1-1	D10777560.9	HOUSING REAR AXLE RH	1
2	D10507990.9	BRAKE ASSEMBLY REAR WHEEL 4.5" (WET TYPE)	1
3	D10537790.9	HOUSING BRAKE INNER RH	1
4	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	5
5	D86500090.9	WASHER M10 SPRING LOCK	16
6	D10618950.9	BEARING BALL 6209 CN	1
7	D90500060.9	CIRCLIP B85X2.5 N	1
8	D93601420.9	SEAL OIL 45X70X14.0	1
9	D10006570.9	PLUG DRAIN M14X1.5X10	1
10	D10513210.9	WASHER BONDED SEAL 14.7X22.0X1.5	1
11	D10580870.9	WASHER LOCK BULL PINION SHAFT BEARING	1
12	D82501060.9	SCREW M8X1.25X18-10.9 HEX HEAD	2
13	D90500470.9	CIRCLIP B70X1.5 N	1
14	D10527500.9	SHAFT AXLE REAR	1
15	D10579620.9	BOLT M16X1.5X48-10.9 REAR WHEEL	5
16	D10536470.9	SHAFT BULL PINION RH (Z-9)	1
17	D10533260.9	BEARING BALL 6306	2
18	D90000560.9	CIRCLIP A30.0X2.0 H	1
19	D10527440.9	SPACER BULL GEAR LOCKING	1
20	D10527450.9	GEAR DRIVEN FINAL DRIVE REDUCTION (Z-53)	1
21	D10527460.9	SPACER AXLE SHAFT INNER	1
22	D10536480.9	NUT CRIMPING M30X1.5	1
23	D10580860.9	PLUG AXLE HOUSING REAR	1
24	D81503420.9	BOLT M10X1.50X70-10.9 HEX HEAD	10
25	D81503890.9	BOLT M10X1.50X143-10.9 HEX HEAD (16 A/F)	1
26	D10181170.9	BOOT EXTERNAL REAR WHEEL BRAKE LINKAGE (DIA 50)	1
27	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR
28	D95000420.9	LOCTITE 262	AR

TABLE-66
HOUSING REAR AXLE LH SUBASSEMBLY




TABLE-66
HOUSING REAR AXLE LH SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10527510.9	HOUSING REAR AXLE LH	1
1-1	D10777550.9	HOUSING REAR AXLE LH	1
2	D10507990.9	BRAKE ASSEMBLY REAR WHEEL 4.5" (WET TYPE)	1
3	D10543900.9	HOUSING BRAKE INNER LH	1
4	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	5
5	D86500090.9	WASHER M10 SPRING LOCK	16
6	D10618950.9	BEARING BALL 6209 CN	1
7	D90500060.9	CIRCLIP B85X2.5 N	1
8	D93601420.9	SEAL OIL 45X70X14.0	1
9	D10006570.9	PLUG DRAIN M14X1.5X10	1
10	D10513210.9	WASHER BONDED SEAL 14.7X22.0X1.5	1
11	D10580870.9	WASHER LOCK BULL PINION SHAFT BEARING	1
12	D82501060.9	SCREW M8X1.25X18-10.9 HEX HEAD	2
13	D90500470.9	CIRCLIP B70X1.5 N	1
14	D81503890.9	BOLT M10X1.50X143-10.9 HEX HEAD (16 A/F)	1
15	D10527500.9	SHAFT AXLE REAR	1
16	D10579620.9	BOLT M16X1.5X48-10.9 REAR WHEEL	5
17	D81503420.9	BOLT M10X1.50X70-10.9 HEX HEAD	10
18	D10536460.9	SHAFT BULL PINION LH (Z-9)	1
19	D10533260.9	BEARING BALL 6306	2
20	D90000560.9	CIRCLIP A30.0X2.0 H	1
21	D10527440.9	SPACER BULL GEAR LOCKING	1
22	D10527450.9	GEAR DRIVEN FINAL DRIVE REDUCTION (Z-53)	1
23	D10527460.9	SPACER AXLE SHAFT INNER	1
24	D10536480.9	NUT CRIMPING M30X1.5	1
25	D10580860.9	PLUG AXLE HOUSING REAR	1
26	D10181170.9	BOOT EXTERNAL REAR WHEEL BRAKE LINKAGE (DIA 50)	1
27	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-67
PTO REAR SHIFTING ASSEMBLY (HST)




TABLE-67**PTO REAR SHIFTING ASSEMBLY (HST)**

Fig. No.	Part No.	Description	Qty
1	D10599710.9	LEVER REAR PTO COMPACT	1
2	D10599700.9	SHAFT REAR PTO LEVER COMPACT	1
3	D10683440.9	PIN 6.0X35 SPRING DOWEL COMBINATION TYPE	2
4	D10578880.9	FORK REAR PTO SHIFTER	1
5	D10578910.9	RAIL MID PTO SHIFTER	1
6	D10611760.9	SPRING MID PTO LEVER	1
7	D10007720.9	SEAL O RING 2.00X14.00	1
8	D10543890.9	SCREW PTO RAIL LOCK	1
9	D83500090.9	NUT M10X1.50-8 HEX	1
10	D10617950.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (PTO)	1

TABLE-68
PTO MID SHIFTING ASSEMBLY




TABLE-68**PTO MID SHIFTING ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10541370.9	LEVER PTO SHIFTING	1
2	D10007720.9	SEAL O RING 2.00X14.00	1
3	D10543890.9	SCREW PTO RAIL LOCK	1
4	D83500090.9	NUT M10X1.50-8 HEX	1
5	D10578910.9	RAIL MID PTO SHIFTER	1
6	D10578890.9	FORK MID PTO SHIFTER	1
7	D82501100.9	SCREW GRUB M10X1.5X10 - 45H	1
8	D10006740.9	BALL 5/16" SNAP LOCK	1
9	D10543910.9	SPRING PTO SHIFTING	1
10	D10611760.9	SPRING MID PTO LEVER	1
11	D10602680.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (MID PTO)	1
12	D10683440.9	PIN 6.0X35 SPRING DOWEL COMBINATION TYPE	1

TABLE-69
GEARS AND SHAFT PTO SUBASSEMBLY (HST)




TABLE-69**GEARS AND SHAFT PTO SUBASSEMBLY (HST)**

Fig. No.	Part No.	Description	Qty
1	D90500370.9	CIRCLIP B47X2.0 H	1
2	D10541470.9	BEARING BALL 6005	1
3	D10170170.9	BEARING BALL 6305	2
4	D10578830.9	SHAFT INPUT PTO (Z-11)	1
4A	D10553350.9	SPACER 35X25X3.0	1
5	D10578850.9	SHAFT REAR PTO OUTPUT	1
6	D10578870.9	SLEEVE REAR PTO SHIFTER	1
7	D10578840.9	GEAR MID PTO DRIVER Z-21	1
8	D10006740.9	BALL 5/16" SNAP LOCK	1
9	D10548300.9	SPRING COMPRESSION GEAR (4WD)	1
10	D90000550.9	CIRCLIP A35.0X2.5 H	1
11	D10578860.9	GEAR MID PTO Z-41	1
12	D90000240.9	CIRCLIP B72X2.5 N	1
13	D10001040.9	BEARING BALL PTO COUNTERSHAFT	1
14	D10538850.9	GEAR PTO DRIVEN (Z-51)	1
15	D90000240.9	CIRCLIP B72X2.5 N	1
16	D10001040.9	BEARING BALL PTO COUNTERSHAFT	1
17	D10590350.9	SPACER PTO OUTPUT SHAFT (4.7 MM)	2
18	D10590360.9	SPACER PTO OUTPUT SHAFT (4.8 MM)	2
19	D10590370.9	SPACER PTO OUTPUT SHAFT (4.9 MM)	2
20	D10590380.9	SPACER PTO OUTPUT SHAFT (5.0 MM)	2
21	D10590390.9	SPACER PTO OUTPUT SHAFT (5.1 MM)	2




TABLE-70
PTO MID DROP BOX ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10594380.9	HOUSING DROP BOX MID PTO	1
2	D10238120.9	PLUG M30X1.5X12 WELCH	1
3	D10598860.9	WASHER SEALING M30	1
4	D10006570.9	PLUG DRAIN M14X1.5X10	1
5	D10513210.9	WASHER BONDED SEAL 14.7X22.0X1.5	1
6	D93601230.9	SEAL O RING 3.53X104.37	1
7	D10579670.9	SPACER GEAR MID PTO	2
8	D10579680.9	SHAFT GEAR MID PTO	1
9	D10579660.9	CAGE NEEDLE ROLLER BEARING	1
10	D87500170.9	PIN 6.0X18.0 SPRING DOWEL	1
11	D10579650.9	GEAR TRANSMISSION MID PTO (Z-32)	1
12	D10541460.9	BEARING BALL 6304	1
13	D10170170.9	BEARING BALL 6305	1
16	D10579640.9	GEAR MID PTO DRIVEN Z-23	1
18	D81502150.9	BOLT M10X1.50X25-10.9 HEX HEAD	1
19	D10598870.9	WASHER 11X27X3.0 HST	1
20	D10779660.9	CAP MID PTO SHAFT REAR AXLE	1
22	D82500680.9	SCREW M8X1.25X30 ALLEN	4
23	D81501910.9	BOLT M12X1.75X30-10.9 HEX HEAD	4
24	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR
26	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	4
27	D81503270.9	BOLT M10X25X1.5-10.9 ALLEN	4
28	D86500090.9	WASHER M10 SPRING LOCK	4
29	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-71
HARDWARE BUCKLE UP TRANSMISSION AND REAR AXLE SUBASSEMBLY




TABLE-71**HARDWARE BUCKLE UP TRANSMISSION AND REAR AXLE SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	8
2	D81503420.9	BOLT M10X1.50X70-10.9 HEX HEAD	2
3	D86500090.9	WASHER M10 SPRING LOCK	10
4	D10668700.9	COUPLING PTO INPUT SHAFT	1
5	D10547270.9	COUPLING COUNTERSHAFT SPEED AND RANGE	1
6	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-72
FRONT AXLE ASSY.




Fig. No.	Part No.	Description	Qty
1	D10471030.9	FRONT AXLE ASSEMBLY WITH CYLINDER AND GUARD ASSEMBLY(4WD COMPACT)	1
2	D10564460.9	AXLE FRONT ASSEMBLY 4WD COMPACT	1

TABLE-74
HOUSING ASSEMBLY SWIVEL FRONT AXLE RH (4WD COMPACT)




TABLE-74**HOUSING ASSEMBLY SWIVEL FRONT AXLE RH (4WD COMPACT)**

Fig. No.	Part No.	Description	Qty
1	D10528120.9	HOUSING SWIVEL FRONT AXLE RH	1
2	D82501210.9	SCREW M12X1.75X12-8.8 HEX HEAD	1
3	D10161480.9	WASHER 12.0X22.0 SCREW RAIL	1
4	D10533270.9	BEARING TAPER ROLLER 30304	2
5	D10528100.9	SHAFT DRIVER BEVEL GEAR Z-9	1
6	D90000660.9	CIRCLIP A40X2.5 H	1
7	D10538670.9	BEARING BALL 6908	1
8	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	2
9	D10542380.9	SHIM 60X50 (0.075 MM)	1
10	D10542390.9	SHIM 60X50 (0.2285 MM)	1
11	D10542400.9	SHIM 60.X50 (0.4065 MM)	1
12	D10538680.9	BEARING BALL 6909	1
13	D10550290.9	SLEEVE OIL SEAL SWIVEL HOUSING	1
14	D10550300.9	SEAL OIL SWIVEL HOUSING 52X70X10	1
15	D10528130.9	HOUSING KNUCKLE FRONT AXLE	1
16	D10542310.9	SHIM 61.8X51 (0.2285 MM)	1
17	D10542320.9	SHIM 61.8X51 (0.4065 MM)	1
18	D10542330.9	SHIM 61.8X51 (0.5335 MM)	1
19	D10542340.9	SHIM 61.8X51 (0.7875 MM)	1
20	D10542350.9	SHIM 61.8X51 (1 MM)	1
21	D10542360.9	SHIM 61.8X51 (1.2 MM)	1
22	D10542370.9	SHIM 61.8X51 (1.5 MM)	1
23	D10170200.9	BEARING BALL 6206	1
24	D10528150.9	GEAR DRIVER BEVEL KNUCKLE Z-10	1
25	D10159950.9	DOWEL POSITIONING 10X25	3
26	D10528140.9	GEAR DRIVEN BEVEL KNUCKLE Z-16	1
27	D85500450.9	WASHER 36.0X20.0X3.0	1
28	D10542450.9	COVER KNUCKLE HOUSING	1
29	D10544670.9	SHIM COVER KNUCKLE (0.075 MM)	1
30	D10544680.9	SHIM COVER KNUCKLE (0.125 MM)	1
31	D10544690.9	SHIM COVER KNUCKLE (0.2285 MM)	1
32	D10544700.9	SHIM COVER KNUCKLE (0.4065 MM)	1
33	D93601100.9	SEAL O RING 2.62X62.00	1
34	D10005880.9	WASHER M18 FLAT COPPER	1
35	D10006500.9	PLUG M18X1.5X12-6.8 HEX HEAD	1
36	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
37	D81503330.9	BOLT M10X1.50X45-8.8 HEX HEAD WITH ROUNDED TOP	1
38	D83500170.9	NUT M10X1.50 NYLOCK HEX	1
39	D10547400.9	SEAL O RING 3.53X95.0	1
40	D95000410.9	LOCTITE 574	AR

TABLE-74
HOUSING ASSEMBLY SWIVEL FRONT AXLE RH (4WD COMPACT)




TABLE-74**HOUSING ASSEMBLY SWIVEL FRONT AXLE RH (4WD COMPACT)**

Fig. No.	Part No.	Description	Qty
41	D10528080.9	HOUSING WHEEL FRONT AXLE	1
42	D10528070.9	SHAFT FRONT AXLE WHEEL	1
43	D10541620.9	BOLT M12X1.5 FRONT WHEEL HUB	5
44	D10452820.9	SEAL OIL 35X60X14.5 PTO OUTPUT SHAFT	1
45	D10537800.9	SHIM REAR AXLE SHAFT (0.075 MM)	1
46	D10537810.9	SHIM REAR AXLE SHAFT (0.125 MM)	1
47	D10537820.9	SHIM REAR AXLE SHAFT (0.2285 MM)	1
48	D10537830.9	SHIM REAR AXLE SHAFT (0.4065 MM)	1
49	D10537840.9	SHIM REAR AXLE SHAFT (0.5335 MM)	1
50	D10537850.9	SHIM REAR AXLE SHAFT (0.7875 MM)	1
51	D10533260.9	BEARING BALL 6306	1
52	D10542420.9	WASHER SPLIT WHEEL END	2
53	D10528090.9	GEAR DRIVEN BEVEL WHEEL Z-37	1
54	D10170170.9	BEARING BALL 6305	1
55	D95000410.9	LOCTITE 574	2
56	D81502320.9	BOLT M10X1.50X30-10.9 HEX HEAD	8
56-1	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	8
57	D82500610.9	SCREW M12X1.75X30-10.9	4
58	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	1
59	D10159950.9	DOWEL POSITIONING 10X25	1

TABLE-75
HOUSING ASSEMBLY SWIVEL FRONT AXLE LH (4WD COMPACT)




TABLE-75**HOUSING ASSEMBLY SWIVEL FRONT AXLE LH (4WD COMPACT)**

Fig. No.	Part No.	Description	Qty
1	D10528110.9	HOUSING SWIVEL FRONT AXLE LH	1
2	D82501210.9	SCREW M12X1.75X12-8.8 HEX HEAD	1
3	D10161480.9	WASHER 12.0X22.0 SCREW RAIL	1
4	D10533270.9	BEARING TAPER ROLLER 30304	2
5	D10528100.9	SHAFT DRIVER BEVEL GEAR Z-9	1
6	D90000030.9	CIRCLIP A40X1.75 N	1
7	D10538670.9	BEARING BALL 6908	1
8	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	2
9	D10542380.9	SHIM 60X50 (0.075 MM)	1
10	D10542390.9	SHIM 60X50 (0.2285 MM)	1
11	D10542400.9	SHIM 60.X50 (0.4065 MM)	1
12	D10538680.9	BEARING BALL 6909	1
13	D10550290.9	SLEEVE OIL SEAL SWIVEL HOUSING	1
14	D10550300.9	SEAL OIL SWIVEL HOUSING 52X70X10	1
15	D10528130.9	HOUSING KNUCKLE FRONT AXLE	1
16	D10542310.9	SHIM 61.8X51 (0.2285 MM)	1
17	D10542320.9	SHIM 61.8X51 (0.4065 MM)	1
18	D10542330.9	SHIM 61.8X51 (0.5335 MM)	1
19	D10542340.9	SHIM 61.8X51 (0.7875 MM)	1
20	D10542350.9	SHIM 61.8X51 (1 MM)	1
21	D10542360.9	SHIM 61.8X51 (1.2 MM)	1
22	D10542370.9	SHIM 61.8X51 (1.5 MM)	1
23	D10170200.9	BEARING BALL 6206	1
24	D10528150.9	GEAR DRIVER BEVEL KNUCKLE Z-10	1
25	D10159950.9	DOWEL POSITIONING 10X25	3
26	D10528140.9	GEAR DRIVEN BEVEL KNUCKLE Z-16	1
27	D85500450.9	WASHER 36.0X20.0X3.0	1
28	D10542450.9	COVER KNUCKLE HOUSING	1
29	D10544670.9	SHIM COVER KNUCKLE (0.075 MM)	1
30	D10544680.9	SHIM COVER KNUCKLE (0.125 MM)	1
31	D10544690.9	SHIM COVER KNUCKLE (0.2285 MM)	1
32	D10544700.9	SHIM COVER KNUCKLE (0.4065 MM)	1
33	D93601100.9	SEAL O RING 2.62X62.00	1
34	D10005880.9	WASHER M18 FLAT COPPER	1
35	D10006500.9	PLUG M18X1.5X12-6.8 HEX HEAD	1
36	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
37	D81503330.9	BOLT M10X1.50X45-8.8 HEX HEAD WITH ROUNDED TOP	1
38	D83500170.9	NUT M10X1.50 NYLOCK HEX	1
39	D10547400.9	SEAL O RING 3.53X95.0	1
40	D95000410.9	LOCTITE 574	AR

TABLE-75
HOUSING ASSEMBLY SWIVEL FRONT AXLE LH (4WD COMPACT)




TABLE-75**HOUSING ASSEMBLY SWIVEL FRONT AXLE LH (4WD COMPACT)**

Fig. No.	Part No.	Description	Qty
41	D10528080.9	HOUSING WHEEL FRONT AXLE	1
42	D10528070.9	SHAFT FRONT AXLE WHEEL	1
43	D10541620.9	BOLT M12X1.5 FRONT WHEEL HUB	5
44	D10452820.9	SEAL OIL 35X60X14.5 PTO OUTPUT SHAFT	1
45	D10537800.9	SHIM REAR AXLE SHAFT (0.075 MM)	1
46	D10537810.9	SHIM REAR AXLE SHAFT (0.125 MM)	1
47	D10537820.9	SHIM REAR AXLE SHAFT (0.2285 MM)	1
48	D10537830.9	SHIM REAR AXLE SHAFT (0.4065 MM)	1
49	D10537840.9	SHIM REAR AXLE SHAFT (0.5335 MM)	1
50	D10537850.9	SHIM REAR AXLE SHAFT (0.7875 MM)	1
51	D10533260.9	BEARING BALL 6306	1
52	D10542420.9	WASHER SPLIT WHEEL END	2
53	D10528090.9	GEAR DRIVEN BEVEL WHEEL Z-37	1
54	D10170170.9	BEARING BALL 6305	1
55	D95000410.9	LOCTITE 574	2
56	D81502320.9	BOLT M10X1.50X30-10.9 HEX HEAD	8
56-1	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	8
57	D82500610.9	SCREW M12X1.75X30-10.9	4
58	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	1
59	D10159950.9	DOWEL POSITIONING 10X25	1

TABLE-75
PILLOW BLOCK SUBASSEMBLY FRONT




TABLE-75**PILLOW BLOCK SUBASSEMBLY FRONT**

Fig. No.	Part No.	Description	Qty
1	D10543050.9	PILLOW BLOCK ASSEMBLY FRONT	1
2	D10542430.9	BUSH PILLOW BLOCK FRONT	1
3	D10548830.9	DOWEL BUSH PILLOW BLOCK	2
4	D83500170.9	NUT M10X1.50 NYLOCK HEX	1
5	D81500210.9	BOLT M10X1.50X35-6.6P HEX HEAD	1
6	D10547380.9	SEAL O RING 2.62X55.0	1
7	D92500010.9	GREASE NIPPLE B M6	1
8	D10542460.9	WASHER 48.0X4.0 THRUST	1

TABLE-76
PILLOW BLOCK SUBASSEMBLY REAR




TABLE-76**PILLOW BLOCK SUBASSEMBLY REAR**

Fig. No.	Part No.	Description	Qty
1	D10543060.9	PILLOW BLOCK ASSEMBLY REAR	1
2	D10542440.9	BUSH PILLOW BLOCK REAR	1
3	D10547390.9	SEAL O RING 3.53X72.0	1
4	D10548830.9	DOWEL BUSH PILLOW BLOCK	2
5	D93601110.9	SEAL OIL 22X37X7.0	1