

Parts Catalog

FARMTRAC

TRACTOR FARMTRAC 22

Escorts Agri Machinery

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
1	ENGINE ASSEMBLY MITSUBISHI MVL3E-Z564ET-15.8kW@3000RPM	1	1-2
2	ACCESSORIES COMPACT ENGINE SUBASSEMBLY	1A	3-4
3	CYLINDER HEAD	2	5-6
4	LIFTING EYE	3	7-8
5	VALVE MECHANISM	4	9-10
6	ROCKER COVER	5	11-12
7	CAMSHAFT & TAPPET	6	13-14
8	CRANKCASE (ASSY)	7	15-16
9	CRANKCASE (OIL SEAL CASE)	8	17-18
10	DRAIN COCK & PIPE	9	19-20
11	MAIN BEARING	10	21-22
12	TIMING GEAR CASE	11	23-24
13	TIMING GEAR	12	25-26
14	OIL PAN	13	27-28
15	ENGINE SUPPORT	14	29-30
16	PISTON	15	31-32
17	CONNECTING ROD	16	33-34
18	CRANKSHAFT	17	35-36
19	CRANK PULLEY	18	37-38
20	INLET SYSTEM	19	39-40
21	EXHAUST SYSTEM	20	41-42
22	OIL PUMP	21	43-44
23	OIL STRAINER	22	45-46
24	OIL SYSTEM	23	47-48
25	OIL FILTER	24	49-50
26	OIL FILLER & GUAGE	25	51-52
27	BREATHER	26	53-54
28	WATER PUMP	27	55-56
29	WATER PUMP PULLEY	28	57-58
30	COOLING SYSTEM	29	59-60

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
31	FAN SPACER	30	61-62
32	FUEL SYSTEM	31	63-64
33	FUEL SYSTEM (NOZZLE ASSY)	32	65-66
34	GOVERNOR	33	67-70
35	INJECTION PUMP	34	71-72
36	FUEL INJECTION PUMP DRIVE	35	73-74
37	GLOW PLUG & WIRE	36	75-76
38	ENGINE CONTROL (STOP)	37	77-78
39	INJECTION PUMP (ASSY)	38	79-80
40	ACCESSORY	39	81-82
41	INSTRUMENT	40	83-84
42	OVERHAUL GASKET KIT	41	85-86
43	COOLING SYSTEM SUBASSEMBLY	42	87-88
44	AIR CLEANER SUBASSEMBLY	43	89-90
45	EXHAUST SYSTEM SUBASSEMBLY	44	91-92
46	CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (FROM T052427038BG)	45	93-94
47	TRANSMISSION ASSEMBLY DRESSED UP	46	95-96
48	HOUSING CLUTCH SUBASSEMBLY (9+3)	47	97-98
49	CLUTCH RELEASE MECHANISM ASSEMBLY	48	99-100
50	HOUSING SPEED ASSEMBLY	49	101-102
51	GEAR ASSEMBLY IDLER REVERSE SPEED	50	103-104
52	COVER TOP SPEED ASSEMBLY	51	105-106
53	DRIVER TRAIN INPUT ASSEMBLY	52	107-108
54	DRIVE TRAIN SPEED ASSEMBLY	53	109-110
55	SPEED SHIFTING SYSTEM ASSEMBLY	54	111-112
56	GEAR SPEED SELECTION ASSEMBLY	55	113-114
57	DRIVE TRAIN 4WD ASSEMBLY (9+3)	56	115-116
58	PLATE INTERMEDIATE TRANSMISSION ASSEMBLY	57	117-118
59	GEAR ASSEMBLY 4WD IDLER	58	119-120
60	GEAR DRIVE TRAIN RANGE ASSEMBLY (9+3)	59	121-122

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
61	RANGE GEAR SHIFTING ASSEMBLY (COMPACT)	60	123-124
62	HOUSING REAR AXLE CENTRE SUBASSEMBLY (9+3)	61	125-126
63	GEAR AND DIFFERENTIAL REAR AXLE SUBASSEMBLY	62	127-128
64	DIFFERENTIAL LOCK SUBASSEMBLY	63	129-130
65	RETAINER BEARING DIFFERENTIAL SUBASSEMBLY LH	64	131-132
66	RETAINER BEARING DIFFERENTIAL SUBASSEMBLY RH	65	133-134
67	HOUSING REAR AXLE RH SUBASSEMBLY	66	135-136
68	HOUSING REAR AXLE LH SUBASSEMBLY	67	137-138
69	DRIVE TRAIN PTO AND SHIFTING SUBASSEMBLY	68	139-140
70	HARDWARE BUCKLE UP TRANSMISSION AND REAR AXLE SUBASSEMBLY	69	141-142
71	FRONT AXLE ASSY.	70	143-144
72	HOUSING ASSEMBLY SWIVEL FRONT AXLE RH (4WD COMPACT)	71	145-148
73	HOUSING ASSEMBLY SWIVEL FRONT AXLE LH (4WD COMPACT)	72	149-152
74	SHAFT PROPELLER ASSEMBLY (4WD COMPACT)	73	153-154
75	PILLOW BLOCK SUBASSEMBLY FRONT	74	155-156
76	PILLOW BLOCK SUBASSEMBLY REAR	75	157-158
77	DIFFERENTIAL ASSEMBLY FRONT AXLE (4WD COMPACT)	76	159-160
78	RETAINER AND BEVEL PINION SHAFT ASSEMBLY FRONT AXLE (4WD COMPACT)	77	161-162
79	INDICATOR FRONT AXLE OIL LEVEL	78	163-164
80	AXLE FRONT WITH CYLINDER AND LINK ASSEMBLY	79	165-166
81	COVER ASSEMBLY GUARD STEERING CYLINDER	80	167-168
82	SUPPORT AND FRONT AXLE ASSEMBLY	81	169-170
83	BUMPER AND NUT ASSEMBLY FRONT	82	171-172
84	TOW HOOK ASSEMBLY FRONT	83	173-174
85	HARDWARE BUCKLE UP ADAPTOR PLATE AND BACKEND SUBASSEMBLY	84	175-176
86	FRAME FUEL TANK AND BRACKET HINGE ASSEMBLY	85	177-178
87	FUEL TANK SUBASSEMBLY	86	179-180
88	TUBING FUEL SYSTEM SUBASSEMBLY	87	181-182
89	WHEEL STEERING AND UNIT STEERING SUBASSEMBLY	88	183-184
90	LEVER CONTROL 2WD 4WD SUBASSEMBLY	89	185-186

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
91	LEVER RANGE HIGH LOW MEDIUM GEAR SHIFT SUBASSEMBLY	90	187-188
92	LEVER PTO GEAR SHIFT SUBASSEMBLY	91	189-190
93	LEVER SPEED GEAR SHIFT SUBASSEMBLY	92	191-192
94	LEVER POSITION CONTROL SUBASSEMBLY	93	193-194
95	LINKAGE ASSEMBLY DIFFERENTIAL LOCK CONTROL	95	195-196
96	LINKAGE CLUTCH SUBASSEMBLY	96	197-198
97	LINKAGE ASSEMBLY BRAKE CONTROL	97	199-200
98	LINKAGE ASSEMBLY THROTTLE CONTROL	98	201-202
99	LINKAGE THREE POINT SUBASSEMBLY	99	203-204
100	PUMP HYDRAULIC LIFT ASSEMBLY	100	205-206
101	TUBING HYDRAULIC SUCTION SUBASSEMBLY	101	207-208
102	TUBING POWER STEERING SUBASSEMBLY	102	209-212
103	TUBING AUXILLIARY VALVE SUBASSEMBLY	103	213-214
104	HYDRAULIC LIFT ASSEMBLY (COMPACT TRACTOR MODEL)	104	215-216
105	CYLINDER ASSY	105	217-218
106	INTERNAL LEVER ASSY	106	219-220
107	TOP LINK BRACKET ASSY	107	221-222
108	CONTROL LEVERS ASSY	108	223-224
109	SEAT DRIVER SUBASSEMBLY (EXPORT)	109	225-226
110	HITCH REAR SWINGING DRAWBAR SUBASSEMBLY	110	227-228
111	FENDER SUBASSEMBLY	111	229-230
112	BOARD RUNNING SUBASSEMBLY (EXPORT)	112	231-232
113	HOOD FRONT AND MIRROR SUBASSEMBLY	113	233-234
114	HOOD FRONT LOWER ASSEMBLY	114	235-236
115	HOOD FRONT LOWER SIDE LH ASSEMBLY	115	237-238
116	HOOD FRONT LOWER SIDE RH ASSEMBLY	116	239-240
117	HEADLAMP AND BRACKET MOUNTING ASSEMBLY RH	117	241-242
118	HOOD REAR SUBASSEMBLY	118	243-244
119	LATCH ASSEMBLY HOOD FRONT	119	245-246
120	COVER ASSEMBLY ENGINE SIDE RH	120	247-248

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
121	COVER ASSEMBLY ENGINE SIDE LH	121	249-250
122	MIRROR AND FRONT LAMP SUBASSEMBLY	122	251-252
123	GUIDE SUPPORT AND GAS SPRING FRONT HOOD SUBASSEMBLY	123	253-254
124	HARNESS SUBASSEMBLY	124	255-258
125	GUARD ASSEMBLY PROPELLER SHAFT	125	259-260
126	WHEEL AND TYRE ASSEMBLY FRONT 5x12 TR128 (M/S BKT)	126	261-262
127	WHEEL AND TYRE ASSEMBLY REAR 8x18 FARM 2000 (M/S BKT)	127	263-264
128	ROPS FOLDABLE SUBASSEMBLY COMPACT	128	265-266
129	CONSUMABLES SUBASSEMBLY	129	267-268
130	DECAL AND BADGE MODEL IDENTIFICATION ASSEMBLY 26HP EXPORT	130	269-270
131	HARDWARE BUCKLE UP CLUTCH HOUSING & SPEED HOUSING SUBASSEMBLY	131	271-272
132	HARDWARE BUCKLE UP ADAPTOR PLATE & BACKEND HOUSING SUBASSEMBLY	132	273-274
133	ACCESSORIES SUBASSEMBLY	133	275-276
134	BAFFLE PLATE SIDE ASSEMBLY	134	277-278

TABLE-1
ENGINE ASSEMBLY MITSUBISHI MVL3E-Z564ET-15.8kW@3000RPM




TABLE-1
ENGINE ASSEMBLY MITSUBISHI MVL3E-Z564ET-15.8kW@3000RPM

Fig. No.	Part No.	Description	Qty
1	D10776830.9	ENGINE ASSEMBLY MITSUBISHI MVL3E-Z564ET-15.8KW@3000RPM	1

TABLE-1A
ACCESSORIES COMPACT ENGINE SUBASSEMBLY




TABLE-1A
ACCESSORIES COMPACT ENGINE SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D87500570.9	PIN 9.5X20 PLAIN DOWEL	1
2	D10702010.9	ADAPTER ENGINE TRANSMISSION COUPLING	1
3	D10707310.9	LEVER ALTERNATOR ADJUSTING	1
4	D10702040.9	GASKET REAR PLATE ENGINE	1
5	D81500470.9	BOLT M10X1.50X115 HEX HEAD	1
5-1	D10042970.9	BOLT M8X1.25X100 (CLUTCH COVER)	1
6	D83500090.9	NUT M10X1.50-8 HEX	1
7	D86500050.9	WASHER M10 SPRING LOCK	2
8	D82500060.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
9	D83501000.9	NUT M8X1.25-10 HEX FLANGED (WHITE PASSIVATED)	4
10	D85500050.9	WASHER M8 FLAT	5
11	D10702020.9	FLYWHEEL ASSEMBLY	1
12	D10524970.9	RING GEAR FLYWHEEL	1
15	D10622550.9	DISC ASSEMBLY SINGLE CLUTCH 8.5 ORGANIC LINING	1
16	D10622560.9	COVER ASSEMBLY SINGLE CLUTCH 8.5 (ORGANIC)	1
17	D10538690.9	BEARING BALL 6001 2RS	1
18	D87500720.9	PIN 6X20 PLAIN DOWEL	3
19	D86500030.9	WASHER M8 SPRING LOCK	10
20	D87500030.9	PIN 10X22 PLAIN DOWEL	2
21	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	8
22	D10746060.9	BRACKET ASSEMBLY SOLENOID MOUNTING	1
23	D10746090.9	BRACKET ASSEMBLY SOLENOID MOUNTING ENGINE FRONT RH	1
24	D82500080.9	SCREW M8X1.25X25-8.8 HEX HEAD	2
25	D84500500.9	STUD B M10X40-10.9	4
26	D81503970.9	BOLT M10X1.25X25-8.8 FLANGE HEAD	8
27	D81503980.9	BOLT M10X1.25X30-8.8 FLANGE HEAD	4
28	D10750590.9	GASKET EXHAUST ELBOW	1
29	D10704040.9	ELBOW EXHAUST MANIFOLD	1
30	D10702030.9	FLYWHEEL (MACHINED)	1

TABLE-2
CYLINDER HEAD




TABLE-2
CYLINDER HEAD

Fig. No.	Part No.	Description	Qty
1	D10732550.9	HEAD ASSY,CYLINDER (MITSUBISHI PART NO. 31N01-01053)	1
2	D10732560.9	SEAT,INLET VALVE (MITSUBISHI PART NO.31A01-01201)	3
3	D10732570.9	SEAT EXHAUST VALVE (MITSUBISHI PART NO.31A01-01301)	3
4	D10732580.9	CAP SEALING (MITSUBISHI PART NO.31N01-00300)	1
5	D10732590.9	CAP SEALING (MITSUBISHI PART NO. F5014-25000)	5
6	D10732600.9	PLUG TAPERED (MITSUBISHI PART NO.30N01-01600)	1
7	D10732610.9	BOLT CYLINDER HEAD (MITSUBISHI PART NO.31A01-21100)	11
8	D10732620.9	GASKET CYLINDER HEAD (MITSUBISHI PART NO.31B01-23200)	1
9	D10732630.9	GUIDE EXHAUST VALVE (MITSUBISHI PART NO.31N01-00800)	3
10	D10732640.9	GUIDE INLET VALVE (MITSUBISHI PART NO.31N01-02300)	3
11	D10732650.9	JET COMBUSTION (MITSUBISHI PART NO.31A03-13601)	3

TABLE-3
LIFTING EYE




TABLE-3
LIFTING EYE

Fig. No.	Part No.	Description	Qty
1	D10732660.9	HANGER ENGINE (MITSUBISHI PART NO.31N01-01700)	2
2	D10732670.9	BOLT,W/WASHER(MITSUBISHI PART NO. F1805-10020)	2

TABLE-4
VALVE MECHANISM




TABLE-4
VALVE MECHANISM

Fig. No.	Part No.	Description	Qty
1	D10732680.9	VALVE INLET (MITSUBISHI PART NO.31N04-01300)	3
2	D10732690.9	VALVE EXHAUST (MITSUBISHI PART NO. 31N04-01400)	3
3	D10732700.9	SPRING VALVE (MITSUBISHI PART NO. 31N04-01500)	6
4	D10732710.9	RETAINER VALVE SPRING (MITSUBISHI PART NO. MM433-30601)	6
5	D10732720.9	LOCK SPRING RETAINER (MITSUBISHI PART NO. 30N04-00500)	12
6	D10732730.9	SEAL,VALVE STEM (MITSUBISHI PART NO. MD115472)	6
7	D10732740.9	CAP,VALVE STEM (MITSUBISHI PART NO. 31A04-00700)	6
8	D10732750.9	SHAFT ASSY,ROCKER(MITSUBISHI PART NO. 31N04-10080)	1
9	D10732760.9	BRACKET,ROCKER SHAFT (MITSUBISHI PART NO. 31N04-00800)	2
10	D10732770.9	SPRING,ROCKER SHAFT(MITSUBISHI PART NO. 31N04-00900)	2
11	D10732780.9	BRACKET,ROCKER SHAFT (MITSUBISHI PART NO. 31N04-01700)	1
12	D10732790.9	ARM,ROCKER(MITSUBISHI PART NO. 31N04-03500)	6
13	D10732800.9	SHAFT ASSY,ROCKER(MITSUBISHI PART NO. 31N04-10010)	1
14	D10732810.9	CAP,SEALING(MITSUBISHI PART NO. 31N04-00200)	2
15	D10732820.9	SCREW,ROCKER(MITSUBISHI PART NO. 32A04-02401)	6
16	D10732830.9	BOLT(MITSUBISHI PART NO. F1035-05010)	1
17	D10732840.9	NUT,(MITSUBISHI PART NO. F2325-08000)	6
18	D10732850.9	RING,SNAP(MITSUBISHI PART NO. F3200-01900)	2
19	D10732860.9	BOLT,ROCKER BRACKET(MITSUBISHI PART NO. 31N04-01100)	3

TABLE-5
ROCKER COVER




TABLE-5
ROCKER COVER

Fig. No.	Part No.	Description	Qty
1	D10732870.9	COVER ASSY,ROCKER (MITSUBISHI PART NO. 31N04-00071)	1
2	D10698140.9	GASKET ROCKER COVER (MITSUBISHI PART NO 31B0413201)	1
3	D10732890.9	BOLT,W/WASHER(MITSUBISHI PART NO. F1805-08040)	4
4	D10732900.9	CAP,OIL FILLER (MITSUBISHI PART NO. MD008784)	1

TABLE-6
CAMSHAFT & TAPPET




TABLE-6
CAMSHAFT & TAPPET

Fig. No.	Part No.	Description	Qty
1	D10732910.9	CAMSHAFT (MITSUBISHI PART NO. 31N05-00600)	1
2	D10732920.9	KEY,WOODRUFF (MITSUBISHI PART NO. F2872-05019)	1
3	D10732930.9	PLATE,THRUST (MITSUBISHI PART NO. 31N05-00300)	1
4	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	2
5	D10732950.9	TAPPET (MITSUBISHI PART NO. 31N05-00400)	6
6	D10732960.9	ROD,PUSH (MITSUBISHI PART NO. 31N05-00500)	6

TABLE-7
CRANKCASE (ASSY)




TABLE-7
CRANKCASE (ASSY)

Fig. No.	Part No.	Description	Qty
1	D10732970.9	BLOCK ASSY,CYLINDER (MITSUBISHI PART NO. 31N07-01090)	AR
2	D10732980.9	BOLT,BEARING CAP(MITSUBISHI PART NO.31A07-00801)	8
3	D10732990.9	BUSH,CAMSHAFT (MITSUBISHI PART NO.31A07-03100)	1
4	D10733000.9	CAP,SEALING (MITSUBISHI PART NO.31N07-01800)	2
5	D10733010.9	CAP,SEALING (MITSUBISHI PART NO.31N07-01900)	2
6	D10733020.9	GUIDE,OIL LEVEL GAUGE (MITSUBISHI PART NO.30N07-02100)	1
7	D10733030.9	CAP,SEALING (MITSUBISHI PART NO.F5014-12000)	1
8	D10733040.9	CAP,SEALING (MITSUBISHI PART NO.F5014-14000)	1
9	D10732600.9	PLUG TAPERED (MITSUBISHI PART NO.30N01-01600)	1
10	D10733050.9	PLUG,TAPERED MEC (MITSUBISHI PART NO.31N07-02100)	2
11	D10733060.9	BUSHING,KNOCK (MITSUBISHI PART NO.31N07-01100)	4
12	D10733070.9	BUSHING,KNOCK (MITSUBISHI PART NO.30N07-03200)	2
13	D10733080.9	BUSHING,KNOCK (MITSUBISHI PART NO.31N07-01300)	1
14	D10733090.9	PLUG,EXPANSION (MITSUBISHI PART NO.MF665511)	1
15	D10733100.9	PIN,DOWEL (MITSUBISHI PART NO.30N07-02700)	1
16	D10733110.9	PIN,DOWEL (MITSUBISHI PART NO.30N07-00600)	2
17	D10733120.9	SHAFT ASSY,IDLER (MITSUBISHI PART NO.31N07-00050)	1
18	D10733130.9	STEEL BALL,BEARING(MITSUBISHI PART NO.F8000-08000)	1
19	D10733140.9	PIN,DOWEL (MITSUBISHI PART NO.F2846-05000)	2
20	D10733150.9	PLUG,TAPERED (MITSUBISHI PART NO.31N07-02200)	1

TABLE-8
CRANKCASE (OIL SEAL CASE)




TABLE-8**CRANKCASE (OIL SEAL CASE)**

Fig. No.	Part No.	Description	Qty
1	D10733160.9	SEAL,SIDE (MITSUBISHI PART NO.31A07-12200)	4
2	D10733170.9	SHAFT,OIL FILTER (MITSUBISHI PART NO.30N07-02400)	1
3	D10733180.9	CASE,OIL SEAL (MITSUBISHI PART NO.31N07-01400)	1
4	D10733190.9	GASKET,OIL SEAL CASE (MITSUBISHI PART NO.31A07-11701)	1
5	D10698310.9	SEAL OIL (MITSUBISHI PART NO 31A0702300)	1
6	D10733210.9	BOLT (MITSUBISHI PART NO. 31N07-02300)	5

TABLE-9
DRAIN COCK & PIPE




TABLE-9
DRAIN COCK & PIPE

Fig. No.	Part No.	Description	Qty
1	D10733220.9	PLUG,TAPERED (MITSUBISHI PART NO. 30N07-02500)	1

TABLE-10
MAIN BEARING




TABLE-10
MAIN BEARING

Fig. No.	Part No.	Description	Qty
1	D10733230.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01010)	1
2	D10733240.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01020)	1
3	D10733250.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01030)	1
4	D10733260.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01040)	1

TABLE-11
TIMING GEAR CASE




TABLE-11
TIMING GEAR CASE

Fig. No.	Part No.	Description	Qty
1	D10733270.9	PLATE,FRONT (MITSUBISHI PART NO. 31A11-02100)	1
2	D10733280.9	GASKET,FRONT PLATE (MITSUBISHI PART NO. 31N11-00600)	1
3	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	5
4	D10733290.9	CASE,GEAR (MITSUBISHI PART NO. 31A11-10103)	1
5	D10733300.9	GASKET,GEAR CASE (MITSUBISHI PART NO. 31A11-11101)	1
6	D10733310.9	BOLT (MITSUBISHI PART NO. 31N11-00900)	8
7	D10698380.9	OIL SEAL (MITSUBISHI PART NO MD008762)	1
8	D10733330.9	HOUSING,GEAR PUMP (MITSUBISHI PART NO. 31A11-05101)	1
9	D10733340.9	GASKET,HOUSING (MITSUBISHI PART NO.31A11-05201)	1
10	D10733350.9	COVER,OIL PUMP SHAFT (MITSUBISHI PART NO.MM401205)	1
11	D10733360.9	COVER,OIL PUMP (MITSUBISHI PART NO. K7910451)	1
12	D10733370.9	GASKET,OIL PUMP COVER (MITSUBISHI PART NO. 30A11-00101)	2
13	D10733380.9	CAP,FILLER (MITSUBISHI PART NO. 31A42-01300)	1
14	D10733390.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08030)	1
15	D10733400.9	STUD (MITSUBISHI PART NO. MS401433)	1
16	D10733410.9	STUD (MITSUBISHI PART NO.MS401426)	1
17	D10733420.9	NUT (MITSUBISHI PART NO. F2300-08000)	4
18	D10733430.9	BOLT,W/WASHER (MITSUBISHI PART NO.F1825-08016)	4
19	D10733440.9	BOLT (MITSUBISHI PART NO. F1035-08070)	2
20	D10733450.9	WASHER,SPRING (MITSUBISHI PART NO. F2515-08000)	4

TABLE-12
TIMING GEAR




TABLE-12
TIMING GEAR

Fig. No.	Part No.	Description	Qty
1	D10733780.9	GEAR,CRANKSHAFT (MITSUBISHI PART NO. 31N23-10300)	1
2	D10733790.9	GEAR,CAMSHAFT (MITSUBISHI PART NO. 31N23-10400)	1
3	D10733800.9	GEAR,INJECTION PUMP (MITSUBISHI PART NO. 31N23-00700)	1
4	D10733810.9	GEAR ASSY,IDLER (MITSUBISHI PART NO. 31N23-10020)	1
5	D10733820.9	BUSHING,IDLER GEAR (MITSUBISHI PART NO. 31A23-00600)	1
6	D10733830.9	GEAR,OIL PUMP (MITSUBISHI PART NO. 31A23-01502)	1
7	D10733840.9	BEARING,BALL (MITSUBISHI PART NO.MD712517)	2

TABLE-13
OIL PAN




TABLE-13**OIL PAN**

Fig. No.	Part No.	Description	Qty
1	D10733460.9	PAN ASSY,OIL (MITSUBISHI PART NO. 31N13-02010)	1
2	D10733470.9	GASKET (MITSUBISHI PART NO. 31N13-00400)	2
3	D10733480.9	PLUG,DRAIN (MITSUBISHI PART NO. 31N13-00500)	2
4	D10733490.9	BOLT,FLANGE (MITSUBISHI PART NO. 30H13-00801)	12
5	D10733500.9	BOLT (MITSUBISHI PART NO.F1035-08040	1
6	D10733510.9	BOLT (MITSUBISHI PART NO. MM434762)	2

TABLE-14
ENGINE SUPPORT




TABLE-14
ENGINE SUPPORT

Fig. No.	Part No.	Description	Qty
1	D10733520.9	BOLT (MITSUBISHI PART NO. F1035-12025)	4

TABLE-15
PISTON




TABLE-15
PISTON

Fig. No.	Part No.	Description	Qty
7	D10733590.9	PISTON (MITSUBISHI PART NO. 31N17-03400)	3
8	D10733600.9	PIN,PISTON (MITSUBISHI PART NO. 31A17-10602)	3
9	D10733610.9	RING SET PISTON (MITSUBISHI PART NO.31A17-00010)	3
10	D10733620.9	RING SET PISTON (MITSUBISHI PART NO. 31A17-00020)	3
11	D10733630.9	RING SET PISTON (MITSUBISHI PART NO. 31A17-00030)	3
12	D10733640.9	PISTON (MITSUBISHI PART NO. 31N17-03500)	3
13	D10733650.9	PISTON (MITSUBISHI PART NO. 31N17-03600)	3

TABLE-16
CONNECTING ROD




TABLE-16
CONNECTING ROD

Fig. No.	Part No.	Description	Qty
1	D10733660.9	ROD ASSY,CONNECTING (MITSUBISHI PART NO. 31N19-00070)	3
2	D10733670.9	NUT,CONNECTING ROD (MITSUBISHI PART NO. MD006704)	6
3	D10733680.9	BOLT,CONNECTING ROD (MITSUBISHI PART NO. MD021105)	6
4	D10733690.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO.30A19-00040)	3
5	D10733700.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10010)	3
6	D10733710.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10020)	3
7	D10733720.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10030)	3

TABLE-17
CRANKSHAFT




TABLE-17
CRANKSHAFT

Fig. No.	Part No.	Description	Qty
1	D10733730.9	CRANKSHAFT (MITSUBISHI PART NO. 31B20-00204)	1
2	D10732920.9	KEY,WOODRUFF (MITSUBISHI PART NO. F2872-05019)	2
3	D10733740.9	WASHER,PLAIN (MITSUBISHI PART NO. F2500-18000)	1
4	D10733750.9	WASHER,SPRING (MITSUBISHI PART NO.F2515-18000)	1
5	D10733760.9	NUT (MITSUBISHI PART NO. F2300-18000)	1

TABLE-18
CRANK PULLEY




TABLE-18
CRANK PULLEY

Fig. No.	Part No.	Description	Qty
1	D10733770.9	PULLEY,CRANK (MITSUBISHI PART NO.31N20-00601)	1

TABLE-19
INLET SYSTEM




TABLE-19
INLET SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10733850.9	COVER ASSY,INLET (MITSUBISHI PART NO. 31N30-00031)	1
2	D10733860.9	GASKET,INLET COVER (MITSUBISHI PART NO.31N30-01300)	1
3	D10733870.9	BOLT,W/WASHER (MITSUBISHI PART NO.F1805-08035)	5

TABLE-20
EXHAUST SYSTEM




TABLE-20
EXHAUST SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10733880.9	MANIFOLD,EXHAUST (MITSUBISHI PART NO. 31N32-00100)	1
2	D10733890.9	GASKET,EXHAUST MANIFOLD (MITSUBISHI PART NO. 31B32-01200)	1
3	D10733900.9	STUD (MITSUBISHI PART NO. F1450-08025)	4
4	D10733910.9	BOLT (MITSUBISHI PART NO. F1035-08020)	4
5	D10733920.9	BOLT (MITSUBISHI PART NO. F1035-08055)	2

TABLE-21
OIL PUMP




TABLE-21
OIL PUMP

Fig. No.	Part No.	Description	Qty
1	D10733930.9	PUMP ASSY,OIL (MITSUBISHI PART NO.31N35-00010)	1
2	D10733940.9	PACKING,BODY (MITSUBISHI PART NO. 31N35-01900)	1
3	D10733950.9	BOLT (MITSUBISHI PART NO. F1035-08025)	3

TABLE-22
OIL STRAINER




TABLE-22
OIL STRAINER

Fig. No.	Part No.	Description	Qty
1	D10733960.9	STRAINER ASSY (MITSUBISHI PART NO.31N35-00050)	1
2	D10733970.9	NUT,JAM (MITSUBISHI PART NO.F2320-16000)	1
3	D10733980.9	GASKET (MITSUBISHI PART NO. MF660036)	1

TABLE-23
OIL SYSTEM




TABLE-24
OIL FILTER




TABLE-24
OIL FILTER

Fig. No.	Part No.	Description	Qty
1	D10671130.9	FILTER ASSEMBLY LUBE OIL	1

TABLE-25
OIL FILLER & GUAGE




TABLE-25
OIL FILLER & GUAGE

Fig. No.	Part No.	Description	Qty
1	D10734020.9	GAGE,OIL LEVEL (MITSUBISHI PART NO. 31N42-00500)	1

TABLE-26
BREATHER




TABLE-26
BREATHER

Fig. No.	Part No.	Description	Qty
1	D10698180.9	HOSE BREATHER (MITSUBISHI PART NO 31N4300101)	1

TABLE-27
WATER PUMP




TABLE-27
WATER PUMP

Fig. No.	Part No.	Description	Qty
1	D10698320.9	WATER PUMP ASSEMBLY-SL (MITSUBISHI PART NO 31N4500020)	1
2	D10734050.9	NIPPLE,HOSE (MITSUBISHI PART NO. 31N45-01500)	1
3	D10734060.9	GASKET,WATER PUMP (MITSUBISHI PART NO. 31N45-01600)	1
4	D10734070.9	PLATE,WATER PUMP (MITSUBISHI PART NO. 31N45-01200)	1
5	D10734080.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-06030)	2
6	D10698330.9	GASKET WATER PUMP (MITSUBISHI PART NO 31N4500200)	1
7	D10734100.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08045)	3
8	D10734110.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08060)	1
9	D10734120.9	WASHER,PLAIN (MITSUBISHI PART NO. F2500-08000)	4

TABLE-28
WATER PUMP PULLEY




TABLE-28
WATER PUMP PULLEY

Fig. No.	Part No.	Description	Qty
1	D10734130.9	PULLEY,WATER PUMP (MITSUBISHI PART NO. 31N45-00300)	1

TABLE-29
COOLING SYSTEM




TABLE-29
COOLING SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10734140.9	CASE ASSY,THERMOSTAT (MITSUBISHI PART NO. 31N46-00050)	1
2	D10734150.9	THERMOSTAT ASSY (MITSUBISHI PART NO. K6516441)	1
3	D10734160.9	GASKET,THERMOSTAT (MITSUBISHI PART NO. 31A46-11200)	1
4	D10734170.9	BOLT,FLANGE (MITSUBISHI PART NO. F1010-08025)	2
5	D10734180.9	COVER,THERMOSTAT (MITSUBISHI PART NO. 31N46-00600)	1
6	D10734190.9	GASKET,THERMO CASE (MITSUBISHI PART NO. 31N46-00700)	1
7	D10734200.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08065)	2
8	D10698280.9	HOSE ASSEMBLY BY-PASS (MITSUBISHI PART NO 31N4600060)	1
9	D10734220.9	HOSE,BY-PASS (MITSUBISHI PART NO. 31N46-00800)	1
10	D10734230.9	CLAMP,HOSE(MITSUBISHI PART NO. F4300-02000)	2
11	D10734240.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08070)	1

TABLE-30
FAN SPACER




TABLE-30
FAN SPACER

Fig. No.	Part No.	Description	Qty
1	D10734250.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-06025)	4


TABLE-31
FUEL SYSTEM

TABLE-31
FUEL SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10734260.9	NOZZLE ASSY,INJECTION (MITSUBISHI PART NO. MM435-94101)	3
2	D10698160.9	GASKET HOLDER (MITSUBISHI PART NO 30N6100600)	3
3	D10698150.9	GASKET FUEL RETURN PIPE (MITSUBISHI PART NO 30N6100800)	3
4	D10734290.9	NUT (MITSUBISHI PART NO. 31N61-00100)	3
5	D10734300.9	PIPE,INJECTION NO.1 (MITSUBISHI PART NO. 31N61-02200)	1
6	D10734310.9	PIPE,INJECTION NO.2 (MITSUBISHI PART NO. 31N61-02300)	1
7	D10734320.9	PIPE,INJECTION NO.3 (MITSUBISHI PART NO. 31N61-02400)	1
8	D10734330.9	CLAMP (MITSUBISHI PART NO. MM430-70301)	2
9	D10734340.9	CLAMP (MITSUBISHI PART NO. MM430-61401)	2
10	D10734350.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1825-06025)	2
11	D10734360.9	PIPE,FUEL LEAK OFF (MITSUBISHI PART NO. 31N61-01600)	1
12	D10698210.9	HOSE ASSEMBLY AIR VENT (MITSUBISHI PART NO 31N6101200)	1
13	D10698220.9	HOSE FUEL (MITSUBISHI PART NO 31N6101700)	1
14	D10698230.9	HOSE FUEL (MITSUBISHI PART NO 31N6101400)	1
15	D10734400.9	CLIP,HOSE (MITSUBISHI PART NO. 30N61-01300)	4
16	D10734410.9	HOSE,RUBBER (MITSUBISHI PART NO. 31N61-01300)	1
17	D10734420.9	JOINT,THREE WAY (MITSUBISHI PART NO. 30N61-01200)	1

TABLE-32
FUEL SYSTEM (NOZZLE ASSY)




TABLE-32
FUEL SYSTEM (NOZZLE ASSY)

Fig. No.	Part No.	Description	Qty
1	D10734260.9	NOZZLE ASSY,INJECTION (MITSUBISHI PART NO. MM435-94101)	3
2	D10698170.9	NOZZLE AND HOLDER ASSEMBLY (MITSUBISHI PART NO MM43594101)	3
3	D10734440.9	HOLDER ASSY (MITSUBISHI PART NO. MM514045)	3
4	D10734450.9	SHIM (MITSUBISHI PART NO. MD603490)	AR
5	D10734460.9	SHIM (MITSUBISHI PART NO. MD603491)	AR
6	D10734470.9	SHIM (MITSUBISHI PART NO. MD603492)	AR
7	D10734480.9	SHIM (MITSUBISHI PART NO. MD603493)	AR
8	D10734490.9	SHIM (MITSUBISHI PART NO. MD603494)	AR
9	D10734500.9	SHIM (MITSUBISHI PART NO. MD603495)	AR
10	D10734510.9	SHIM (MITSUBISHI PART NO. MD603496)	AR
11	D10734520.9	SHIM (MITSUBISHI PART NO. MD603497)	AR
12	D10734530.9	SHIM (MITSUBISHI PART NO. MD603498)	AR
13	D10734540.9	SHIM (MITSUBISHI PART NO. MD603499)	AR
14	D10734550.9	PIN,PRESSURE (MITSUBISHI PART NO. MM501838)	3
15	D10734560.9	PIECE,DISTANCE (MITSUBISHI PART NO. MM501841)	3
16	D10734570.9	SPRING,PRESSURE (MITSUBISHI PART NO. MM514047)	3
17	D10734580.9	BODY SUB ASSY (MITSUBISHI PART NO.MM514048)	3
18	D10734590.9	NUT,NOZZLE RETAINING (MITSUBISHI PART NO. MM514380)	3

TABLE-33
GOVERNOR




TABLE-33
GOVERNOR

Fig. No.	Part No.	Description	Qty
1	D10734600.9	LEVER ASSY,TENSION (MITSUBISHI PART NO. 31N63-01030)	AR
2	D10734610.9	CASE ASSY,GOVERNOR (MITSUBISHI PART NO. 31N63-03040)	1
3	D10734620.9	BOLT ASSY,HIGH SPEED (MITSUBISHI PART NO. 30N63-00080)	1
4	D10734630.9	BOLT,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04500)	1
5	D10734640.9	NUT,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04600)	1
6	D10734650.9	C-RING,TORQUE SET (MITSUBISHI PART NO. 30N63-04300)	1
7	D10734660.9	C-RING,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04800)	1
8	D10734670.9	COVER,GOVERNOR SHAFT (MITSUBISHI PART NO. 31N63-01400)	1
9	D10734680.9	SHAFT,GOVERNOR (MITSUBISHI PART NO. 31N63-01500)	1
10	D10734690.9	LEVER,SPEED CONTROL (MITSUBISHI PART NO. 31N63-02200)	1
11	D10698340.9	SPRING START (MITSUBISHI PART NO 31N6301800)	1
12	D10734710.9	SPRING SET,TORQUE (MITSUBISHI PART NO. 31A64-01080)	1
13	D10734720.9	NUT,TORQUE SET (MITSUBISHI PART NO. 30L63-00600)	1
14	D10734730.9	CASE,TORQUE SPRING (MITSUBISHI PART NO. 31A64-00200)	1
15	D10734740.9	SPRING,TORQUE (MITSUBISHI PART NO. 31A64-01800)	2
16	D10734750.9	NUT (MITSUBISHI PART NO. MD000961)	1
17	D10734760.9	SCREW,ADJUSTING ROCK (MITSUBISHI PART NO. MD065628)	1
18	D10734770.9	STOPPER,SPRING (MITSUBISHI PART NO. MM434541)	1
19	D10698350.9	SPRING TIE ROD (MITSUBISHI PART NO 31N6302700)	1
20	D10734790.9	BOLT,LOW IDLE SET (MITSUBISHI PART NO. 31N63-00200)	1
21	D10734800.9	PIN,GROOVED (MITSUBISHI PART NO. 31N63-00300)	1
22	D10734810.9	CASE,GOVERNOR (MITSUBISHI PART NO. 31N63-00600)	1
23	D10734820.9	SHIM,GOVERNOR SHAFT (MITSUBISHI PART NO. 31N63-02300)	1
24	D10734830.9	TIE-ROD (MITSUBISHI PART NO. 31N63-02600)	1
25	D10734840.9	LEVER,GOVERNOR SPRING (MITSUBISHI PART NO. 31N63-04300)	1
26	D10734850.9	LEVER,GOVERNOR (MITSUBISHI PART NO. 31N63-04400)	1
27	D10734860.9	NUT (MITSUBISHI PART NO. 49302-90070)	1
28	D10734870.9	NUT,JAM (MITSUBISHI PART NO. F2320-08000)	1
29	D10733450.9	WASHER,SPRING (MITSUBISHI PART NO. F2515-08000)	4
30	D10734880.9	PIN,SPRING (MITSUBISHI PART NO. F2850-03020)	1
31	D10734890.9	O-RING (MITSUBISHI PART NO. F3150-01010)	1
32	D10698360.9	SPRING GOVERNOR (MITSUBISHI PART NO 31N6304200)	1
33	D10734910.9	GASKET,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03100)	1
34	D10734920.9	SHAFT,SLIDING SLEEVE (MITSUBISHI PART NO. 31A63-10305)	1
35	D10734930.9	SLEEVE,SLIDING (MITSUBISHI PART NO. 31A63-20201)	1
36	D10734940.9	WEIGHT ASSY,GOVERNOR (MITSUBISHI PART NO. 31A63-11061)	1
37	D10734950.9	COVER,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04700)	1
38	D10734960.9	COVER,TORQUE SET (MITSUBISHI PART NO. 30N63-04400)	1
39	D10733310.9	BOLT (MITSUBISHI PART NO. 31N11-00900)	8
40	D10734970.9	BOLT,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03500)	1

TABLE-33
GOVERNOR




TABLE-33
GOVERNOR

Fig. No.	Part No.	Description	Qty
41	D10734980.9	COVER,TIE ROD (MITSUBISHI PART NO. 31N63-03600)	1
42	D10734990.9	GASKET,TIE ROD COVER (MITSUBISHI PART NO. 30A63-00101)	1
43	D10735000.9	BOLT,W/B/WWASHER (MITSUBISHI PART NO. F1805-06014)	4

TABLE-34
INJECTION PUMP




TABLE-34
INJECTION PUMP

Fig. No.	Part No.	Description	Qty
1	D10698250.9	PUMP ASSEMBLY FUEL INJECTOR (MITSUBISHI PART NO 31B6514090)	1
2	D10735020.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01100)	AR
3	D10735030.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01200)	AR
4	D10735040.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01300)	AR
5	D10735050.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01400)	AR
6	D10735060.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01500)	AR
7	D10735070.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01600)	AR
8	D10735080.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01700)	AR
9	D10735090.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01800)	AR
10	D10735100.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01900)	AR
11	D10735110.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03100)	AR
12	D10735120.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03200)	AR
13	D10735130.9	SHIM,ADJUSTING (MITSUBISHI PART NO.31N65-03300)	AR
14	D10735140.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03400)	AR
15	D10735150.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03500)	AR
16	D10733210.9	BOLT (MITSUBISHI PART NO. 31N07-02300)	5
17	D10735160.9	WASHER,SEAL (MITSUBISHI PART NO. MK661-12000)	2
18	D10735170.9	COLLAR,UNION (MITSUBISHI PART NO. 31B65-00300)	1

TABLE-35
FUEL INJECTION PUMP DRIVE




TABLE-35
FUEL INJECTION PUMP DRIVE

Fig. No.	Part No.	Description	Qty
1	D10735480.9	SHAFT,FUEL INJECTION PUMP (MITSUBISHI PART NO. 31N65-00700)	1
2	D10735490.9	BEARING,RADIAL BALL (MITSUBISHI PART NO. MD703856)	1
3	D10735500.9	WASHER (MITSUBISHI PART NO. MD000425)	1
4	D10735510.9	KEY,SUNK (MITSUBISHI PART NO. 30N07-02800)	1
5	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	2

TABLE-36
GLOW PLUG & WIRE




TABLE-36
GLOW PLUG & WIRE

Fig. No.	Part No.	Description	Qty
1	D10698370.9	PLUG GLOW 12V (MITSUBISHI PART NO 32A6603102)	3
2	D10735530.9	PLATE,CONNECTION (MITSUBISHI PART NO. 31N66-00200)	1

TABLE-37
ENGINE CONTROL (STOP)




TABLE-37
ENGINE CONTROL (STOP)

Fig. No.	Part No.	Description	Qty
1	D10698240.9	SOLENOID AND NUT SET (MITSUBISHI PART NO 30A8700061)	1
2	D10735550.9	SOLENOID ASSY (MITSUBISHI PART NO. MM409-67002)	1
3	D10735560.9	NUT (MITSUBISHI PART NO. MM409-67101)	1

TABLE-38
INJECTION PUMP (ASSY)




TABLE-38
INJECTION PUMP (ASSY)

Fig. No.	Part No.	Description	Qty
1	D10698410.9	PUMP ASSEMBLY FUEL (MITSUBISHI PART NO 30N6020301)	1
1A	D10698250.9	PUMP ASSEMBLY FUEL INJECTOR (MITSUBISHI PART NO 31B6514090)	1
2	D10735180.9	HOUSING SUB ASSY(MITSUBISHI PART NO. 47X01-06100)	1
3	D10735190.9	ELEMENT SUB ASSY (MITSUBISHI PART NO. 47X01-05400)	3
4	D10735200.9	VALVE SUB ASSY (MITSUBISHI PART NO. 47X01-07700)	3
5	D10735210.9	HOLDER,DELIVERY (MITSUBISHI PART NO. 47X01-13200)	3
6	D10735220.9	SPRING,DELIVERY (MITSUBISHI PART NO. 47X01-13300)	3
7	D10735230.9	O RING(MITSUBISHI PART NO. 47X01-22700)	3
8	D10735240.9	SLEEVE,CONTROL (MITSUBISHI PART NO. MM500229)	3
9	D10735250.9	TAPPET SUB ASSY,INJECTION (MITSUBISHI PART NO. MM500230)	3
10	D10735260.9	PIN,TAPPET GUIDE (MITSUBISHI PART NO. MM500231)	3
11	D10735270.9	SHIM (MITSUBISHI PART NO. MM500309)	AR
12	D10735280.9	SHIM (MITSUBISHI PART NO. MM500314)	AR
13	D10735290.9	SHIM (MITSUBISHI PART NO. MM500310)	AR
14	D10735300.9	SHIM (MITSUBISHI PART NO. MM500315)	AR
15	D10735310.9	SHIM (MITSUBISHI PART NO. MM500311)	AR
16	D10735320.9	SHIM (MITSUBISHI PART NO. MM501246)	AR
17	D10735330.9	SHIM (MITSUBISHI PART NO. MM500312)	AR
18	D10735340.9	SEAT,SPRING (MITSUBISHI PART NO. MM500316)	3
19	D10735350.9	SPRING,PLUNGER (MITSUBISHI PART NO. MM500360)	3
20	D10735360.9	WASHER,COPPER PLATE (MITSUBISHI PART NO. MM500578)	1
21	D10735370.9	SEAT,SPRING (MITSUBISHI PART NO. MM501098)	3
22	D10735380.9	SCREW,AIR BLEEDER (MITSUBISHI PART NO. MM501152)	1
23	D10735390.9	PLATE (MITSUBISHI PART NO. MM501162)	1
24	D10735400.9	SHIM (MITSUBISHI PART NO. MM501364)	AR
25	D10735410.9	RACK ASSY,CONTROL (MITSUBISHI PART NO. MM501311)	1
26	D10735420.9	SCREW,HOLLOW (MITSUBISHI PART NO. MM501320)	1
27	D10735430.9	SHIM (MITSUBISHI PART NO. MM500299)	AR
28	D10735440.9	SHIM (MITSUBISHI PART NO. MM501365)	AR
29	D10735450.9	GASKET,DELIVERY (MITSUBISHI PART NO. MM501856)	3
30	D10735460.9	PLATE,ADJUSTING (MITSUBISHI PART NO. MM514109)	2
31	D10735470.9	BOLT,WASHER HEAD (MITSUBISHI PART NO. MM514195)	2

TABLE-39
ACCESSORY



TABLE-39
ACCESSORY

Fig. No.	Part No.	Description	Qty
1	D10734200.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08065)	1

TABLE-40
INSTRUMENT





TABLE-40
INSTRUMENT

Fig. No.	Part No.	Description	Qty
1	D10698200.9	SWITCH ASSEMBLY THERMOMETER (MITSUBISHI PART NO 30N4600500)	1
2	D10735580.9	PLUG,DRAIN (MITSUBISHI PART NO. MM316248)	1
3	D10698390.9	WASHER SEALING (MITSUBISHI PART NO 0594601601)	2
4	D10698190.9	SWITCH OIL PRESS (MITSUBISHI PART NO 31N9000200)	1
5	D10698300.9	SENSOR TEMPERATURE (MITSUBISHI PART NO 30N9600950)	1

TABLE-41
OVERHAUL GASKET KIT




TABLE-41
OVERHAUL GASKET KIT

Fig. No.	Part No.	Description	Qty
1	D10698400.9	GASKET KIT (MITSUBISHI PART NO 31N9400050)	1
2	D10732620.9	GASKET CYLINDER HEAD (MITSUBISHI PART NO.31B01-23200)	1
3	D10732730.9	SEAL,VALVE STEM (MITSUBISHI PART NO. MD115472)	6
4	D10698140.9	GASKET ROCKER COVER (MITSUBISHI PART NO 31B0413201)	1
5	D10733160.9	SEAL,SIDE (MITSUBISHI PART NO.31A07-12200)	4
6	D10735630.9	GASKET,OIL SEAL CASE (MITSUBISHI PART NO. 31N07-01500)	1
7	D10733280.9	GASKET,FRONT PLATE (MITSUBISHI PART NO. 31N11-00600)	1
8	D10733300.9	GASKET,GEAR CASE (MITSUBISHI PART NO. 31A11-11101)	1
9	D10733340.9	GASKET,HOUSING (MITSUBISHI PART NO.31A11-05201)	1
10	D10698290.9	GASKET OIL PUMP (MITSUBISHI PART NO 30N1101900)	2
11	D10735650.9	GASKET,INLET COVER (MITSUBISHI PART NO. 31B30-00800)	1
12	D10733890.9	GASKET,EXHAUST MANIFOLD (MITSUBISHI PART NO. 31B32-01200)	1
13	D10735660.9	PACKING,OIL PUMP (MITSUBISHI PART NO. 31A35-02300)	1
14	D10734000.9	GASKET (MITSUBISHI PART NO. 34340-00700)	1
15	D10733980.9	GASKET (MITSUBISHI PART NO. MF660036)	1
16	D10698330.9	GASKET WATER PUMP (MITSUBISHI PART NO 31N4500200)	1
17	D10734190.9	GASKET,THERMO CASE (MITSUBISHI PART NO. 31N46-00700)	1
18	D10734160.9	GASKET,THERMOSTAT (MITSUBISHI PART NO. 31A46-11200)	1
19	D10698160.9	GASKET HOLDER (MITSUBISHI PART NO 30N6100600)	3
20	D10698150.9	GASKET FUEL RETURN PIPE (MITSUBISHI PART NO 30N6100800)	3
21	D10734910.9	GASKET,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03100)	1
22	D10734990.9	GASKET,TIE ROD COVER (MITSUBISHI PART NO. 30A63-00101)	1
23	D10698270.9	GASKET (MITSUBISHI PART NO F420214000)	2
24	D10698390.9	WASHER SEALING (MITSUBISHI PART NO 0594601601)	3

TABLE-42
COOLING SYSTEM SUBASSEMBLY




TABLE-42
COOLING SYSTEM SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10704000.9	RADIATOR AND SHROUD ASSEMBLY	1
2	D10716520.9	FRAME ASSEMBLY RADIATOR SIDE LH	1
3	D83500070.9	NUT M6X1.00-6 HEX	1
4	D83500060.9	NUT M8X1.25-6 HEX	2
5	D10716540.9	FRAME ASSEMBLY RADIATOR SIDE RH	1
6	D10547780.9	FRAME ASSEMBLY RADIATOR	1
6 -1	D10877040.9	FRAME ASSEMBLY RADIATOR	1
7	D10801990.9	BOTTLE RADIATOR ASSEMBLY RECOVERY	1
8	D10555800.9	PLATE BAFFLE RADIATOR FRAME	1
9	D10547430.9	MESH ASSEMBLY RADIATOR FRONT	1
10	D10704920.9	SPACER FAN WATER COOLING	1
11	D10704930.9	FAN ASSEMBLY WATER COOLING DIA 350MM	1
12	D10704010.9	HOSE RADIATOR TOP	1
13	D10704020.9	HOSE RADIATOR BOTTOM	1
14	D10017540.9	CLAMP RADIATOR HOSE UPPER	4
14 -1	D10329500.9	CLAMP HOSE WORM DRIVE 55MM	4
15	D86500030.9	WASHER M8 SPRING LOCK	11
16	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	3
17	D85500050.9	WASHER M8 FLAT	11
18	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
19	D82500160.9	SCREW M10X1.50X45-8.8P HEX HEAD	4
20	D86500050.9	WASHER M10 SPRING LOCK	4
21	D10668970.9	BEADING RADIATOR FRAME TOP	1
22	D10559580.9	FOAM SEALING RADIATOR BOTTOM	1
23	D82500050.9	SCREW M6X1.00X12-6.8 HEX HEAD	2
24	D85500040.9	WASHER M6 FLAT	6
25	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	4
26	D86500040.9	WASHER M6 SPRING LOCK	4
26 -1	D86500030.9	WASHER M8 SPRING LOCK	4
27	D81503520.9	BOLT M6X1.0X50-10.9 HEX HEAD	4
28	D10745350.9	FOAM SEALING RADIATOR BOTTOM	1
29	D10745360.9	FOAM SEALING RADIATOR TOP	1

TABLE-43
AIR CLEANER SUBASSEMBLY




TABLE-43**AIR CLEANER SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10517880.9	CLEANER ASSEMBLY ENGINE AIR	1
2	D10522000.9	BRACKET ASSEMBLY AIR CLEANER	1
3	D10521960.9	BRACKET ASSEMBLY AIR CLEANER HOLDING REAR	1
4	D83500070.9	NUT M6X1.00-6 HEX	2
5	D10521990.9	RUBBER STRAP ASSEMBLY AIR CLEANER HOLDING	1
6	D10522380.9	PIPE AIR CLEANER INTAKE	1
7	D10532900.9	INDICATOR RESTRICTION AIR CLEANER	1
8	D10704030.9	HOSE AIR CLEANER TO INTAKE MANIFOLD	1
9	D10017170.9	CLAMP ASSEMBLY 70MM DIAMETER	3
10	D86500030.9	WASHER M8 SPRING LOCK	6
11	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
12	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	2
13	D85500050.9	WASHER M8 FLAT	9
14	D83500060.9	NUT M8X1.25-6 HEX	2
15	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	1
16	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
17	D10517920.9	FILTER ASSEMBLY PRIMARY ENGINE AIR CLEANER	1

TABLE-44
EXHAUST SYSTEM SUBASSEMBLY




TABLE-44**EXHAUST SYSTEM SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10710200.9	MUFFLER ASSEMBLY HORIZONTAL (INSIDE)	1
2	D10704050.9	PIPE EXHAUST AND BRACKET ASSEMBLY	1
3	D10755640.9	GASKET MUFFLER OUTLET	1
4	D10716020.9	GASKET MUFFLER INLET	1
5	D83500060.9	NUT M8X1.25-6 HEX	4
6	D86500030.9	WASHER M8 SPRING LOCK	8
7	D81501580.9	BOLT M8X1.25X16 HEX HEAD FLANGED	2
8	D85500050.9	WASHER M8 FLAT	6
9	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	2
10	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
11	D10748210.9	PLATE SUPPORT EXHAUST TAIL PIPE	1

TABLE-45
CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (FROM T052427038BG)




TABLE-45**CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (FROM T052427038BG)**

Fig. No.	Part No.	Description	Qty
1	D10508760.9	DISC ASSEMBLY CLUTCH 8.75" ORGANIC LINING	1
2	D10508770.9	COVER ASSEMBLY CLUTCH 8.75" (ORGANIC)	1
3	D10538690.9	BEARING BALL 6001 2RS	1
4	D10044920.9	DOWEL FLY-WHEEL	3
5	D86500030.9	WASHER M8 SPRING LOCK	6
6	D87500030.9	PIN 10X22 PLAIN DOWEL	2
7	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	6

TABLE-46
TRANSMISSION ASSEMBLY DRESSED UP




TABLE-46
TRANSMISSION ASSEMBLY DRESSED UP

Fig. No.	Part No.	Description	Qty
1	D93400450.9	PIN 10X45 CLEVIS	2
2	D10552680.9	PIN LEVER 2WD 4WD ASSEMBLY	1
3	D87500320.9	PIN 6.35X40 SPRING DOWEL COMBINATION TYPE	2
3-1	D87000160.9	PIN 1/4"X1.50" SPRING DOWEL COMBINATION TYPE	2
4	D10552400.9	BLOCK SWIVEL BRAKE PEDAL REAR	4
5	D10552410.9	LEVER BRAKE PEDAL REAR	2
6	D10498400.9	SWITCH ASSEMBLY STOP LAMP	2
6-1	D10498400AB.9	SWITCH ASSEMBLY STOP LAMP	2
6-2	D10716760.9	SWITCH ASSEMBLY (NO TYPE)	2
7	D86500030.9	WASHER M8 SPRING LOCK	4
8	D85500140.9	WASHER M10 FLAT	10
9	D10013460.9	PIN 1/8"X0.75" COTTER	10
10	D10556870.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (PTO)	1
11	D10552770.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (HIGH LOW MEDIUM)	1
12	D82500040.9	SCREW M8X1.25X20-8.8 HEX HEAD	4
13	D10552830.9	BRACKET ASSEMBLY HIGH LOW MEDIUM AND PTO LEVER HOLDING	1
14	D10559610.9	BRACKET PTO GEAR SHIFT SWITCH HOLDING ASSEMBLY	1
15	D10009600.9	WASHER 8.5X22 FLAT PHOSPHATED	4
16	D10552650.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (2WD 4WD)	1
17	D10182150.9	PLUG M16X1.5X16	1
18	D10554200.9	LEVER ASSEMBLY BRAKE PEDAL REAR RH	1
19	D10554230.9	LEVER ASSEMBLY BRAKE PEDAL REAR LH	1
20	D87500330.9	PIN 8X40 SPRING DOWEL COMBINATION TYPE	1

TABLE-47
HOUSING CLUTCH SUBASSEMBLY (9+3)




TABLE-47
HOUSING CLUTCH SUBASSEMBLY (9+3)

Fig. No.	Part No.	Description	Qty
1	D10538270.9	RETAINER INPUT SHAFT	1
1-1	D11080290AA.9	RETAINER INPUT SHAFT	1
2	D10538220.9	SEAL TRANSMISSION INPUT SHAFT	1
3	D81503090.9	BOLT M8X1.25X16-8.8 HEX HEAD	4
4	D10559860.9	WASHER M8 FLAT COPPER (FUEL INJECTION PUMP)	1
5	D10538180.9	HOUSING CLUTCH COMPACT 9+3	1
5-1	D10538180AD.9	HOUSING CLUTCH COMPACT 9+3	1
6	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-48
CLUTCH RELEASE MECHANISM ASSEMBLY




TABLE-48**CLUTCH RELEASE MECHANISM ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10534720.9	HUB AND BUSH ASSEMBLY CLUTCH RELEASE	1
2	D81503440.9	BOLT M8X1.25X40-10.9 HEX HEAD	2
3	D10538360.9	BEARING CLUTCH RELEASE	1
4	D10534690.9	SHAFT ASSEMBLY CLUTCH RELEASE	1
5	D10007690.9	SEAL O RING 2.30X15.60	2
6	D10547230.9	WASHER NYLON 20.5X30 CLUTCH SHAFT	1
7	D92500010.9	GREASE NIPPLE B M6	2
8	D10534750.9	FORK CLUTCH RELEASE (M/S R G BRONZE)	1
8-1	D10781440.9	FORK CLUTCH RELEASE	1

TABLE-49
HOUSING SPEED ASSEMBLY




TABLE-49
HOUSING SPEED ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10538200.9	HOUSING SPEED COMPACT 9+3	1
2	D87500030.9	PIN 10X22 PLAIN DOWEL	2

TABLE-50
GEAR ASSEMBLY IDLER REVERSE SPEED




TABLE-50
GEAR ASSEMBLY IDLER REVERSE SPEED

Fig. No.	Part No.	Description	Qty
1	D10534960.9	GEAR IDLER REVERSE SPEED Z-33	1
2	D10543070.9	BEARING NEEDLE ROLLER 25X35X30	1
3	D10534800.9	SHAFT REVERSE IDLER	1
4	D86500190.9	WASHER 45X25X1.5	2
5	D10005170.9	WASHER BOLT THRUST	1
6	D10293400.9	BOLT THRUST M8X1.25X59 HEX	1

TABLE-51
COVER TOP SPEED ASSEMBLY





TABLE-51**COVER TOP SPEED ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10543120.9	COVER TOP SPEED HOUSING	1
2	D10547250.9	INDICATOR TRANSMISSION OIL LEVEL	1
3	D10005120.9	WASHER M24 FLAT COPPER	1
4	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	10
5	D85500130.9	WASHER M8 FLAT	10
6	D10667480.9	GASKET COVER TOP SPEED HOUSING	1

TABLE-52
DRIVER TRAIN INPUT ASSEMBLY




TABLE-52**DRIVER TRAIN INPUT ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10534680.9	SHAFT TRANSMISSION INPUT	1
2	D10541440.9	BEARING BALL 6305 Z-C3	1
3	D10170190.9	BEARING BALL 6205	1
4	D10553350.9	SPACER 35X25X3.0	1
4-1	D11274260AA.9	SPACER 35 X 25 X 4.8	1
5	D90500390.9	CIRCLIP B52X2.0 N	1
6	D90000480.9	CIRCLIP A25X2.0 H	2
7	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	1
8	D10534850.9	GEAR DRIVING CONSTANT MESH Z-18	1

TABLE-53
DRIVE TRAIN SPEED ASSEMBLY




TABLE-53
DRIVE TRAIN SPEED ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10534770.9	SHAFT SPEED DRIVING Z-13 / Z-14	1
2	D10170170.9	BEARING BALL 6305	2
3	D10541490.9	BEARING ROLLER NJ 205	1
4	D10541460.9	BEARING BALL 6304	1
5	D90500390.9	CIRCLIP B52X2.0 N	2
6	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	2
7	D10534790.9	SHAFT SPEED DRIVEN	1
8	D10541740.9	WASHER 45X25X3 THRUST	1
9	D10541730.9	WASHER THRUST GEAR DRIVEN REVERSE SPEED	2
10	D10541710.9	SPACER 33X25 SPEED SHAFT	1
11	D10538330.9	COUPLING GEAR SHIFT	2
12	D10538340.9	HUB GEAR SHIFT 2ND AND 3RD SPEED	1
13	D10538350.9	HUB GEAR SHIFT 1ST AND REVERSE SPEED	1
14	D10534950.9	GEAR DRIVEN REVERSE SPEED Z-27	1
15	D10543080.9	BEARING NEEDLE ROLLER 28X33X17	2
16	D10538300.9	GEAR AND BUSH ASSEMBLY DRIVEN 1ST SPEED Z-29	1
17	D10534860.9	GEAR DRIVEN CONSTANT MESH Z-35	1
18	D10534890.9	GEAR DRIVING 2ND SPEED Z-19	1
19	D10538280.9	GEAR AND BUSH ASSEMBLY DRIVEN 2ND SPEED Z-30	1
20	D10534940.9	GEAR DRIVEN 3RD SPEED Z-23	1
21	D10534930.9	GEAR DRIVING 3RD SPEED Z-26	1

TABLE-54
SPEED SHIFTING SYSTEM ASSEMBLY




TABLE-54**SPEED SHIFTING SYSTEM ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10535020.9	RAIL GEAR SHIFT 2-3 SPEED	1
2	D10535030.9	RAIL GEAR SHIFT 1-R SPEED	1
3	D10535040.9	FORK GEAR SHIFT 1-R SPEED	1
4	D10535050.9	FORK GEAR SHIFT 2-3 SPEED	1
5	D83000010.9	NUT 3/8"-24 HEX	2
6	D10000550.9	SCREW TRANSMISSION CONNECTOR LOCK	2
7	D10543110.9	PIN DETENT DIA8.0X25.6	2
8	D10543130.9	SPRING SPEED GEAR SHIFT	2
9	D10006740.9	BALL 5/16" SNAP LOCK	2
10	D10535140.9	INTERLOCK GEAR SHIFTING	1
11	D93100010.9	PLUG 1/4"-18 PIPE	1

TABLE-55
GEAR SPEED SELECTION ASSEMBLY




TABLE-55**GEAR SPEED SELECTION ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10510300.9	PLUG DIFFERENTIAL LOCK LEVER SHAFT RH-FRONT	1
2	D10589570.9	SEAL OIL SPEED SHIFT SHAFT	1
3	D10586100.9	SHAFT SPEED SHIFTING	1
4	D85500600.9	WASHER 30X20X2.0 FLAT	2
5	D10587520.9	SPRING SPEED SHIFTING 9+3	1
5-1	D11088250AA.9	SPRING SPEED SHIFTING	1
6	D10546180.9	PIN REAR AXLE DIFFERENTIAL LOCK SHAFT	1
7	D87500680.9	PIN 8X32 SPRING DOWEL COMBINATION TYPE	1
8	D10586110.9	LEVER SPEED SHIFTING	1
9	D10203560.9	CLAMP GROMMET GEAR SHIFTING LEVER	1
10	D10671030.9	BOOT HOUSING MOUNTING MAIN GEAR SHIFT LEVER	1

TABLE-56
DRIVE TRAIN 4WD ASSEMBLY (9+3)




TABLE-56**DRIVE TRAIN 4WD ASSEMBLY (9+3)**

Fig. No.	Part No.	Description	Qty
1	D10542290.9	COVER FRONT DROP BOX	1
2	D93601110.9	SEAL OIL 22X37X7.0	1
3	D93601120.9	SEAL O RING 1.78X42.0	1
4	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
5	D10542280.9	SHAFT OUTPUT DROP BOX	1
6	D10542260.9	GEAR OUTPUT 4WD Z-25	1
7	D10548300.9	SPRING COMPRESSION GEAR (4WD)	1
8	D10006740.9	BALL 5/16" SNAP LOCK	1
9	D10583080.9	SPACER 20X26X8.0 SHAFT DROP BOX	1
10	D10541470.9	BEARING BALL 6005	1
11	D90000480.9	CIRCLIP A25X2.0 H	1
12	D10152510.9	SEAL OIL 20.0X30.0X7.0	1
13	D10542300.9	LEVER 4WD ENGAGE	1
14	D10252790.9	PIN PTO SHIFTER FORK	1
15	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-57
PLATE INTERMEDIATE TRANSMISSION ASSEMBLY




TABLE-57**PLATE INTERMEDIATE TRANSMISSION ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10565720.9	PLATE INTERMEDIATE TRANSMISSION Z 24	1
2	D81502150.9	BOLT M10X1.50X25-10.9 HEX HEAD	4
3	D10001990.9	BEARING ASSEMBLY TRANSMISSION MAIN SHAFT REAR PILOT	1
4	D10565690.9	GEAR DRIVER 4WD Z 24	1
5	D10541490.9	BEARING ROLLER NJ 205	1
6	D10541500.9	BEARING ROLLER NJ 204	1
7	D90500390.9	CIRCLIP B52X2.0 N	1

TABLE-58
GEAR ASSEMBLY 4WD IDLER




TABLE-58
GEAR ASSEMBLY 4WD IDLER

Fig. No.	Part No.	Description	Qty
1	D10542270.9	SHAFT IDLER 4WD	1
2	D10542250.9	GEAR IDLER 4WD Z-26	1
3	D10106190.9	BEARING NEEDLE ROLLER (25X33X23.8)	1
4	D90000480.9	CIRCLIP A25X2.0 H	1
5	D86500190.9	WASHER 45X25X1.5	1
6	D10673250.9	WASHER THRUST GEAR 4WD IDLER	1

TABLE-59
GEAR DRIVE TRAIN RANGE ASSEMBLY (9+3)




TABLE-59**GEAR DRIVE TRAIN RANGE ASSEMBLY (9+3)**

Fig. No.	Part No.	Description	Qty
1	D10534980.9	GEAR DRIVING HIGH RANGE Z-27	1
2	D10534990.9	GEAR DRIVING MEDIUM RANGE Z-23	1
3	D10535010.9	GEAR DRIVEN LOW RANGE Z-41	1
4	D10534970.9	SHAFT RANGE DRIVING Z-11	1
5	D90500140.9	CIRCLIP B55X2 N INTERNAL (IS3075 PART-II)	1
6	D10541450.9	BEARING BALL 6006	1
7	D10541770.9	SPACER RANGE DRIVING LOW GEAR	1
8	D10541760.9	SPACER RANGE DRIVING HIGH GEAR	1
9	D10547280.9	WASHER TAB LOCK	1
10	D83501010.9	NUT M22X1.5 HEX HEAD (THICKNESS 8.0MM)	1
11	D10535000.9	GEAR DRIVEN HIGH-MEDIUM RANGE Z-16/27	1
12	D90000080.9	CIRCLIP A30X1.5 N	1
13	D10541780.9	SPACER TAIL PINION SHAFT	1
14	D10052860.9	BEARING TAPPER ROLLER 30206	1
15	D10562420.9	SPACER GRADED PINION SHAFT (2.5 MM)	AR
16	D10562430.9	SPACER GRADED PINION SHAFT (2.6 MM)	AR
17	D10562440.9	SPACER GRADED PINION SHAFT (2.7 MM)	AR
18	D10562450.9	SPACER GRADED PINION SHAFT (2.8 MM)	AR
19	D10562460.9	SPACER GRADED PINION SHAFT (2.9 MM)	AR
20	D10562470.9	SPACER GRADED PINION SHAFT (3.0 MM)	AR
21	D10562480.9	SPACER GRADED PINION SHAFT (3.1 MM)	AR
22	D10562490.9	SPACER GRADED PINION SHAFT (3.2 MM)	AR
23	D90500320.9	CIRCLIP B62X3.0 H	1
24	D10541500.9	BEARING ROLLER NJ 204	1

TABLE-60
RANGE GEAR SHIFTING ASSEMBLY (COMPACT)




TABLE-60
RANGE GEAR SHIFTING ASSEMBLY (COMPACT)

Fig. No.	Part No.	Description	Qty
1	D87500700.9	PIN 6X30 SPRING DOWEL COMBINATION TYPE	1
2	D10535070.9	RAIL RANGE SHIFTING	1
3	D10535080.9	SHAFT AND LEVER ASSEMBLY RANGE SHIFTING	1
4	D10152510.9	SEAL OIL 20.0X30.0X7.0	1
5	D10535060.9	FORK RANGE SHIFTING	1
6	D10547290.9	SPRING RANGE GEAR SHIFT	1
7	D10006740.9	BALL 5/16" SNAP LOCK	1

TABLE-61
HOUSING REAR AXLE CENTRE SUBASSEMBLY (9+3)




TABLE-61**HOUSING REAR AXLE CENTRE SUBASSEMBLY (9+3)**

Fig. No.	Part No.	Description	Qty
1	D10538250.9	HOUSING REAR COMPACT 9+3	1
2	D10213110.9	PLUG DRAIN 3/4-14 NPTF (MAGNETIC)	1
3	D87500030.9	PIN 10X22 PLAIN DOWEL	9
4	D93400460.9	PIN 10X35 PLAIN DOWEL	2
5	D10541130.9	SHIM RETAINER DIFFERENTIAL (0.075 MM)	AR
6	D10541140.9	SHIM RETAINER DIFFERENTIAL (0.125 MM)	AR
7	D10541150.9	SHIM RETAINER DIFFERENTIAL (0.2285 MM)	AR
8	D10541160.9	SHIM RETAINER DIFFERENTIAL (0.4065 MM)	AR
9	D10541170.9	SHIM RETAINER DIFFERENTIAL (0.5335 MM)	AR
10	D10541180.9	SHIM RETAINER DIFFERENTIAL (0.7875 MM)	AR
11	D10537800.9	SHIM REAR AXLE SHAFT (0.075 MM)	AR
12	D10537810.9	SHIM REAR AXLE SHAFT (0.125 MM)	AR
13	D10537820.9	SHIM REAR AXLE SHAFT (0.2285 MM)	AR
14	D10537830.9	SHIM REAR AXLE SHAFT (0.4065 MM)	AR
15	D10537840.9	SHIM REAR AXLE SHAFT (0.5335 MM)	AR
16	D10537850.9	SHIM REAR AXLE SHAFT (0.7875 MM)	AR

TABLE-62
GEAR AND DIFFERENTIAL REAR AXLE SUBASSEMBLY




TABLE-62**GEAR AND DIFFERENTIAL REAR AXLE SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10541050.9	GEAR SET BEVEL PINION AND CROWN WHEEL REAR AXLE Z-41/11	1
1.1	D10541060.9	SHAFT BEVEL PINION REAR AXLE DIFFERENTIAL Z-11	1
1.2	D10541070.9	GEAR DRIVEN REAR AXLE DIFFERENTIAL Z-41	1
2	D10537130.9	CASING DIFFERENTIAL REAR AXLE	1
3	D82501060.9	SCREW M8X1.25X18-10.9 HEX HEAD	10
4	D85500440.9	WASHER 8.1X13X1.0 FLAT	10
5	D10536870.9	WASHER LOCK DIFFERENTIAL CROWN WHEEL GEAR	5
6	D10520880.9	BEVEL SIDE GEAR DIFFERENTIAL Z-13	2
7	D10536860.9	WASHER REAR AXLE DIFFERENTIAL THRUST	2
8	D10520890.9	PINION GEAR DIFFERENTIAL Z-9	2
9	D10536850.9	WASHER REAR AXLE DIFFERENTIAL PINION	2
10	D10536840.9	SPIDER REAR AXLE DIFFERENTIAL	1
11	D87500540.9	PIN 5X40 SPRING DOWEL	1

TABLE-63
DIFFERENTIAL LOCK SUBASSEMBLY




TABLE-63**DIFFERENTIAL LOCK SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10541080.9	SPRING REAR AXLE DIFFERENTIAL LOCK	1
2	D10541100.9	SHAFT AND LEVER ASSEMBLY REAR AXLE DIFFERENTIAL LOCK	1
3	D10541110.9	FORK DIFFERENTIAL LOCK	1
4	D10007720.9	SEAL O RING 2.00X14.00	2
5	D10546180.9	PIN REAR AXLE DIFFERENTIAL LOCK SHAFT	2
6	D10550590.9	SPACER 18X26X4.0 FLAT	1
7	D10541090.9	SLEEVE REAR AXLE DIFFERENTIAL LOCK	1

TABLE-64
RETAINER BEARING DIFFERENTIAL SUBASSEMBLY LH




TABLE-64
RETAINER BEARING DIFFERENTIAL SUBASSEMBLY LH

Fig. No.	Part No.	Description	Qty
1	D10537770.9	RETAINER BEARING DIFFERENTIAL LH	1
2	D10584630.9	BALL BEARING 6211 CN	1
3	D86500030.9	WASHER M8 SPRING LOCK	6
4	D82500080.9	SCREW M8X1.25X25-8.8 HEX HEAD	6

TABLE-65
RETAINER BEARING DIFFERENTIAL SUBASSEMBLY RH





TABLE-65
RETAINER BEARING DIFFERENTIAL SUBASSEMBLY RH

Fig. No.	Part No.	Description	Qty
1	D10537780.9	RETAINER BEARING DIFFERENTIAL RH	1
2	D10541480.9	BEARING BALL 6011	1
3	D86500030.9	WASHER M8 SPRING LOCK	6
4	D82500080.9	SCREW M8X1.25X25-8.8 HEX HEAD	6

TABLE-66
HOUSING REAR AXLE RH SUBASSEMBLY




TABLE-66
HOUSING REAR AXLE RH SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10777560.9	HOUSING REAR AXLE RH	1
1-1	D10777560BA.9	HOUSING REAR AXLE RH	1
2	D10507990.9	BRAKE ASSEMBLY REAR WHEEL 4.5" (WET TYPE)	1
2-1	D10507990AD.9	BRAKE ASSEMBLY REAR WHEEL	1
3	D10537790.9	HOUSING BRAKE INNER RH	1
4	D81503880.9	BOLT M10X1.50X30-10.9 HEX HEAD (16 A/F)	5
5	D86500090.9	WASHER M10 SPRING LOCK	16
5-1	D86500030.9	WASHER M8 SPRING LOCK	16
6	D10618950.9	BEARING BALL 6209 CN	1
7	D90500060.9	CIRCLIP B85X2.5 N	1
8	D93601420.9	SEAL OIL 45X70X14.0	1
9	D10006570.9	PLUG DRAIN M14X1.5X10	2
10	D10513210.9	WASHER BONDED SEAL 14.7X22.0X1.5	1
11	D10580870.9	WASHER LOCK BULL PINION SHAFT BEARING	1
12	D82501060.9	SCREW M8X1.25X18-10.9 HEX HEAD	2
13	D90500470.9	CIRCLIP B70X1.5 N	1
14	D10527500.9	SHAFT AXLE REAR	1
15	D10579620.9	BOLT M16X1.5X48-10.9 REAR WHEEL	5
16	D10536470.9	SHAFT BULL PINION RH (Z-9)	1
17	D10533260.9	BEARING BALL 6306	2
18	D90000560.9	CIRCLIP A30.0X2.0 H	1
19	D10527440.9	SPACER BULL GEAR LOCKING	1
20	D10527450.9	GEAR DRIVEN FINAL DRIVE REDUCTION (Z-53)	1
21	D10527460.9	SPACER AXLE SHAFT INNER	1
22	D10536480.9	NUT CRIMPING M30X1.5	1
23	D10580860.9	PLUG AXLE HOUSING REAR	1
24	D81503420.9	BOLT M10X1.50X70-10.9 HEX HEAD	10
25	D81503890.9	BOLT M10X1.50X143-10.9 HEX HEAD (16 A/F)	1
26	D10181170.9	BOOT EXTERNAL REAR WHEEL BRAKE LINKAGE (DIA 50)	1
27	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR