

Parts Catalog

FARMTRAC

TRACTOR FARMTRAC 26 EXPORT EU
,COMPACT,SC,PS,STAGEV, 9 3, BG,MHI,3
CYL,78x92,24.3HP@2500ERPM

Escorts Agri Machinery

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
1	ENGINE ASSEMBLY MITSUBISHI MVS3L2-Z362ET-19.9KW@2700RPM EXPORT DRESSED UP WITH CLUTCH ASSEMBLY	1	1-2
2	INLET SYSTEM	2	3-4
3	EXHAUST SYSTEM	3	5-6
4	OIL PUMP	4	7-8
5	OIL STRAINER	5	9-10
6	OIL SYSTEM	6	11-12
7	OIL FILTER	7	13-14
8	OIL FILLER & GUAGE	8	15-16
9	BREATHER	9	17-18
10	WATER PUMP	10	19-20
11	WATER PUMP PULLEY	11	21-22
12	COOLING SYSTEM	12	23-24
13	FAN SPACER	13	25-26
14	CYLINDER HEAD	14	27-28
15	FUEL SYSTEM	15	29-30
16	FUEL SYSTEM (NOZZLE ASSY)	16	31-32
17	GOVERNOR	17	33-36
18	INJECTION PUMP	18	37-38
19	FUEL INJECTION PUMP DRIVE	19	39-40
20	GLOW PLUG & WIRE	20	41-42
21	ENGINE CONTROL (STOP)	21	43-44
22	INJECTION PUMP (ASSY)	22	45-46
23	ACCESSORY	23	47-48
24	INSTRUMENT	24	49-50
25	LIFTING EYE	25	51-52
26	VALVE MECHANISM	26	53-54
27	ROCKER COVER	27	55-56
28	CAMSHAFT & TAPPET	28	57-58
29	CRANKCASE (ASSY)	29	59-60
30	OVERHAUL GASKET KIT	30	61-62

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
31	COOLING SYSTEM SUBASSEMBLY	31	63-64
32	AIR CLEANER SUBASSEMBLY	32	65-66
33	EXHAUST SYSTEM SUBASSEMBLY	33	67-68
34	CRANKCASE (OIL SEAL CASE)	34	69-70
35	DRAIN COCK & PIPE	35	71-72
36	MAIN BEARING	36	73-74
37	TIMING GEAR CASE	37	75-76
38	TIMING GEAR	38	77-78
39	OIL PAN	39	79-80
40	PISTON	40	81-82
41	CONNECTING ROD	41	83-84
42	CRANKSHAFT	42	85-86
43	CRANK PULLEY	43	87-88
44	DRIVE TRAIN PTO AND SHIFTING SUBASSEMBLY	44	89-90
45	SHAFT PROPELLER ASSEMBLY (4WD COMPACT)	45	91-92
46	TRANSMISSION ASSEMBLY DRESSED UP	46	93-94
47	HOUSING CLUTCH SUBASSEMBLY (9+3)	47	95-96
48	CLUTCH RELEASE MECHANISM ASSEMBLY	48	97-98
49	HOUSING SPEED ASSEMBLY	49	99-100
50	GEAR ASSEMBLY IDLER REVERSE SPEED	50	101-102
51	COVER TOP SPEED ASSEMBLY	51	103-104
52	DRIVER TRAIN INPUT ASSEMBLY	52	105-106
53	DRIVE TRAIN SPEED ASSEMBLY	53	107-108
54	SPEED SHIFTING SYSTEM ASSEMBLY	54	109-110
55	GEAR SPEED SELECTION ASSEMBLY	55	111-112
56	DRIVE TRAIN 4WD ASSEMBLY (9+3)	56	113-114
57	PLATE INTERMEDIATE TRANSMISSION ASSEMBLY	57	115-116
58	GEAR ASSEMBLY 4WD IDLER	58	117-118
59	GEAR DRIVE TRAIN RANGE ASSEMBLY (9+3)	59	119-120
60	RANGE GEAR SHIFTING ASSEMBLY (COMPACT)	60	121-122

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
61	HARDWARE BUCKLE UP TRANSMISSION AND REAR AXLE SUBASSEMBLY	61	123-124
62	HARDWARE BUCKLE UP ADAPTOR PLATE & BACKEND HOUSING SUBASSEMBLY	62	125-126
63	HARDWARE BUCKLE UP CLUTCH HOUSING & SPEED HOUSING SUBASSEMBLY	63	127-128
64	DIFFERENTIAL ASSEMBLY FRONT AXLE (4WD COMPACT)	64	129-130
65	RETAINER AND BEVEL PINION SHAFT ASSEMBLY FRONT AXLE (4WD COMPACT)	65	131-132
66	CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (UPTO T052417111LG)	66	133-134
67	CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (FROM T052427038BG)	67	135-136
68	COUPLING TRANSMISSION CLUTCH HOUSING ASSEMBLY	68	137-138
69	WHEEL AND TYRE ASSEMBLY FRONT 6X12 (M/S BKT AGRI)	69	139-140
70	WHEEL AND TYRE ASSEMBLY REAR 8.3X20 (M/S BKT AGRI)	70	141-142
71	FRONT AXLE ASSY.	71	143-144
72	HOUSING ASSEMBLY SWIVEL FRONT AXLE RH (4WD COMPACT)	72	145-148
73	HOUSING ASSEMBLY SWIVEL FRONT AXLE LH (4WD COMPACT)	73	149-152
74	PILLOW BLOCK SUBASSEMBLY FRONT	74	153-154
75	PILLOW BLOCK SUBASSEMBLY REAR	75	155-156
76	INDICATOR FRONT AXLE OIL LEVEL	76	157-158
77	AXLE FRONT WITH CYLINDER AND LINK ASSEMBLY	77	159-160
78	SUPPORT AND FRONT AXLE ASSEMBLY	78	161-162
79	HOUSING REAR AXLE CENTRE SUBASSEMBLY (9+3)	79	163-164
80	GEAR AND DIFFERENTIAL REAR AXLE SUBASSEMBLY	80	165-166
81	DIFFERENTIAL LOCK SUBASSEMBLY	81	167-168
82	RETAINER BEARING DIFFERENTIAL SUBASSEMBLY LH	82	169-170
83	RETAINER BEARING DIFFERENTIAL SUBASSEMBLY RH	83	171-172
84	HOUSING REAR AXLE RH SUBASSEMBLY	84	173-174
85	HOUSING REAR AXLE LH SUBASSEMBLY	85	175-176
86	COVER ASSEMBLY GUARD STEERING CYLINDER	86	177-178
87	WHEEL STEERING AND UNIT STEERING SUBASSEMBLY	87	179-180
88	TUBING POWER STEERING SUBASSEMBLY	88	181-184
89	LEVER RANGE HIGH LOW MEDIUM GEAR SHIFT SUBASSEMBLY	89	185-186
90	LEVER PTO GEAR SHIFT SUBASSEMBLY	90	187-188

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
91	LEVER SPEED GEAR SHIFT SUBASSEMBLY	91	189-190
92	LEVER POSITION CONTROL SUBASSEMBLY	92	191-192
93	LEVER DRAFT CONTROL SUBASSEMBLY	93	193-194
94	LINKAGE ASSEMBLY DIFFERENTIAL LOCK CONTROL	94	195-196
95	LINKAGE CLUTCH SUBASSEMBLY	95	197-198
96	LINKAGE ASSEMBLY BRAKE CONTROL	96	199-200
97	LINKAGE ASSEMBLY THROTTLE CONTROL	97	201-204
98	HYDRAULIC LIFT ASSEMBLY (COMPACT TRACTOR MODEL)	98	205-206
99	LINKAGE THREE POINT COMPACT TRACTOR SUBASSEMBLY	99	207-208
100	PUMP HYDRAULIC LIFT ASSEMBLY	100	209-210
101	TUBING HYDRAULIC SUCTION SUBASSEMBLY	101	211-212
102	TUBING AUXILLIARY VALVE SUBASSEMBLY	102	213-214
103	CYLINDER ASSY	103	215-216
104	INTERNAL LEVER ASSY	104	217-218
105	TOP LINK BRACKET ASSY	105	219-220
106	CONTROL LEVERS ASSY	106	221-222
107	SEAT DRIVER SUBASSEMBLY (EXPORT)	107	223-224
108	HITCH REAR SWINGING DRAWBAR SUBASSEMBLY	108	225-226
109	FENDER SUBASSEMBLY	109	227-228
110	BOARD RUNNING SUBASSEMBLY (EXPORT)	110	229-230
111	HOOD FRONT AND MIRROR SUBASSEMBLY	111	231-232
112	HOOD FRONT LOWER ASSEMBLY	112	233-234
113	HOOD FRONT LOWER SIDE LH ASSEMBLY	113	235-236
114	HOOD FRONT LOWER SIDE RH ASSEMBLY	114	237-238
115	HEADLAMP AND BRACKET MOUNTING ASSEMBLY RH	115	239-240
116	HOOD REAR SUBASSEMBLY	116	241-242
117	LATCH ASSEMBLY HOOD FRONT	117	243-244
118	COVER ASSEMBLY ENGINE SIDE RH	118	245-246
119	COVER ASSEMBLY ENGINE SIDE LH	119	247-248
120	MIRROR AND FRONT LAMP SUBASSEMBLY	120	249-250

TABLE INDEX

Sr No.	Table Name	Table No.	Page No.
121	GUIDE SUPPORT AND GAS SPRING FRONT HOOD SUBASSEMBLY	121	251-252
122	GUIDE SUPPORT AND RADIATOR FRAME SUBASSEMBLY	122	253-254
123	HARNESS SUBASSEMBLY	123	255-258
124	GUARD PROPELLER SHAFT SUBASSEMBLY	124	259-260
125	ROPS FOLDABLE SUBASSEMBLY COMPACT	125	261-262
126	DECAL AND BADGE MODEL IDENTIFICATION ASSEMBLY 26HP EXPORT	126	263-266
127	CONSUMABLES SUBASSEMBLY	127	267-268
128	WEIGHT FRONT AND BUMPER ASSEMBLY	128	269-270
129	BUMPER AND NUT ASSEMBLY FRONT	129	271-272
130	TOW HOOK ASSEMBLY FRONT	130	273-274
131	FRAME FUEL TANK AND BRACKET HINGE ASSEMBLY	131	275-276
132	FUEL TANK SUBASSEMBLY	132	277-278
133	TUBING FUEL SYSTEM SUBASSEMBLY	133	279-280
134	KIT ENGINE OVERHAULING WITH HEAD GASKET (COMPACT TRACTOR)	134	281-282
135	KIT ENGINE OVERHAULING WITH GASKET / MAIN UNDER SIZE 0.25 AND CONNECTING ROD BEARING SET SIZE 0.25	135	283-284
136	KIT ENGINE OVERHAULING WITH GASKET / MAIN UNDER SIZE 0.50 AND CONNECTING ROD BEARING SET SIZE 0.50	136	285-286
137	KIT ENGINE VALVES INLET AND EXHAUST (COMPACT)	137	287-288
138	KIT GASKETS OVERHAULING WITH HEAD GASKET (COMPACT)	138	289-290

TABLE-1
ENGINE ASSEMBLY MITSUBISHI MVS3L2-Z362ET-19.9KW@2700RPM EXPORT DRESSED UP WITH CLUTCH ASSEMBLY




TABLE-1**ENGINE ASSEMBLY MITSUBISHI MVS3L2-Z362ET-19.9KW@2700RPM EXPORT DRESSED UP WITH CLUTCH ASSEMBLY**

Fig. No.	Part No.	Description	Qty
5	D10017460.9	CLAMP ASSEMBLY FUEL TUBE	1
6	D10567380.9	HOSE ASSEMBLY FUEL TANK RETURN	1
7	D10551060.9	BRACKET SUPPORT MUFFLER HORIZONTAL	1
8	D10536300.9	GASKET INTAKE ELBOW MITSUBISHI ENGINE (S3L2)	1
9	D10536290.9	ELBOW INTAKE MANIFOLD MITSUBISHI ENGINE (S3L2)	1
10	D81502510.9	BOLT M8X1.25X60-8.8 HEX HEAD FLANGED (WHITE PASSIVATED)	1
11	D82500230.9	SCREW M8X1.25X20-8.8 HEX HEAD FLANGED	1
12	D10524990.9	LEVER ALTERNATOR ADJUSTING	1
13	D84500450.9	STUD B M12X45-10.9	2
14	D10633630.9	FLYWHEEL ASSEMBLY	1
15	D10044920.9	DOWEL FLY-WHEEL	2
16	D81503200.9	BOLT M12X1.25X30-10.9 HEX HEAD	8
17	D10525000.9	GASKET REAR PLATE ENGINE	1
18	D10524940.9	ADAPTER ENGINE TRANSMISSION COUPLING	1
19	D10524980.9	GASKET STARTER MOTOR	1
20	D10525010.9	SPACER ALTERNATOR ADJUSTMENT	1
21	D82500150.9	SCREW M10X1.50X25-8.8 HEX HEAD	2
22	D81500470.9	BOLT M10X1.50X115 HEX HEAD	1
23	D83500090.9	NUT M10X1.50-8 HEX	1
23-1	D83500170.9	NUT M10X1.50 NYLOCK HEX	1
24	D86500050.9	WASHER M10 SPRING LOCK	2
25	D82500060.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
26	D83500060.9	NUT M8X1.25-6 HEX	1
27	D85500050.9	WASHER M8 FLAT	1
28	D10776850.9	ENGINE ASSEMBLY MITSUBISHI MVS3L2-Z564ET-18.2KW@2500RPM	1

TABLE-2
INLET SYSTEM




TABLE-2
INLET SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10733850.9	COVER ASSY,INLET (MITSUBISHI PART NO. 31N30-00031)	1
2	D10733860.9	GASKET,INLET COVER (MITSUBISHI PART NO.31N30-01300)	1
3	D10733870.9	BOLT,W/WASHER (MITSUBISHI PART NO.F1805-08035)	5

TABLE-3
EXHAUST SYSTEM




TABLE-3
EXHAUST SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10733880.9	MANIFOLD,EXHAUST (MITSUBISHI PART NO. 31N32-00100)	1
2	D10733890.9	GASKET,EXHAUST MANIFOLD (MITSUBISHI PART NO. 31B32-01200)	1
3	D10733900.9	STUD (MITSUBISHI PART NO. F1450-08025)	4
4	D10733910.9	BOLT (MITSUBISHI PART NO. F1035-08020)	4
5	D10733920.9	BOLT (MITSUBISHI PART NO. F1035-08055)	2

TABLE-4
OIL PUMP




TABLE-4
OIL PUMP

Fig. No.	Part No.	Description	Qty
1	D10733930.9	PUMP ASSY,OIL (MITSUBISHI PART NO.31N35-00010)	1
2	D10733940.9	PACKING,BODY (MITSUBISHI PART NO. 31N35-01900)	1
3	D10733950.9	BOLT (MITSUBISHI PART NO. F1035-08025)	3

TABLE-5
OIL STRAINER




TABLE-6
OIL SYSTEM




TABLE-6
OIL SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10733990.9	VALVE ASSY,RELIEF (MITSUBISHI PART NO. 31N36-00010)	1
2	D10734000.9	GASKET (MITSUBISHI PART NO. 34340-00700)	1

TABLE-7
OIL FILTER




TABLE-7
OIL FILTER

Fig. No.	Part No.	Description	Qty
1	D10671130.9	FILTER ASSEMBLY LUBE OIL	1

TABLE-8
OIL FILLER & GUAGE




TABLE-8
OIL FILLER & GUAGE

Fig. No.	Part No.	Description	Qty
1	D10734020.9	GAGE,OIL LEVEL (MITSUBISHI PART NO. 31N42-00500)	1

TABLE-9
BREATHER




TABLE-9
BREATHER

Fig. No.	Part No.	Description	Qty
1	D10698180.9	HOSE BREATHER (MITSUBISHI PART NO 31N4300101)	1

TABLE-10
WATER PUMP




TABLE-10
WATER PUMP

Fig. No.	Part No.	Description	Qty
1	D10698320.9	WATER PUMP ASSEMBLY-SL (MITSUBISHI PART NO 31N4500020)	1
2	D10734050.9	NIPPLE,HOSE (MITSUBISHI PART NO. 31N45-01500)	1
3	D10734060.9	GASKET,WATER PUMP (MITSUBISHI PART NO. 31N45-01600)	1
4	D10734070.9	PLATE,WATER PUMP (MITSUBISHI PART NO. 31N45-01200)	1
5	D10734080.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-06030)	2
6	D10698330.9	GASKET WATER PUMP (MITSUBISHI PART NO 31N4500200)	1
7	D10734100.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08045)	3
8	D10734110.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08060)	1
9	D10734120.9	WASHER,PLAIN (MITSUBISHI PART NO. F2500-08000)	4

TABLE-11
WATER PUMP PULLEY




TABLE-11
WATER PUMP PULLEY

Fig. No.	Part No.	Description	Qty
1	D10734130.9	PULLEY,WATER PUMP (MITSUBISHI PART NO. 31N45-00300)	1

TABLE-12
COOLING SYSTEM




TABLE-12
COOLING SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10734140.9	CASE ASSY,THERMOSTAT (MITSUBISHI PART NO. 31N46-00050)	1
2	D10734150.9	THERMOSTAT ASSY (MITSUBISHI PART NO. K6516441)	1
3	D10734160.9	GASKET,THERMOSTAT (MITSUBISHI PART NO. 31A46-11200)	1
4	D10734170.9	BOLT,FLANGE (MITSUBISHI PART NO. F1010-08025)	2
5	D10734180.9	COVER,THERMOSTAT (MITSUBISHI PART NO. 31N46-00600)	1
6	D10734190.9	GASKET,THERMO CASE (MITSUBISHI PART NO. 31N46-00700)	1
7	D10734200.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08065)	2
8	D10698280.9	HOSE ASSEMBLY BY-PASS (MITSUBISHI PART NO 31N4600060)	1
9	D10734220.9	HOSE,BY-PASS (MITSUBISHI PART NO. 31N46-00800)	1
10	D10734230.9	CLAMP,HOSE(MITSUBISHI PART NO. F4300-02000)	2
11	D10734240.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08070)	1

TABLE-13
FAN SPACER




TABLE-13
FAN SPACER

Fig. No.	Part No.	Description	Qty
1	D10734250.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-06025)	4

TABLE-14
CYLINDER HEAD




TABLE-14
CYLINDER HEAD

Fig. No.	Part No.	Description	Qty
1	D10732550.9	HEAD ASSY,CYLINDER (MITSUBISHI PART NO. 31N01-01053)	1
2	D10732560.9	SEAT,INLET VALVE (MITSUBISHI PART NO.31A01-01201)	3
3	D10732570.9	SEAT EXHAUST VALVE (MITSUBISHI PART NO.31A01-01301)	3
4	D10732580.9	CAP SEALING (MITSUBISHI PART NO.31N01-00300)	1
5	D10732590.9	CAP SEALING (MITSUBISHI PART NO. F5014-25000)	5
6	D10732600.9	PLUG TAPERED (MITSUBISHI PART NO.30N01-01600)	1
7	D10732610.9	BOLT CYLINDER HEAD (MITSUBISHI PART NO.31A01-21100)	11
8	D10732620.9	GASKET CYLINDER HEAD (MITSUBISHI PART NO.31B01-23200)	1
9	D10732630.9	GUIDE EXHAUST VALVE (MITSUBISHI PART NO.31N01-00800)	3
10	D10732640.9	GUIDE INLET VALVE (MITSUBISHI PART NO.31N01-02300)	3
11	D10732650.9	JET COMBUSTION (MITSUBISHI PART NO.31A03-13601)	3

TABLE-15
FUEL SYSTEM




TABLE-15
FUEL SYSTEM

Fig. No.	Part No.	Description	Qty
1	D10734260.9	NOZZLE ASSY,INJECTION (MITSUBISHI PART NO. MM435-94101)	3
2	D10698160.9	GASKET HOLDER (MITSUBISHI PART NO 30N6100600)	3
3	D10698150.9	GASKET FUEL RETURN PIPE (MITSUBISHI PART NO 30N6100800)	3
4	D10734290.9	NUT (MITSUBISHI PART NO. 31N61-00100)	3
5	D10734300.9	PIPE,INJECTION NO.1 (MITSUBISHI PART NO. 31N61-02200)	1
6	D10734310.9	PIPE,INJECTION NO.2 (MITSUBISHI PART NO. 31N61-02300)	1
7	D10734320.9	PIPE,INJECTION NO.3 (MITSUBISHI PART NO. 31N61-02400)	1
8	D10734330.9	CLAMP (MITSUBISHI PART NO. MM430-70301)	2
9	D10734340.9	CLAMP (MITSUBISHI PART NO. MM430-61401)	2
10	D10734350.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1825-06025)	2
11	D10734360.9	PIPE,FUEL LEAK OFF (MITSUBISHI PART NO. 31N61-01600)	1
12	D10698210.9	HOSE ASSEMBLY AIR VENT (MITSUBISHI PART NO 31N6101200)	1
13	D10698220.9	HOSE FUEL (MITSUBISHI PART NO 31N6101700)	1
14	D10698230.9	HOSE FUEL (MITSUBISHI PART NO 31N6101400)	1
15	D10734400.9	CLIP,HOSE (MITSUBISHI PART NO. 30N61-01300)	4
16	D10734410.9	HOSE,RUBBER (MITSUBISHI PART NO. 31N61-01300)	1
17	D10734420.9	JOINT,THREE WAY (MITSUBISHI PART NO. 30N61-01200)	1

TABLE-16
FUEL SYSTEM (NOZZLE ASSY)




TABLE-16
FUEL SYSTEM (NOZZLE ASSY)

Fig. No.	Part No.	Description	Qty
1	D10734260.9	NOZZLE ASSY,INJECTION (MITSUBISHI PART NO. MM435-94101)	3
2	D10698170.9	NOZZLE AND HOLDER ASSEMBLY (MITSUBISHI PART NO MM43594101)	3
3	D10734440.9	HOLDER ASSY (MITSUBISHI PART NO. MM514045)	3
4	D10734450.9	SHIM (MITSUBISHI PART NO. MD603490)	AR
5	D10734460.9	SHIM (MITSUBISHI PART NO. MD603491)	AR
6	D10734470.9	SHIM (MITSUBISHI PART NO. MD603492)	AR
7	D10734480.9	SHIM (MITSUBISHI PART NO. MD603493)	AR
8	D10734490.9	SHIM (MITSUBISHI PART NO. MD603494)	AR
9	D10734500.9	SHIM (MITSUBISHI PART NO. MD603495)	AR
10	D10734510.9	SHIM (MITSUBISHI PART NO. MD603496)	AR
11	D10734520.9	SHIM (MITSUBISHI PART NO. MD603497)	AR
12	D10734530.9	SHIM (MITSUBISHI PART NO. MD603498)	AR
13	D10734540.9	SHIM (MITSUBISHI PART NO. MD603499)	AR
14	D10734550.9	PIN,PRESSURE (MITSUBISHI PART NO. MM501838)	3
15	D10734560.9	PIECE,DISTANCE (MITSUBISHI PART NO. MM501841)	3
16	D10734570.9	SPRING,PRESSURE (MITSUBISHI PART NO. MM514047)	3
17	D10734580.9	BODY SUB ASSY (MITSUBISHI PART NO.MM514048)	3
18	D10734590.9	NUT,NOZZLE RETAINING (MITSUBISHI PART NO. MM514380)	3

TABLE-17
GOVERNOR




TABLE-17
GOVERNOR

Fig. No.	Part No.	Description	Qty
1	D10734600.9	LEVER ASSY,TENSION (MITSUBISHI PART NO. 31N63-01030)	AR
2	D10734610.9	CASE ASSY,GOVERNOR (MITSUBISHI PART NO. 31N63-03040)	1
3	D10734620.9	BOLT ASSY,HIGH SPEED (MITSUBISHI PART NO. 30N63-00080)	1
4	D10734630.9	BOLT,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04500)	1
5	D10734640.9	NUT,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04600)	1
6	D10734650.9	C-RING,TORQUE SET (MITSUBISHI PART NO. 30N63-04300)	1
7	D10734660.9	C-RING,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04800)	1
8	D10734670.9	COVER,GOVERNOR SHAFT (MITSUBISHI PART NO. 31N63-01400)	1
9	D10734680.9	SHAFT,GOVERNOR (MITSUBISHI PART NO. 31N63-01500)	1
10	D10734690.9	LEVER,SPEED CONTROL (MITSUBISHI PART NO. 31N63-02200)	1
11	D10698340.9	SPRING START (MITSUBISHI PART NO 31N6301800)	1
12	D10734710.9	SPRING SET,TORQUE (MITSUBISHI PART NO. 31A64-01080)	1
13	D10734720.9	NUT,TORQUE SET (MITSUBISHI PART NO. 30L63-00600)	1
14	D10734730.9	CASE,TORQUE SPRING (MITSUBISHI PART NO. 31A64-00200)	1
15	D10734740.9	SPRING,TORQUE (MITSUBISHI PART NO. 31A64-01800)	2
16	D10734750.9	NUT (MITSUBISHI PART NO. MD000961)	1
17	D10734760.9	SCREW,ADJUSTING ROCK (MITSUBISHI PART NO. MD065628)	1
18	D10734770.9	STOPPER,SPRING (MITSUBISHI PART NO. MM434541)	1
19	D10698350.9	SPRING TIE ROD (MITSUBISHI PART NO 31N6302700)	1
20	D10734790.9	BOLT,LOW IDLE SET (MITSUBISHI PART NO. 31N63-00200)	1
21	D10734800.9	PIN,GROOVED (MITSUBISHI PART NO. 31N63-00300)	1
22	D10734810.9	CASE,GOVERNOR (MITSUBISHI PART NO. 31N63-00600)	1
23	D10734820.9	SHIM,GOVERNOR SHAFT (MITSUBISHI PART NO. 31N63-02300)	1
24	D10734830.9	TIE-ROD (MITSUBISHI PART NO. 31N63-02600)	1
25	D10734840.9	LEVER,GOVERNOR SPRING (MITSUBISHI PART NO. 31N63-04300)	1
26	D10734850.9	LEVER,GOVERNOR (MITSUBISHI PART NO. 31N63-04400)	1
27	D10734860.9	NUT (MITSUBISHI PART NO. 49302-90070)	1
28	D10734870.9	NUT,JAM (MITSUBISHI PART NO. F2320-08000)	1
29	D10733450.9	WASHER,SPRING (MITSUBISHI PART NO. F2515-08000)	4
30	D10734880.9	PIN,SPRING (MITSUBISHI PART NO. F2850-03020)	1
31	D10734890.9	O-RING (MITSUBISHI PART NO. F3150-01010)	1
32	D10698360.9	SPRING GOVERNOR (MITSUBISHI PART NO 31N6304200)	1
33	D10734910.9	GASKET,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03100)	1
34	D10734920.9	SHAFT,SLIDING SLEEVE (MITSUBISHI PART NO. 31A63-10305)	1
35	D10734930.9	SLEEVE,SLIDING (MITSUBISHI PART NO. 31A63-20201)	1
36	D10734940.9	WEIGHT ASSY,GOVERNOR (MITSUBISHI PART NO. 31A63-11061)	1
37	D10734950.9	COVER,HIGH SPEED SET (MITSUBISHI PART NO. 30N63-04700)	1
38	D10734960.9	COVER,TORQUE SET (MITSUBISHI PART NO. 30N63-04400)	1
39	D10733310.9	BOLT (MITSUBISHI PART NO. 31N11-00900)	8
40	D10734970.9	BOLT,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03500)	1

TABLE-17
GOVERNOR




TABLE-17
GOVERNOR

Fig. No.	Part No.	Description	Qty
41	D10734980.9	COVER,TIE ROD (MITSUBISHI PART NO. 31N63-03600)	1
42	D10734990.9	GASKET,TIE ROD COVER (MITSUBISHI PART NO. 30A63-00101)	1
43	D10735000.9	BOLT,W/B/WWASHER (MITSUBISHI PART NO. F1805-06014)	4

TABLE-18
INJECTION PUMP




TABLE-18
INJECTION PUMP

Fig. No.	Part No.	Description	Qty
1	D10698250.9	PUMP ASSEMBLY FUEL INJECTOR (MITSUBISHI PART NO 31B6514090)	1
2	D10735020.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01100)	AR
3	D10735030.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01200)	AR
4	D10735040.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01300)	AR
5	D10735050.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01400)	AR
6	D10735060.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01500)	AR
7	D10735070.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01600)	AR
8	D10735080.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01700)	AR
9	D10735090.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01800)	AR
10	D10735100.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-01900)	AR
11	D10735110.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03100)	AR
12	D10735120.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03200)	AR
13	D10735130.9	SHIM,ADJUSTING (MITSUBISHI PART NO.31N65-03300)	AR
14	D10735140.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03400)	AR
15	D10735150.9	SHIM,ADJUSTING (MITSUBISHI PART NO. 31N65-03500)	AR
16	D10733210.9	BOLT (MITSUBISHI PART NO. 31N07-02300)	5
17	D10735160.9	WASHER,SEAL (MITSUBISHI PART NO. MK661-12000)	2
18	D10735170.9	COLLAR,UNION (MITSUBISHI PART NO. 31B65-00300)	1

TABLE-19
FUEL INJECTION PUMP DRIVE




TABLE-19
FUEL INJECTION PUMP DRIVE

Fig. No.	Part No.	Description	Qty
1	D10735480.9	SHAFT,FUEL INJECTION PUMP (MITSUBISHI PART NO. 31N65-00700)	1
2	D10735490.9	BEARING,RADIAL BALL (MITSUBISHI PART NO. MD703856)	1
3	D10735500.9	WASHER (MITSUBISHI PART NO. MD000425)	1
4	D10735510.9	KEY,SUNK (MITSUBISHI PART NO. 30N07-02800)	1
5	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	2

TABLE-20
GLOW PLUG & WIRE




TABLE-20
GLOW PLUG & WIRE

Fig. No.	Part No.	Description	Qty
1	D10698370.9	PLUG GLOW 12V (MITSUBISHI PART NO 32A6603102)	3
2	D10735530.9	PLATE,CONNECTION (MITSUBISHI PART NO. 31N66-00200)	1

TABLE-21
ENGINE CONTROL (STOP)




Fig. No.	Part No.	Description	Qty
1	D10698240.9	SOLENOID AND NUT SET (MITSUBISHI PART NO 30A8700061)	1
2	D10735550.9	SOLENOID ASSY (MITSUBISHI PART NO. MM409-67002)	1
3	D10735560.9	NUT (MITSUBISHI PART NO. MM409-67101)	1

TABLE-22
INJECTION PUMP (ASSY)




TABLE-22
INJECTION PUMP (ASSY)

Fig. No.	Part No.	Description	Qty
1	D10698250.9	PUMP ASSEMBLY FUEL INJECTOR (MITSUBISHI PART NO 31B6514090)	1
2	D10735180.9	HOUSING SUB ASSY(MITSUBISHI PART NO. 47X01-06100)	1
3	D10735190.9	ELEMENT SUB ASSY (MITSUBISHI PART NO. 47X01-05400)	3
4	D10735200.9	VALVE SUB ASSY (MITSUBISHI PART NO. 47X01-07700)	3
5	D10735210.9	HOLDER,DELIVERY (MITSUBISHI PART NO. 47X01-13200)	3
6	D10735220.9	SPRING,DELIVERY (MITSUBISHI PART NO. 47X01-13300)	3
7	D10735230.9	O RING(MITSUBISHI PART NO. 47X01-22700)	3
8	D10735240.9	SLEEVE,CONTROL (MITSUBISHI PART NO. MM500229)	3
9	D10735250.9	TAPPET SUB ASSY,INJECTION (MITSUBISHI PART NO. MM500230)	3
10	D10735260.9	PIN,TAPPET GUIDE (MITSUBISHI PART NO. MM500231)	3
11	D10735270.9	SHIM (MITSUBISHI PART NO. MM500309)	AR
12	D10735280.9	SHIM (MITSUBISHI PART NO. MM500314)	AR
13	D10735290.9	SHIM (MITSUBISHI PART NO. MM500310)	AR
14	D10735300.9	SHIM (MITSUBISHI PART NO. MM500315)	AR
15	D10735310.9	SHIM (MITSUBISHI PART NO. MM500311)	AR
16	D10735320.9	SHIM (MITSUBISHI PART NO. MM501246)	AR
17	D10735330.9	SHIM (MITSUBISHI PART NO. MM500312)	AR
18	D10735340.9	SEAT,SPRING (MITSUBISHI PART NO. MM500316)	3
19	D10735350.9	SPRING,PLUNGER (MITSUBISHI PART NO. MM500360)	3
20	D10735360.9	WASHER,COPPER PLATE (MITSUBISHI PART NO. MM500578)	1
21	D10735370.9	SEAT,SPRING (MITSUBISHI PART NO. MM501098)	3
22	D10735380.9	SCREW,AIR BLEEDER (MITSUBISHI PART NO. MM501152)	1
23	D10735390.9	PLATE (MITSUBISHI PART NO. MM501162)	1
24	D10735400.9	SHIM (MITSUBISHI PART NO. MM501364)	AR
25	D10735410.9	RACK ASSY,CONTROL (MITSUBISHI PART NO. MM501311)	1
26	D10735420.9	SCREW,HOLLOW (MITSUBISHI PART NO. MM501320)	1
27	D10735430.9	SHIM (MITSUBISHI PART NO. MM500299)	AR
28	D10735440.9	SHIM (MITSUBISHI PART NO. MM501365)	AR
29	D10735450.9	GASKET,DELIVERY (MITSUBISHI PART NO. MM501856)	3
30	D10735460.9	PLATE,ADJUSTING (MITSUBISHI PART NO. MM514109)	2
31	D10735470.9	BOLT,WASHER HEAD (MITSUBISHI PART NO. MM514195)	2
32	D10698410.9	PUMP ASSEMBLY FUEL (MITSUBISHI PART NO 30N6020301)	1

TABLE-23
ACCESSORY



TABLE-23
ACCESSORY

Fig. No.	Part No.	Description	Qty
1	D10734200.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08065)	1

TABLE-24
INSTRUMENT





TABLE-24
INSTRUMENT

Fig. No.	Part No.	Description	Qty
1	D10698200.9	SWITCH ASSEMBLY THERMOMETER (MITSUBISHI PART NO 30N4600500)	1
2	D10735580.9	PLUG,DRAIN (MITSUBISHI PART NO. MM316248)	1
3	D10698390.9	WASHER SEALING (MITSUBISHI PART NO 0594601601)	2
4	D10698190.9	SWITCH OIL PRESS (MITSUBISHI PART NO 31N9000200)	1
5	D10698300.9	SENSOR TEMPERATURE (MITSUBISHI PART NO 30N9600950)	1

TABLE-25
LIFTING EYE




TABLE-26
VALVE MECHANISM




TABLE-26
VALVE MECHANISM

Fig. No.	Part No.	Description	Qty
1	D10732680.9	VALVE INLET (MITSUBISHI PART NO.31N04-01300)	3
2	D10732690.9	VALVE EXHAUST (MITSUBISHI PART NO. 31N04-01400)	3
3	D10732700.9	SPRING VALVE (MITSUBISHI PART NO. 31N04-01500)	6
4	D10732710.9	RETAINER VALVE SPRING (MITSUBISHI PART NO. MM433-30601)	6
5	D10732720.9	LOCK SPRING RETAINER (MITSUBISHI PART NO. 30N04-00500)	12
6	D10732730.9	SEAL,VALVE STEM (MITSUBISHI PART NO. MD115472)	6
7	D10732740.9	CAP,VALVE STEM (MITSUBISHI PART NO. 31A04-00700)	6
8	D10732750.9	SHAFT ASSY,ROCKER(MITSUBISHI PART NO. 31N04-10080)	1
9	D10732760.9	BRACKET,ROCKER SHAFT (MITSUBISHI PART NO. 31N04-00800)	2
10	D10732770.9	SPRING,ROCKER SHAFT(MITSUBISHI PART NO. 31N04-00900)	2
11	D10732780.9	BRACKET,ROCKER SHAFT (MITSUBISHI PART NO. 31N04-01700)	1
12	D10732790.9	ARM,ROCKER(MITSUBISHI PART NO. 31N04-03500)	6
13	D10732800.9	SHAFT ASSY,ROCKER(MITSUBISHI PART NO. 31N04-10010)	1
14	D10732810.9	CAP,SEALING(MITSUBISHI PART NO. 31N04-00200)	2
15	D10732820.9	SCREW,ROCKER(MITSUBISHI PART NO. 32A04-02401)	6
16	D10732830.9	BOLT(MITSUBISHI PART NO. F1035-05010)	1
17	D10732840.9	NUT,(MITSUBISHI PART NO. F2325-08000)	6
18	D10732850.9	RING,SNAP(MITSUBISHI PART NO. F3200-01900)	2
19	D10732860.9	BOLT,ROCKER BRACKET(MITSUBISHI PART NO. 31N04-01100)	3

TABLE-27
ROCKER COVER




TABLE-27
ROCKER COVER

Fig. No.	Part No.	Description	Qty
1	D10732870.9	COVER ASSY,ROCKER (MITSUBISHI PART NO. 31N04-00071)	1
2	D10698140.9	GASKET ROCKER COVER (MITSUBISHI PART NO 31B0413201)	1
3	D10732890.9	BOLT,W/WASHER(MITSUBISHI PART NO. F1805-08040)	4
4	D10732900.9	CAP,OIL FILLER (MITSUBISHI PART NO. MD008784)	1

TABLE-28
CAMSHAFT & TAPPET




TABLE-28
CAMSHAFT & TAPPET

Fig. No.	Part No.	Description	Qty
1	D10732910.9	CAMSHAFT (MITSUBISHI PART NO. 31N05-00600)	1
2	D10732920.9	KEY,WOODRUFF (MITSUBISHI PART NO. F2872-05019)	1
3	D10732930.9	PLATE,THRUST (MITSUBISHI PART NO. 31N05-00300)	1
4	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	2
5	D10732950.9	TAPPET (MITSUBISHI PART NO. 31N05-00400)	6
6	D10732960.9	ROD,PUSH (MITSUBISHI PART NO. 31N05-00500)	6

TABLE-29
CRANKCASE (ASSY)




TABLE-29
CRANKCASE (ASSY)

Fig. No.	Part No.	Description	Qty
1	D10732970.9	BLOCK ASSY,CYLINDER (MITSUBISHI PART NO. 31N07-01090)	AR
2	D10732980.9	BOLT,BEARING CAP(MITSUBISHI PART NO.31A07-00801)	8
3	D10732990.9	BUSH,CAMSHAFT (MITSUBISHI PART NO.31A07-03100)	1
4	D10733000.9	CAP,SEALING (MITSUBISHI PART NO.31N07-01800)	2
5	D10733010.9	CAP,SEALING (MITSUBISHI PART NO.31N07-01900)	2
6	D10733020.9	GUIDE,OIL LEVEL GAUGE (MITSUBISHI PART NO.30N07-02100)	1
7	D10733030.9	CAP,SEALING (MITSUBISHI PART NO.F5014-12000)	1
8	D10733040.9	CAP,SEALING (MITSUBISHI PART NO.F5014-14000)	1
9	D10732600.9	PLUG TAPERED (MITSUBISHI PART NO.30N01-01600)	1
10	D10733050.9	PLUG,TAPERED MEC (MITSUBISHI PART NO.31N07-02100)	2
11	D10733060.9	BUSHING,KNOCK (MITSUBISHI PART NO.31N07-01100)	4
12	D10733070.9	BUSHING,KNOCK (MITSUBISHI PART NO.30N07-03200)	2
13	D10733080.9	BUSHING,KNOCK (MITSUBISHI PART NO.31N07-01300)	1
14	D10733090.9	PLUG,EXPANSION (MITSUBISHI PART NO.MF665511)	1
15	D10733100.9	PIN,DOWEL (MITSUBISHI PART NO.30N07-02700)	1
16	D10733110.9	PIN,DOWEL (MITSUBISHI PART NO.30N07-00600)	2
17	D10733120.9	SHAFT ASSY,IDLER (MITSUBISHI PART NO.31N07-00050)	1
18	D10733130.9	STEEL BALL,BEARING(MITSUBISHI PART NO.F8000-08000)	1
19	D10733140.9	PIN,DOWEL (MITSUBISHI PART NO.F2846-05000)	2
20	D10733150.9	PLUG,TAPERED (MITSUBISHI PART NO.31N07-02200)	1

TABLE-30
OVERHAUL GASKET KIT




TABLE-30
OVERHAUL GASKET KIT

Fig. No.	Part No.	Description	Qty
1	D10698400.9	GASKET KIT (MITSUBISHI PART NO 31N9400050)	1
2	D10732620.9	GASKET CYLINDER HEAD (MITSUBISHI PART NO.31B01-23200)	1
3	D10732730.9	SEAL,VALVE STEM (MITSUBISHI PART NO. MD115472)	6
4	D10698140.9	GASKET ROCKER COVER (MITSUBISHI PART NO 31B0413201)	1
5	D10733160.9	SEAL,SIDE (MITSUBISHI PART NO.31A07-12200)	4
6	D10735630.9	GASKET,OIL SEAL CASE (MITSUBISHI PART NO. 31N07-01500)	1
7	D10733280.9	GASKET,FRONT PLATE (MITSUBISHI PART NO. 31N11-00600)	1
8	D10733300.9	GASKET,GEAR CASE (MITSUBISHI PART NO. 31A11-11101)	1
9	D10733340.9	GASKET,HOUSING (MITSUBISHI PART NO.31A11-05201)	1
10	D10698290.9	GASKET OIL PUMP (MITSUBISHI PART NO 30N1101900)	2
11	D10735650.9	GASKET,INLET COVER (MITSUBISHI PART NO. 31B30-00800)	1
12	D10733890.9	GASKET,EXHAUST MANIFOLD (MITSUBISHI PART NO. 31B32-01200)	1
13	D10735660.9	PACKING,OIL PUMP (MITSUBISHI PART NO. 31A35-02300)	1
14	D10734000.9	GASKET (MITSUBISHI PART NO. 34340-00700)	1
15	D10733980.9	GASKET (MITSUBISHI PART NO. MF660036)	1
16	D10698330.9	GASKET WATER PUMP (MITSUBISHI PART NO 31N4500200)	1
17	D10734190.9	GASKET,THERMO CASE (MITSUBISHI PART NO. 31N46-00700)	1
18	D10734160.9	GASKET,THERMOSTAT (MITSUBISHI PART NO. 31A46-11200)	1
19	D10698160.9	GASKET HOLDER (MITSUBISHI PART NO 30N6100600)	3
20	D10698150.9	GASKET FUEL RETURN PIPE (MITSUBISHI PART NO 30N6100800)	3
21	D10734910.9	GASKET,GOVERNOR CASE (MITSUBISHI PART NO. 31N63-03100)	1
22	D10734990.9	GASKET,TIE ROD COVER (MITSUBISHI PART NO. 30A63-00101)	1
23	D10698270.9	GASKET (MITSUBISHI PART NO F420214000)	2
24	D10698390.9	WASHER SEALING (MITSUBISHI PART NO 0594601601)	3

TABLE-31
COOLING SYSTEM SUBASSEMBLY




TABLE-31
COOLING SYSTEM SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10558670.9	RADIATOR AND SHROUD ASSEMBLY	1
2	D10547410.9	FRAME ASSEMBLY RADIATOR SIDE LH	1
3	D83500070.9	NUT M6X1.00-6 HEX	1
4	D83500060.9	NUT M8X1.25-6 HEX	2
5	D10547510.9	FRAME ASSEMBLY RADIATOR SIDE RH	1
6	D10547780.9	FRAME ASSEMBLY RADIATOR	1
7	D10186570.9	BOTTLE RADIATOR ASSEMBLY RECOVERY (1.5 LITRE)	1
7-1	D10801990.9	BOTTLE RADIATOR ASSEMBLY RECOVERY	1
8	D10555800.9	PLATE BAFFLE RADIATOR FRAME	1
9	D10547430.9	MESH ASSEMBLY RADIATOR FRONT	1
10	D10557900.9	SPACER FAN WATER COOLING	1
11	D10521940.9	FAN ASSEMBLY WATER COOLING	1
12	D10547480.9	HOSE RADIATOR TOP	1
13	D10547490.9	HOSE RADIATOR BOTTOM	1
14	D10017540.9	CLAMP RADIATOR HOSE UPPER	4
15	D86500030.9	WASHER M8 SPRING LOCK	11
16	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	3
16-1	D81501450.9	BOLT M8X1.0X30-8.8 HEX HEAD	3
17	D85500050.9	WASHER M8 FLAT	11
18	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
19	D81500210.9	BOLT M10X1.50X35-6.6P HEX HEAD	4
19-1	D82500160.9	SCREW M10X1.50X45-8.8P HEX HEAD	4
20	D86500050.9	WASHER M10 SPRING LOCK	4
21	D10212530.9	BEADING CONSOLE FUEL TANK	1
22	D10559580.9	FOAM SEALING RADIATOR BOTTOM	1
23	D82500050.9	SCREW M6X1.00X12-6.8 HEX HEAD	2
24	D85500040.9	WASHER M6 FLAT	6
25	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	4
26	D86500040.9	WASHER M6 SPRING LOCK	4
27	D81503520.9	BOLT M6X1.0X50-10.9 HEX HEAD	4
28	D10521030.9	CAP ASSEMBLY PRESSURE RADIATOR (M/S SM AUTO)	1

TABLE-32
AIR CLEANER SUBASSEMBLY




TABLE-32**AIR CLEANER SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10517880.9	CLEANER ASSEMBLY ENGINE AIR	1
2	D10522000.9	BRACKET ASSEMBLY AIR CLEANER	1
3	D10521960.9	BRACKET ASSEMBLY AIR CLEANER HOLDING REAR	1
3-1	D10521960AD.9	BRACKET ASSEMBLY AIR CLEANER HOLDING REAR	1
4	D83500070.9	NUT M6X1.00-6 HEX	2
5	D10521990.9	RUBBER STRAP ASSEMBLY AIR CLEANER HOLDING	1
6	D10522380.9	PIPE AIR CLEANER INTAKE	1
7	D10532900.9	INDICATOR RESTRICTION AIR CLEANER	1
8	D10521950.9	HOSE AIR CLEANER TO INTAKE MANIFOLD	1
9	D10017170.9	CLAMP ASSEMBLY 70MM DIAMETER	3
10	D86500030.9	WASHER M8 SPRING LOCK	6
11	D81500590.9	BOLT M8X1.25X25-6.6 HEX HEAD	2
11-1	D81501450.9	BOLT M8X1.0X30-8.8 HEX HEAD	2
12	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	2
13	D85500050.9	WASHER M8 FLAT	9
14	D83500060.9	NUT M8X1.25-6 HEX	2
15	D82500070.9	SCREW M8X1.25X15-6.8 HEX HEAD	1
16	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2
17	D10517920.9	FILTER ASSEMBLY PRIMARY ENGINE AIR CLEANER	1

TABLE-33
EXHAUST SYSTEM SUBASSEMBLY




TABLE-33
EXHAUST SYSTEM SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10551000.9	MUFFLER ASSEMBLY HORIZONTAL(INSIDE)	1
2	D10551010.9	PIPE EXHAUST AND BRACKET ASSEMBLY	1
3	D10551080.9	GASKET MUFFLER OUTLET	1
4	D10551070.9	GASKET MUFFLER INLET	1
5	D83500060.9	NUT M8X1.25-6 HEX	4
6	D86500030.9	WASHER M8 SPRING LOCK	8
7	D81501580.9	BOLT M8X1.25X16 HEX HEAD FLANGED	2
8	D85500050.9	WASHER M8 FLAT	6
9	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	2
10	D81500310.9	SCREW M8X1.25X30-8.8 HEX HEAD	2

TABLE-34
CRANKCASE (OIL SEAL CASE)




TABLE-34**CRANKCASE (OIL SEAL CASE)**

Fig. No.	Part No.	Description	Qty
1	D10733160.9	SEAL,SIDE (MITSUBISHI PART NO.31A07-12200)	4
2	D10733170.9	SHAFT,OIL FILTER (MITSUBISHI PART NO.30N07-02400)	1
3	D10733180.9	CASE,OIL SEAL (MITSUBISHI PART NO.31N07-01400)	1
4	D10733190.9	GASKET,OIL SEAL CASE (MITSUBISHI PART NO.31A07-11701)	1
5	D10698310.9	SEAL OIL (MITSUBISHI PART NO 31A0702300)	1
6	D10733210.9	BOLT (MITSUBISHI PART NO. 31N07-02300)	5

TABLE-35
DRAIN COCK & PIPE




TABLE-35
DRAIN COCK & PIPE

Fig. No.	Part No.	Description	Qty
1	D10733220.9	PLUG,TAPERED (MITSUBISHI PART NO. 30N07-02500)	1

TABLE-36
MAIN BEARING




TABLE-36
MAIN BEARING

Fig. No.	Part No.	Description	Qty
1	D10733230.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01010)	1
2	D10733240.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01020)	1
3	D10733250.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01030)	1
4	D10733260.9	BEARING SET,CRANKSHAFT (MITSUBISHI PART NO. 31A09-01040)	1

TABLE-37
TIMING GEAR CASE




TABLE-37
TIMING GEAR CASE

Fig. No.	Part No.	Description	Qty
1	D10733270.9	PLATE,FRONT (MITSUBISHI PART NO. 31A11-02100)	1
2	D10733280.9	GASKET,FRONT PLATE (MITSUBISHI PART NO. 31N11-00600)	1
3	D10732940.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08016)	5
4	D10733290.9	CASE,GEAR (MITSUBISHI PART NO. 31A11-10103)	1
5	D10733300.9	GASKET,GEAR CASE (MITSUBISHI PART NO. 31A11-11101)	1
6	D10733310.9	BOLT (MITSUBISHI PART NO. 31N11-00900)	8
7	D10698380.9	OIL SEAL (MITSUBISHI PART NO MD008762)	1
8	D10733330.9	HOUSING,GEAR PUMP (MITSUBISHI PART NO. 31A11-05101)	1
9	D10733340.9	GASKET,HOUSING (MITSUBISHI PART NO.31A11-05201)	1
10	D10733350.9	COVER,OIL PUMP SHAFT (MITSUBISHI PART NO.MM401205)	1
11	D10733360.9	COVER,OIL PUMP (MITSUBISHI PART NO. K7910451)	1
12	D10733370.9	GASKET,OIL PUMP COVER (MITSUBISHI PART NO. 30A11-00101)	2
13	D10733380.9	CAP,FILLER (MITSUBISHI PART NO. 31A42-01300)	1
14	D10733390.9	BOLT,W/WASHER (MITSUBISHI PART NO. F1805-08030)	1
15	D10733400.9	STUD (MITSUBISHI PART NO. MS401433)	1
16	D10733410.9	STUD (MITSUBISHI PART NO.MS401426)	1
17	D10733420.9	NUT (MITSUBISHI PART NO. F2300-08000)	4
18	D10733430.9	BOLT,W/WASHER (MITSUBISHI PART NO.F1825-08016)	4
19	D10733440.9	BOLT (MITSUBISHI PART NO. F1035-08070)	2
20	D10733450.9	WASHER,SPRING (MITSUBISHI PART NO. F2515-08000)	4

TABLE-38
TIMING GEAR




TABLE-38
TIMING GEAR

Fig. No.	Part No.	Description	Qty
1	D10733780.9	GEAR,CRANKSHAFT (MITSUBISHI PART NO. 31N23-10300)	1
2	D10733790.9	GEAR,CAMSHAFT (MITSUBISHI PART NO. 31N23-10400)	1
3	D10733800.9	GEAR,INJECTION PUMP (MITSUBISHI PART NO. 31N23-00700)	1
4	D10733810.9	GEAR ASSY,IDLER (MITSUBISHI PART NO. 31N23-10020)	1
5	D10733820.9	BUSHING,IDLER GEAR (MITSUBISHI PART NO. 31A23-00600)	1
6	D10733830.9	GEAR,OIL PUMP (MITSUBISHI PART NO. 31A23-01502)	1
7	D10733840.9	BEARING,BALL (MITSUBISHI PART NO.MD712517)	2

TABLE-39
OIL PAN




TABLE-39**OIL PAN**

Fig. No.	Part No.	Description	Qty
1	D10733460.9	PAN ASSY,OIL (MITSUBISHI PART NO. 31N13-02010)	1
2	D10733470.9	GASKET (MITSUBISHI PART NO. 31N13-00400)	2
3	D10733480.9	PLUG,DRAIN (MITSUBISHI PART NO. 31N13-00500)	2
4	D10733490.9	BOLT,FLANGE (MITSUBISHI PART NO. 30H13-00801)	12
5	D10733500.9	BOLT (MITSUBISHI PART NO.F1035-08040	1
6	D10733510.9	BOLT (MITSUBISHI PART NO. MM434762)	2

TABLE-40
PISTON




TABLE-40
PISTON

Fig. No.	Part No.	Description	Qty
7	D10733590.9	PISTON (MITSUBISHI PART NO. 31N17-03400)	3
8	D10733600.9	PIN,PISTON (MITSUBISHI PART NO. 31A17-10602)	3
9	D10733610.9	RING SET PISTON (MITSUBISHI PART NO.31A17-00010)	3
10	D10733620.9	RING SET PISTON (MITSUBISHI PART NO. 31A17-00020)	3
11	D10733630.9	RING SET PISTON (MITSUBISHI PART NO. 31A17-00030)	3
12	D10733640.9	PISTON (MITSUBISHI PART NO. 31N17-03500)	3
13	D10733650.9	PISTON (MITSUBISHI PART NO. 31N17-03600)	3

TABLE-41
CONNECTING ROD




TABLE-41
CONNECTING ROD

Fig. No.	Part No.	Description	Qty
1	D10733660.9	ROD ASSY,CONNECTING (MITSUBISHI PART NO. 31N19-00070)	3
2	D10733670.9	NUT,CONNECTING ROD (MITSUBISHI PART NO. MD006704)	6
3	D10733680.9	BOLT,CONNECTING ROD (MITSUBISHI PART NO. MD021105)	6
4	D10733690.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO.30A19-00040)	3
5	D10733700.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10010)	3
6	D10733710.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10020)	3
7	D10733720.9	BEARING SET,CONNECTIN ROD (MITSUBISHI PART NO. 30A19-10030)	3

TABLE-42
CRANKSHAFT




TABLE-42
CRANKSHAFT

Fig. No.	Part No.	Description	Qty
1	D10733730.9	CRANKSHAFT (MITSUBISHI PART NO. 31B20-00204)	1
2	D10732920.9	KEY,WOODRUFF (MITSUBISHI PART NO. F2872-05019)	2
3	D10733740.9	WASHER,PLAIN (MITSUBISHI PART NO. F2500-18000)	1
4	D10733750.9	WASHER,SPRING (MITSUBISHI PART NO.F2515-18000)	1
5	D10733760.9	NUT (MITSUBISHI PART NO. F2300-18000)	1

TABLE-43
CRANK PULLEY




TABLE-43
CRANK PULLEY

Fig. No.	Part No.	Description	Qty
1	D10733770.9	PULLEY,CRANK (MITSUBISHI PART NO.31N20-00601)	1

TABLE-44
DRIVE TRAIN PTO AND SHIFTING SUBASSEMBLY





TABLE-44
DRIVE TRAIN PTO AND SHIFTING SUBASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10541350.9	FORK PTO SHIFTING	1
2	D10541360.9	RAIL PTO SHIFTING	1
3	D10541370.9	LEVER PTO SHIFTING	1
4	D10006740.9	BALL 5/16" SNAP LOCK	1
5	D10543910.9	SPRING PTO SHIFTING	1
6	D82501100.9	SCREW GRUB M10X1.5X10 - 45H	1
7	D10007720.9	SEAL O RING 2.00X14.00	1
8	D10543890.9	SCREW PTO RAIL LOCK	1
9	D83500090.9	NUT M10X1.50-8 HEX	1
9-1	D83500170.9	NUT M10X1.50 NYLOCK HEX	1
10	D10556870.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (PTO)	1
11	D10683440.9	PIN 6.0X35 SPRING DOWEL COMBINATION TYPE	1
12	D10541340.9	RETAINER PTO OUTPUT SHAFT	1
13	D10541490.9	BEARING ROLLER NJ 205	1
14	D10001040.9	BEARING BALL PTO COUNTERSHAFT	3
14-1	D10002140.9	BEARING BALL PTO SHAFT REAR AXLE	1
14A	D10001040.9	BEARING BALL PTO COUNTERSHAFT	2
15	D10452820.9	SEAL OIL 35X60X14.5 PTO OUTPUT SHAFT	1
16	D90500370.9	CIRCLIP B47X2.0 H	1
17	D10541470.9	BEARING BALL 6005	1
18	D10170170.9	BEARING BALL 6305	2
19	D10538810.9	SHAFT INPUT PTO (Z-13 / Z-11)	1
20	D10541320.9	SHAFT PTO OUTPUT	1
21	D90000550.9	CIRCLIP A35.0X2.5 H	1
22	D10538830.9	GEAR PTO DRIVEN (Z-49)	1
23	D90000240.9	CIRCLIP B72X2.5 N	2
24	D10538860.9	SLEEVE PTO SHIFTING	1
25	D10538850.9	GEAR PTO DRIVEN (Z-51)	1
26	D10590350.9	SPACER PTO OUTPUT SHAFT (4.7 MM)	AR
27	D10590360.9	SPACER PTO OUTPUT SHAFT (4.8 MM)	AR
28	D10590370.9	SPACER PTO OUTPUT SHAFT (4.9 MM)	AR
29	D10590380.9	SPACER PTO OUTPUT SHAFT (5.0 MM)	AR
30	D10590390.9	SPACER PTO OUTPUT SHAFT (5.1 MM)	AR
31	D10549280.9	CAP PTO SHAFT REAR AXLE	1
32	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	4
33	D81503270.9	BOLT M10X25X1.5-10.9 ALLEN	4
34	D86500090.9	WASHER M10 SPRING LOCK	4
35	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-45
SHAFT PROPELLER ASSEMBLY (4WD COMPACT)




TABLE-45
SHAFT PROPELLER ASSEMBLY (4WD COMPACT)

Fig. No.	Part No.	Description	Qty
1	D10554580.9	COUPLING ASSEMBLY PROPELLER SHAFT	1
2	D90500100.9	CIRCLIP B40X1.75 N	1
4	D87500510.9	PIN 6.0X35.0 SPRING DOWEL	2
5	D10554620.9	SHAFT PROPELLER (4WD)	1
6	D10548310.9	COUPLING PROPELLER SHAFT (4WD)	1

TABLE-46
TRANSMISSION ASSEMBLY DRESSED UP




TABLE-46
TRANSMISSION ASSEMBLY DRESSED UP

Fig. No.	Part No.	Description	Qty
1	D93400450.9	PIN 10X45 CLEVIS	2
2	D10552680.9	PIN LEVER 2WD 4WD ASSEMBLY	1
3	D87000160.9	PIN 1/4"X1.50" SPRING DOWEL COMBINATION TYPE	2
4	D10552400.9	BLOCK SWIVEL BRAKE PEDAL REAR	4
5	D10552410.9	LEVER BRAKE PEDAL REAR	2
6	D10498400.9	SWITCH ASSEMBLY STOP LAMP	2
7	D86500030.9	WASHER M8 SPRING LOCK	4
8	D85500140.9	WASHER M10 FLAT	10
9	D10013460.9	PIN 1/8"X0.75" COTTER	10
10	D10556870.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (PTO)	1
11	D10552770.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (HIGH LOW MEDIUM)	1
12	D82500040.9	SCREW M8X1.25X20-8.8 HEX HEAD	4
13	D10552830.9	BRACKET ASSEMBLY HIGH LOW MEDIUM AND PTO LEVER HOLDING	1
14	D10559610.9	BRACKET PTO GEAR SHIFT SWITCH HOLDING ASSEMBLY	1
15	D10009600.9	WASHER 8.5X22 FLAT PHOSPHATED	4
16	D10552650.9	LEVER AND HUB ASSEMBLY GEAR SHIFTING TRANSMISSION (2WD 4WD)	1
17	D10182150.9	PLUG M16X1.5X16	1
18	D10554200.9	LEVER ASSEMBLY BRAKE PEDAL REAR RH	1
19	D10554230.9	LEVER ASSEMBLY BRAKE PEDAL REAR LH	1
20	D87500330.9	PIN 8X40 SPRING DOWEL COMBINATION TYPE	1

TABLE-47
HOUSING CLUTCH SUBASSEMBLY (9+3)




TABLE-47**HOUSING CLUTCH SUBASSEMBLY (9+3)**

Fig. No.	Part No.	Description	Qty
1	D10538270.9	RETAINER INPUT SHAFT	1
2	D10538220.9	SEAL TRANSMISSION INPUT SHAFT	1
3	D81503090.9	BOLT M8X1.25X16-8.8 HEX HEAD	4
4	D10559860.9	WASHER M8 FLAT COPPER (FUEL INJECTION PUMP)	1
5	D10538180.9	HOUSING CLUTCH COMPACT 9+3	1
6	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-48
CLUTCH RELEASE MECHANISM ASSEMBLY







TABLE-48**CLUTCH RELEASE MECHANISM ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10534720.9	HUB AND BUSH ASSEMBLY CLUTCH RELEASE	1
2	D81503440.9	BOLT M8X1.25X40-10.9 HEX HEAD	2
3	D10538360.9	BEARING CLUTCH RELEASE	1
4	D10534690.9	SHAFT ASSEMBLY CLUTCH RELEASE	1
5	D10007690.9	SEAL O RING 2.30X15.60	2
6	D10547230.9	WASHER NYLON 20.5X30 CLUTCH SHAFT	1
7	D92500010.9	GREASE NIPPLE B M6	2
8	D10534750.9	FORK CLUTCH RELEASE (M/S R G BRONZE)	1

TABLE-49
HOUSING SPEED ASSEMBLY




TABLE-50
GEAR ASSEMBLY IDLER REVERSE SPEED




TABLE-50
GEAR ASSEMBLY IDLER REVERSE SPEED

Fig. No.	Part No.	Description	Qty
1	D10534960.9	GEAR IDLER REVERSE SPEED Z-33	1
2	D10543070.9	BEARING NEEDLE ROLLER 25X35X30	1
3	D10534800.9	SHAFT REVERSE IDLER	1
4	D86500190.9	WASHER 45X25X1.5	2
5	D10005170.9	WASHER BOLT THRUST	1
6	D10293400.9	BOLT THRUST M8X1.25X59 HEX	1

TABLE-51
COVER TOP SPEED ASSEMBLY





TABLE-51**COVER TOP SPEED ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10543120.9	COVER TOP SPEED HOUSING	1
2	D10547250.9	INDICATOR TRANSMISSION OIL LEVEL	1
3	D10005120.9	WASHER M24 FLAT COPPER	1
4	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	10
5	D10034590.9	WASHER M8 FLAT	10
5-1	D85500130.9	WASHER M8 FLAT	10
6	D10667480.9	GASKET COVER TOP SPEED HOUSING	1

TABLE-52
DRIVER TRAIN INPUT ASSEMBLY




TABLE-52**DRIVER TRAIN INPUT ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10534680.9	SHAFT TRANSMISSION INPUT	1
2	D10541440.9	BEARING BALL 6305 Z-C3	1
3	D10170190.9	BEARING BALL 6205	1
4	D10553350.9	SPACER 35X25X3.0	1
5	D90500390.9	CIRCLIP B52X2.0 N	1
6	D90000480.9	CIRCLIP A25X2.0 H	2
7	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	1
8	D10534850.9	GEAR DRIVING CONSTANT MESH Z-18	1

TABLE-53
DRIVE TRAIN SPEED ASSEMBLY




TABLE-53
DRIVE TRAIN SPEED ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10534770.9	SHAFT SPEED DRIVING Z-13 / Z-14	1
2	D10170170.9	BEARING BALL 6305	2
3	D10541490.9	BEARING ROLLER NJ 205	1
4	D10541460.9	BEARING BALL 6304	1
5	D90500390.9	CIRCLIP B52X2.0 N	2
6	D90500410.9	CIRCLIP B62X2.0 N (IS 3075 PART-II)	2
7	D10534790.9	SHAFT SPEED DRIVEN	1
8	D10541740.9	WASHER 45X25X3 THRUST	1
9	D10541730.9	WASHER THRUST GEAR DRIVEN REVERSE SPEED	2
10	D10541710.9	SPACER 33X25 SPEED SHAFT	1
11	D10538330.9	COUPLING GEAR SHIFT	2
12	D10538340.9	HUB GEAR SHIFT 2ND AND 3RD SPEED	1
13	D10538350.9	HUB GEAR SHIFT 1ST AND REVERSE SPEED	1
14	D10534950.9	GEAR DRIVEN REVERSE SPEED Z-27	1
15	D10543080.9	BEARING NEEDLE ROLLER 28X33X17	2
16	D10538300.9	GEAR AND BUSH ASSEMBLY DRIVEN 1ST SPEED Z-29	1
17	D10534860.9	GEAR DRIVEN CONSTANT MESH Z-35	1
18	D10534890.9	GEAR DRIVING 2ND SPEED Z-19	1
19	D10538280.9	GEAR AND BUSH ASSEMBLY DRIVEN 2ND SPEED Z-30	1
20	D10534940.9	GEAR DRIVEN 3RD SPEED Z-23	1
21	D10534930.9	GEAR DRIVING 3RD SPEED Z-26	1

TABLE-54
SPEED SHIFTING SYSTEM ASSEMBLY




TABLE-54
SPEED SHIFTING SYSTEM ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10535020.9	RAIL GEAR SHIFT 2-3 SPEED	1
2	D10535030.9	RAIL GEAR SHIFT 1-R SPEED	1
3	D10535040.9	FORK GEAR SHIFT 1-R SPEED	1
4	D10535050.9	FORK GEAR SHIFT 2-3 SPEED	1
5	D83000010.9	NUT 3/8"-24 HEX	2
6	D10000550.9	SCREW TRANSMISSION CONNECTOR LOCK	2
7	D10543110.9	PIN DETENT DIA8.0X25.6	2
8	D10543130.9	SPRING SPEED GEAR SHIFT	2
9	D10006740.9	BALL 5/16" SNAP LOCK	2
10	D10535140.9	INTERLOCK GEAR SHIFTING	1
11	D93100010.9	PLUG 1/4"-18 PIPE	1

TABLE-55
GEAR SPEED SELECTION ASSEMBLY




TABLE-55
GEAR SPEED SELECTION ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D10510300.9	PLUG DIFFERENTIAL LOCK LEVER SHAFT RH-FRONT	1
2	D10589570.9	SEAL OIL SPEED SHIFT SHAFT	1
3	D10586100.9	SHAFT SPEED SHIFTING	1
4	D85500600.9	WASHER 30X20X2.0 FLAT	2
5	D10587520.9	SPRING SPEED SHIFTING 9+3	1
6	D10546180.9	PIN REAR AXLE DIFFERENTIAL LOCK SHAFT	1
7	D87500680.9	PIN 8X32 SPRING DOWEL COMBINATION TYPE	1
8	D10586110.9	LEVER SPEED SHIFTING	1
9	D10203560.9	CLAMP GROMMET GEAR SHIFTING LEVER	1
10	D10671030.9	BOOT HOUSING MOUNTING MAIN GEAR SHIFT LEVER	1

TABLE-56
DRIVE TRAIN 4WD ASSEMBLY (9+3)




TABLE-56**DRIVE TRAIN 4WD ASSEMBLY (9+3)**

Fig. No.	Part No.	Description	Qty
1	D10542290.9	COVER FRONT DROP BOX	1
2	D93601110.9	SEAL OIL 22X37X7.0	1
3	D93601120.9	SEAL O RING 1.78X42.0	1
4	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	4
5	D10542280.9	SHAFT OUTPUT DROP BOX	1
6	D10542260.9	GEAR OUTPUT 4WD Z-25	1
7	D10548300.9	SPRING COMPRESSION GEAR (4WD)	1
8	D10006740.9	BALL 5/16" SNAP LOCK	1
9	D10583080.9	SPACER 20X26X8.0 SHAFT DROP BOX	1
10	D10541470.9	BEARING BALL 6005	1
11	D90000480.9	CIRCLIP A25X2.0 H	1
12	D10152510.9	SEAL OIL 20.0X30.0X7.0	1
13	D10542300.9	LEVER 4WD ENGAGE	1
14	D10252790.9	PIN PTO SHIFTER FORK	1
15	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-57
PLATE INTERMEDIATE TRANSMISSION ASSEMBLY




TABLE-57**PLATE INTERMEDIATE TRANSMISSION ASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D10538230.9	PLATE INTERMEDIATE TRANSMISSION	1
2	D81502150.9	BOLT M10X1.50X25-10.9 HEX HEAD	4
3	D10001990.9	BEARING ASSEMBLY TRANSMISSION MAIN SHAFT REAR PILOT	1
4	D10542240.9	GEAR DRIVER 4WD Z 23	1
5	D10541490.9	BEARING ROLLER NJ 205	1
6	D10541500.9	BEARING ROLLER NJ 204	1
7	D90500390.9	CIRCLIP B52X2.0 N	1

TABLE-58
GEAR ASSEMBLY 4WD IDLER




TABLE-58**GEAR ASSEMBLY 4WD IDLER**

Fig. No.	Part No.	Description	Qty
1	D10542270.9	SHAFT IDLER 4WD	1
2	D10542250.9	GEAR IDLER 4WD Z-26	1
3	D10106190.9	BEARING NEEDLE ROLLER (25X33X23.8)	1
4	D90000480.9	CIRCLIP A25X2.0 H	1
5	D86500190.9	WASHER 45X25X1.5	1
6	D10673250.9	WASHER THRUST GEAR 4WD IDLER	1

TABLE-59
GEAR DRIVE TRAIN RANGE ASSEMBLY (9+3)




TABLE-59**GEAR DRIVE TRAIN RANGE ASSEMBLY (9+3)**

Fig. No.	Part No.	Description	Qty
1	D10534980.9	GEAR DRIVING HIGH RANGE Z-27	1
2	D10534990.9	GEAR DRIVING MEDIUM RANGE Z-23	1
3	D10535010.9	GEAR DRIVEN LOW RANGE Z-41	1
4	D10534970.9	SHAFT RANGE DRIVING Z-11	1
5	D90500140.9	CIRCLIP B55X2 N INTERNAL (IS3075 PART-II)	1
6	D10541450.9	BEARING BALL 6006	1
7	D10541770.9	SPACER RANGE DRIVING LOW GEAR	1
8	D10541760.9	SPACER RANGE DRIVING HIGH GEAR	1
9	D10547280.9	WASHER TAB LOCK	1
10	D83501010.9	NUT M22X1.5 HEX HEAD (THICKNESS 8.0MM)	1
11	D10535000.9	GEAR DRIVEN HIGH-MEDIUM RANGE Z-16/27	1
12	D90000080.9	CIRCLIP A30X1.5 N	1
13	D10541780.9	SPACER TAIL PINION SHAFT	1
14	D10052860.9	BEARING TAPPER ROLLER 30206	1
15	D10562420.9	SPACER GRADED PINION SHAFT (2.5 MM)	AR
16	D10562430.9	SPACER GRADED PINION SHAFT (2.6 MM)	AR
17	D10562440.9	SPACER GRADED PINION SHAFT (2.7 MM)	AR
18	D10562450.9	SPACER GRADED PINION SHAFT (2.8 MM)	AR
19	D10562460.9	SPACER GRADED PINION SHAFT (2.9 MM)	AR
20	D10562470.9	SPACER GRADED PINION SHAFT (3.0 MM)	AR
21	D10562480.9	SPACER GRADED PINION SHAFT (3.1 MM)	AR
22	D10562490.9	SPACER GRADED PINION SHAFT (3.2 MM)	AR
23	D90500320.9	CIRCLIP B62X3.0 H	1
24	D10541500.9	BEARING ROLLER NJ 204	1

TABLE-60
RANGE GEAR SHIFTING ASSEMBLY (COMPACT)




TABLE-60
RANGE GEAR SHIFTING ASSEMBLY (COMPACT)

Fig. No.	Part No.	Description	Qty
1	D87500700.9	PIN 6X30 SPRING DOWEL COMBINATION TYPE	1
2	D10535070.9	RAIL RANGE SHIFTING	1
3	D10535080.9	SHAFT AND LEVER ASSEMBLY RANGE SHIFTING	1
4	D10152510.9	SEAL OIL 20.0X30.0X7.0	1
5	D10535060.9	FORK RANGE SHIFTING	1
6	D10547290.9	SPRING RANGE GEAR SHIFT	1
7	D10006740.9	BALL 5/16" SNAP LOCK	1

TABLE-61
HARDWARE BUCKLE UP TRANSMISSION AND REAR AXLE SUBASSEMBLY




TABLE-61**HARDWARE BUCKLE UP TRANSMISSION AND REAR AXLE SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	8
2	D81503420.9	BOLT M10X1.50X70-10.9 HEX HEAD	2
3	D86500090.9	WASHER M10 SPRING LOCK	10
4	D10668700.9	COUPLING PTO INPUT SHAFT	1
5	D10547270.9	COUPLING COUNTERSHAFT SPEED AND RANGE	1
6	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-62
HARDWARE BUCKLE UP ADAPTOR PLATE & BACKEND HOUSING SUBASSEMBLY




TABLE-62**HARDWARE BUCKLE UP ADAPTOR PLATE & BACKEND HOUSING SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D81503430.9	BOLT M10X1.50X95-10.9 HEX HEAD	1
2	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	13
3	D86500090	WASHER M10 SPRING LOCK	14
4	D95010830.9	LOCTITE 5060	AR

TABLE-63
HARDWARE BUCKLE UP CLUTCH HOUSING & SPEED HOUSING SUBASSEMBLY




TABLE-63**HARDWARE BUCKLE UP CLUTCH HOUSING & SPEED HOUSING SUBASSEMBLY**

Fig. No.	Part No.	Description	Qty
1	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	8
2	D86500090	WASHER M10 SPRING LOCK	8
3	D95013250.9	SEALANT LIQUID ANAEROBIC (HIGHER STRENGTH)	AR

TABLE-64
DIFFERENTIAL ASSEMBLY FRONT AXLE (4WD COMPACT)




TABLE-64**DIFFERENTIAL ASSEMBLY FRONT AXLE (4WD COMPACT)**

Fig. No.	Part No.	Description	Qty
1	D10528170.9	CASE DIFFERENTIAL FRONT AXLE	1
2	D10520860.9	BEVEL SIDE GEAR DIFFERENTIAL Z-16	2
3	D10520870.9	PINION GEAR DIFFERENTIAL Z-10	2
4	D10541560.9	WASHER THRUST 32X20.5X2 DIFFERENTIAL	2
5	D87500480.9	PIN 5.0X24.0 SPRING DOWEL	2
6	D10528220.9	SHAFT HALF AXLE LH	1
7	D10528230.9	SHAFT HALF AXLE RH	1
8	D10528180.9	GEAR SET BEVEL PINION AND CROWN WHEEL FRONT AXLE (10/21)	1
9	D10541630.9	RING SNAP DIFFERENTIAL FRONT AXLE	1
10	D10602220.9	BEARING BALL 6210 CN	2
11	D10106690.9	CIRCLIP B90X2.80 HB	1
12	D10546960.9	WASHER 89.90X80.0X3.0	1
13	D10546970.9	SHIM 89.90X81.0 (0.125 MM)	1
14	D10546980.9	SHIM 89.90X81.0 (0.2285 MM)	1
15	D10546990.9	SHIM 89.90X81.0 (0.4065 MM)	1

TABLE-65
RETAINER AND BEVEL PINION SHAFT ASSEMBLY FRONT AXLE (4WD COMPACT)




TABLE-65**RETAINER AND BEVEL PINION SHAFT ASSEMBLY FRONT AXLE (4WD COMPACT)**

Fig. No.	Part No.	Description	Qty
1	D10528210.9	RETAINER PINION FRONT AXLE	1
2	D10533280.9	BEARING TAPER ROLLER 32006X	1
3	D10541570.9	NUT CRIMP M24X1.5 HEX HEAD	1
4	D10154560.9	SEAL O RING 2.65X65.0	1
5	D10001990.9	BEARING ASSEMBLY TRANSMISSION MAIN SHAFT REAR PILOT	1
6	D10541580.9	SHIM RETAINER PINION (0.075 MM)	1
7	D10541590.9	SHIM RETAINER PINION (0.125 MM)	1
8	D10541600.9	SHIM RETAINER PINION (0.2285 MM)	1
9	D10541610.9	SHIM RETAINER PINION (0.4065 MM)	1
10	D81503270.9	BOLT M10X25X1.5-10.9 ALLEN	4

TABLE-66
CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (UPTO T052417111LG)




TABLE-66**CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (UPTO T052417111LG)**

Fig. No.	Part No.	Description	Qty
1	D10508760.9	DISC ASSEMBLY CLUTCH 8.75" ORGANIC LINING	1
2	D10508770.9	COVER ASSEMBLY CLUTCH 8.75" (ORGANIC)	1
3	D10538690.9	BEARING BALL 6001 2RS	1
4	D10044920.9	DOWEL FLY-WHEEL	3
5	D86500030.9	WASHER M8 SPRING LOCK	6
6	D87500030.9	PIN 10X22 PLAIN DOWEL	2
7	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	6

TABLE-67
CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (FROM T052427038BG)




TABLE-67**CLUTCH ASSEMBLY COMPACT WITH HARDWARE (9+3) (FROM T052427038BG)**

Fig. No.	Part No.	Description	Qty
1	D10508760.9	DISC ASSEMBLY CLUTCH 8.75" ORGANIC LINING	1
2	D10508770.9	COVER ASSEMBLY CLUTCH 8.75" (ORGANIC)	1
3	D10538690.9	BEARING BALL 6001 2RS	1
4	D10044920.9	DOWEL FLY-WHEEL	3
5	D86500030.9	WASHER M8 SPRING LOCK	6
6	D87500030.9	PIN 10X22 PLAIN DOWEL	2
7	D81500110.9	BOLT M8X1.25X20-8.8 HEX HEAD	6

TABLE-68
COUPLING TRANSMISSION CLUTCH HOUSING ASSEMBLY




TABLE-68
COUPLING TRANSMISSION CLUTCH HOUSING ASSEMBLY

Fig. No.	Part No.	Description	Qty
1	D81503430.9	BOLT M10X1.50X95-10.9 HEX HEAD	1
2	D81503870.9	BOLT M10X1.50X35-10.9 HEX HEAD (16 A/F)	13
3	D87500030.9	PIN 10X22 PLAIN DOWEL	2
4	D86500030.9	WASHER M8 SPRING LOCK	14

TABLE-69
WHEEL AND TYRE ASSEMBLY FRONT 6X12 (M/S BKT AGRI)




TABLE-69**WHEEL AND TYRE ASSEMBLY FRONT 6X12 (M/S BKT AGRI)**

Fig. No.	Part No.	Description	Qty
1	D83501030.9	NUT M12X1.5-10.9 HEX HEAD	10
2	D86500020.9	WASHER M12 SPRING LOCK	10
3	D10538460.9	RIM ASSEMBLY FRONT WHEEL 5JX12" (ANTIQUE SILVER)	2
4	D10538050.9	TUBE ASSEMBLY FRONT WHEEL 6X12 (TR13)	2
5	D10517660.9	TYRE ASSEMBLY FRONT WHEEL 6.00-12 TR128	2

TABLE-70
WHEEL AND TYRE ASSEMBLY REAR 8.3X20 (M/S BKT AGRI)




TABLE-70**WHEEL AND TYRE ASSEMBLY REAR 8.3X20 (M/S BKT AGRI)**

Fig. No.	Part No.	Description	Qty
1	D83501020.9	NUT M16X1.5-10.9 HEX HEAD	10
2	D86500060.9	WASHER M16 SPRING LOCK	10
3	D10538480.9	RIM ASSEMBLY REAR WHEEL W7X20" (ANTIQUE SILVER)	2
4	D10538070.9	TUBE ASSEMBLY REAR WHEEL 8.3X20 (TR218A)	2
5	D10517680.9	TYRE ASSEMBLY REAR WHEEL 8.3X20 (FARM 2000)	2